STUDER D740

CD-Recorder

Serviceanleitung

- 1. Allgemeines / Installation
- 2. Bedienung
- 3. Automatisiertes Überspielen
- 4. Serviceanleitung
- 5. Ersatzteile

INDEX

Service Instructions

- 1. General / Installation
- 2. Operation
- 3. Automated recording
- 4. Service Instructions
- 5. Spare parts

INDEX

6. Schemata / Circuit Diagrams

Prepared and edited by: STUDER INTERNATIONAL (a division of STUDER REVOX AG) TECHNICAL DOCUMENTATION Althardstrasse 10 CH - 8105 Regensdorf - Zürich

We reserve the right to make alterations.

Copyright by STUDER REVOX AG printed in Switzerland Order no. 10.27.3060 (Ed.0892)

STUDER is a registered trade mark of STUDER REVOX AG Regensdorf STUDER ist ein eingetragenes Warenzeichen der STUDER REVOX AG Regensdorf **Hint:** The descriptions in this service manual are based on software version 22.

But theres is no general need to change software 16 to 22 or >22.

In case of changing software 16 to 22 or >22 the following change in hardware

has to be done:

On SERVO BOARD short circuit of pin 9 and 10 of ic 7501

Hinweis: Die Beschreibungen in diesem Service Handbuch basieren im wesentlichen auf der

Software-Version 22. Es besteht am D740 jedoch keine generelle Notwendigkeit, die

Softwareversion 16 durch 22 oder >22 zu ersetzen.

Im Falle eines Softwarewechsels von 16 auf 22 oder >22 muss folgende Hardware-

anpassung ausgeführt werden:

Auf dem SERVO BOARD müssen Pin 9 und Pin 10 vom IC 7501 kurzgeschlossen

werden.

ERSTE HILFE (bei Stromunfällen)

- Bei einem Stromunfall die betroffene Person raschmöglichst vom Strom tren-
- Durch Ausschalten des Gerätes
- Ausziehen oder unterbrechen der Netzzuleitung
- Betroffene Personen mit isoliertem Material (Holz, Kunststoff) von der Gefahrenquelle wegstossen
- Nach einem Stromunfall sollte immer ein Arzt aufgesucht werden.

ACHTUNG!

EINEUNTER SPANNUNG STE-HENDE PERSON DARF NICHT BERÜHRT WERDEN, SIE KÖN-NEN DABEI SELBST ELEK-TRISIERT WERDEN

- 2. Bei Bewusstlosigkeit des Verunfallten:
- Puls kontrollieren,
- bei ausgesetzter Atmung künstlich beatmen,
- Seitenlagerung des Verunfallten vornehmen und Arzt verständigen.

FIRST AID (in case of electric shock)

- Separate the person as quickly as possible from the electric power source:
- by switching off the equipment, unplugging or disconnecting the mains cable,
- pushing the person away from the power source by using dry insulating material (such as wood or plastic).
- After having sustained an electric shock, always consult a doctor.

PREMIERS SECOURS (en cas d'électrocution)

- Si la personne est dans l'impossibilité de se libérer:
- Couper l'interrupteur prin-
- Couper le courant
- Repousser la personne de l'appareil à l'aide d'un objet en matière non conductrice (matière plastique ou boîs)
- Après une électrocution. consulter un médecin.

WARNING!

DONOTTOUCHTHE PERSON OR HIS CLOTHING BEFORE POWER IS TURNED OFF. OTHERWISE YOU STAND THE RISK OF SUSTAINING AN ELECTRIC SHOCK AS WELL

- If the person is unconscious
- Check the pulse,
- reanimate the person if respiration is poor,
- lay the body own and turn it to one side, call for a doctor immediately.

ATTENTION!

NE JAMAIS TOUCHER UNE PERSONNE QUI EST SOUS TENSION. SOUS PEINEDESU-BIR EGALEMENT UNE ELEC-**TROCUTION**

- En cas de perte de connaissance de la personne électrocutée:
- Controller le pouls
- Si nécessaire, pratiquer la respiration artificielle
- Placer l'accidenté sur le flanc et consulter un médecin.

CLASS 1 LASER PRODUCT

CAUTION: Hazardous laser and electromagnetic radiation when open!

Rayonnement laser et électromagnétique dangereux en cas ATTENTION:

d'ouverture du couvercle!

Gefährliche Laser- und elektromagnetische Strahlung im ACHTUNG:

geöffneten Zustand.

Usynlig laserstraling ved abning nar sikkerhedsafbrydere er af ADVARSEL:

funktion, ungda udsaettelse for straling. (DK)

VAROITUS: Laitteen käyattäminen muulla kuin tässä käyttöohjeessa

> mainitulla tavalla saattaa altistaa käyttäjan turvallisuuslokan I ylittävälle nänäkymättömälle lasersäteilylle. (SF,SE)

VARNING: Om apparaten används pa annat sätt än i denna bruksanvisning

specificerats, kan användaren utsättas för osynlig laserstralning.

som överskrider gränsen för laserklass 1.

AVARSEL: Usynlig laserstraling nar deksel apnes. Unnga eksponering for

stralen. (N)

DANGER

INVISIBLE LASER RADIATION WHEN OPEN. AVOID DIRECT EXPOSURE TO BEAM.



To reduce the risk of electric shock, do not remove cover (or back). No user-serviceable parts inside. Refer servicing to qualified service personnel.

Afin de prévenir un choc électrique, ne pas enlever le couvercle (où l'arrière de l'appareil). Il ne se trouve à l'intérieur aucune pièce pouvant être réparée par l'usager.

Um die Gefahr des elektrischen Schlages zu vermeiden, entfernen Sie keine Abdeckung (oder Rückwand).

Überlassen Sie die Wartung und Reparatur dem qualifizierten Personal.



This symbol is intended to alert the user to presence of uninsulated "dangerous voltage" within the apparatus that may be of sufficient magnitude to constitute a risk of electric shock to person.

Ce symbole indique à l'utilisateur qu 'existent à l'intérieur de l'appareil des tensions dangereuses. Ces tensions élevées entrainent un risque de choc électrique en cas de contact.

Dieses Symbol deutet dem Anwender an, dass innerhalb des Gerätes die Gefahr der Berührung von "gefährlicher Spannung" besteht. Die Spannungsgrösse kann zu einem elektrischen Schlag führen.



This symbol is intended to alert the user to the presence of important operating and maintence (servicing) instructions in the enclosured documentation.

Ce symbole indique à l'utilisateur que la documentation jointe contient d'importantes instructions concernant le fonctionnement et la maintenance.

Dieses Symbol deutet dem Anwender an, dass die beigelegte Dokumentation wichtige Hinweise für Betrieb und Wartung beinhaltet.



ATTENTION: Observe precaution for handling electrostatic discharge sensitive

devices! Refer to chapter ESD.

ATTENTION: Respecter les précautions d'usage concernant la manipulation

de composants sensibles à l'électricité statique. Voir chapitre

ESD correspondant.

ACHTUNG: Vorsichtsmassnahmen bei Handhabung elektrostatisch

entladungsgefährdeter Bauelemente beachten! Siehe Kapitel

ESD.

Installation, Betrieb und Entsorgung

Vor der Installation des Gerätes müssen die hier aufgeführten und auch die weiter in dieser Anleitung mit △ bezeichneten Hinweise gelesen und während der Installation und des Betriebes beachtet werden. Das Gerät und sein Zubehör ist auf allfällige Transportschäden zu untersuchen.

Ein Gerät, das mechanische Beschädigung aufweist oder in welches Flüssigkeit oder Gegenstände eingedrungen sind, darf nicht ans Netz angeschlossen oder muss sofort durch Herausziehen des Netzsteckers vom Netz getrennt werden. Das Öffnen und Instandsetzen des Gerätes darf nur vom Fachpersonal unter Einhaltung der geltenden Vorschriften durchgeführt werden.

Für die Netzverbindung ist das mitgelieferte Netzkabel zu verwenden. Vor Anschluss des Netzkabels an die Netzsteckdose müssen die Stromversorgungswerte und die Anschlusswerte des Gerätes (Netzspannung, Netzfrequenz) überprüft werden, ob sie in den erlaubten Toleranzen liegen. Die im Gerät eingesetzten Sicherungen müssen den an dem Gerät angebrachten Angaben entsprechen.

Ein Gerät mit einem dreipoligen Netzstecker (Gerät der Schutzklasse I) muss an eine dreipolige Netzsteckdose angeschlossen und somit das Gerät mit dem Schutzleiter der Strominstallation verbunden werden (Für Dänemark gelten Starkstrombestimmungen, Abschnitt 107). Der im Gerät eingebaute dreipolige Apparatestecker muss mit einem Kabelstecker Bauart IEC 320 / C13 (Kaltapparatestecker mit weiblichen Kontakten) nach unterstehendem Bild angeschlossen werden:

Operation and waste disposal


Before you install the equipment, please read and adhere to the following recommendations and all sections of these instructions marked with \triangle .

Check the equipment for any transport damage.

A unit that is mechanically damaged or which has been penetrated by liquids or foreign objects must not be connected to the AC power outlet or must be immediately disconnected by unplugging the power cable. Repairs must only be performed by trained personnel in accordance with the applicable regulations.

Use the supplied power cable for connecting the unit to the AC power outlet. Before you connect the equipment to the AC power outlet, check that the local line voltage matches the equipment rating (voltage, frequency) within the admissible tolerance. The equipment fuses must be rated in accordance with the specifications on the equipment.

Equipment supplied with a 3-pole power plug (equipment conforming to protection class I) must be connected to a 3-pole AC power outlet so that the equipment is connected to the ground conductor of the AC supply. (For Denmark the Heavy current regulations, Section 107, are applicable). The 3-pole appliance inlet must be connected to an IEC 320/C13 cable socket (cold apparatus connector with female contacts) as shown in the diagram below:



View of cable female socket: L...... live, phase; brown National American Standard: black

N neutral; blue white

PE protective earth, ground; green-and-yellow green

Vue de la partie femelle du câble d'alimentation:

L.....phase, brune Standard National Américain: noire

N.....neutr, bleue blanc

PE....terre protectif, verte et jaune verte

Ansicht gegen Steckkontakte des Kabelsteckers

L.....Polleiter braun
N.....Neutralleiter hellblau

PE....Schutzleiter gelb/grün

Die Installation des Gerätes muss vermeiden dass:

- das Gerät Regen, Feuchtigkeit, direkter Sonneneinstrahlung oder übermässiger Wärmestrahlung von Wärmequellen (Heizgeräte, Heizungen, Spotlampen) ausgesetzt wird,
- die für den Betrieb des Gerätes benötigte Luftzirkulation beeinträchtigt und dadurch die zulässige maximale Lufttemperatur der Geräteumgebung überschritten wird (Wärmestau),
- die Belüftungsöffnungen des Gerätes blockiert oder abgedeckt werden.

Das Gerät und seine Verpackung darf nur sachgerecht entsorgt werden. Alle Teile des Gerätes, die gefährliche Stoffe (Quecksilber, Kadmium) beinhalten, wie z.B. Batterien und Akkumulatoren, müssen als Sondermüll behandelt werden.

Wartung und Reparatur

Durch Entfernen von Gehäuseteilen, Abschirmungen etc werden stromführende Teile freigelegt. Aus diesem Grunde müssen u.a. die folgenden Grundsätze beachtet werden:

Eingriff in das Gerät darf nur vom Fachpersonal unter Einhaltung der geltenden Vorschriften vorgenommen werden.

Vor Entfernen von Gehäuseteilen muss das Gerät ausgeschaltet und vom Netz getrennt werden.

Bei geöffnetem, vom Netz getrenntem Gerät dürfen Teile mit gefährlichen Ladungen (z. B. Kondensatoren, Bildröhren) erst nach deren kontrolliertem Entladen und heisse Bauteile (Leistungshalbleiter, Kühlkörper etc.) erst nach deren Abkühlen berührt werden.

Bei Wartungsarbeiten am geöffneten, unter Netzspannung stehenden Gerät dürfen keine blanken Schaltungsteile und metallene Halbleitergehäuse weder direkt noch mit einem nichtisolierten Werkzeug berührt werden

Zusätzliche Gefahren bestehen bei unsachgemässer Handhabung besonderer Komponenten:

- Explosionsgefahr bei Lithiumzellen, elektrolytischen Kondensatoren und Leistungshalbleitern,
- Implosionsgefahr bei evakuierten Anzeigeeinheiten,
- Strahlungsgefahr bei Lasereinheiten (nichtionisierend), Bildröhren (ionisierend),
- Verätzungsgefahr bei Anzeigeeinheiten (LCD) und Komponenten mit flüssigem Elektrolyt.

Solche Komponenten dürfen nur vom dafür ausgebildeten Fachpersonal unter Verwendung von vorgeschriebenen Schutzmitteln (u.a. Schutzbrille, Handschuhe) gehandhabt werden.

The equipment installation **must satisfy** the following requirements

- Protection against rain, humidity, direct solar irradiation or strong thermal radiation from heat sources (heaters, radiators, spotlights).
- Unobstructed air circulation so that the maximum air temperature in the equipment environment will not be exceeded (no heat accumulation).
- Ventilation louvers of the equipment not blocked or covered.

The equipment and its packing material should ultimately be disposed off in accordance with the applicable regulations. All parts of the equipment that contain hazardous substances (mercury, cadmium) such as batteries must be treated as toxic waste.

Maintenance and Repair

The removal of housing parts, shields, etc. exposes energized parts. For this reason the following precautions should be observed:

Maintenance should only be performed by trained personnel in accordance with the applicable regulations. The equipment should be switched off and disconnected from the AC power outlet before any housing parts are removed.

Even after the equipment has been disconnected from the power, parts with hazardous charges (e.g. capacitors, picture tubes) should only be touched after they have been properly discharged. Hot components (power semiconductors, heat sinks, etc.) should only be touched after they have cooled off.

If maintenance is performed on a unit that is opened and switched on, no uninsulated circuit components and metallic semiconductor housings should be touched with uninsulated tools.

Certain components pose additional hazards:

- Explosion hazard from lithium batteries, electrolytic capacitors and power semiconductors,
- Implosion hazard from evacuated display units,
- Radiation hazard from laser units (non-ionizing), picture tubes (ionizing),
- Caustic effect of display units (LCD) and such components containig liquid electrolyte.

Such components should only be handled by trained personnel who are properly protected (e.g. by goggles, gloves).

Für Wartungsarbeiten und Reparaturen der sicherheitsrelevanten Teile des Gerätes darf nur Ersatzmaterial nach Herstellerspezifikation verwendet werden, gebrauchte Batterien und Akkumulatoren müssen fachgerecht entsorgt werden.

Das Gerät muss ordnungsgemäss und regelmässig gewartet und somit im sicheren Zustand erhalten werden. Bei ungenügender Wartung oder bei Änderungen der sicherheitsrelevanten Teile des Gerätes erlischt entsprechende Produktehaftung des Herstellers.

Störaussendung und Störfestigkeit

Das Gerät entspricht den Schutzanforderungen auf dem Gebiet der elektromagnetischen Phänomene, die u.a. in den Richtlinien 89/336/EWG und FCC, Part 15 aufgeführt sind :

- Die vom Gerät erzeugten elektromagnetischen Aussendungen sind soweit begrenzt, dass ein bestimmungsgemässer Betrieb anderer Geräte und Systeme möglich ist.
- 2. Das Gerät weist eine angemessene Festigkeit gegen elektromagnetische Störungen auf, so dass sein bestimmungsgemässer Betrieb möglich ist.

Das Gerät wurde getestet und erfüllt die Bedingungen der im Kapitel Technische Daten aufgeführten EMV-Standards, die für Bereiche Wohnung, Büro und leichte Industrie ausgelegt sind. Die Limiten dieser Standards gewährleisten mit einer angemessenen Wahrscheinlichkeit sowohl einen Schutz der Umgebung wie auch entsprechende Störfestigkeit des Gerätes. Eine absolute Garantie, dass keine unerlaubte elektromagnetische Beeinträchtigung während des Gerätebetriebes entsteht, ist jedoch nicht gegeben.

Um die Wahrscheinlichkeit solcher Beeinträchtigung möglichst auszuschliessen, sind u.a. folgende Massnahmen zu beachten:

- Installieren Sie das Gerät nach Angaben in der Bedienungsanleitung, verwenden Sie das mitgelieferte
 Zubehör
- Verwenden Sie im System und in der Umgebung, in denen das Gerät eingesetzt ist, nur solche Komponenten (Anlagen, Geräte), die ihrerseits die Anforderungen der obenerwähnten Standards erfüllen.
- Sehen Sie ein Erdungskonzept des Systems vor, das sowohl die Sicherheitsanforderungen (Erdung der Geräte Schutzklasse I mit einem Schutzleiter muss gewährleistet sein), wie auch die EMV-Belange berücksichtigt. Bei der Entscheidung zwischen Sternförmiger, flächenförmiger oder kombinierter Erdung sind Vor- und Nachteile gegeneinander abzuwägen.

For maintenance work and repair on components that influence the equipment safety, only replacement material conforming to the manufacturer's specifications may be used. Discharged batteries must be disposed of in accordance with the applicable environmental protection regulations.

The equipment should be properly serviced in regular intervals and be maintained in safe operating condition. If the equipment is not properly maintained or if any modifications are made to components that influence the equipment safety, the manufacturer's product liability becomes void.

Electromagnetic Compatibility

The equipment conforms to the protection requirements relevant to electromagnetic phenomena that are listed in the guidelines 89/336/EC and FCC, part 15.

- 1. The electromagnetic interference generated by the equipment is limited in such a way that other equipment and systems can be operated normally.
- 2. The equipment is adequately protected against electromagnetic interference so that it can operate correctly.

The equipment has been tested and conforms to the EMC standards applicable to residential, commercial and light industry, as listed in the Section 'Technical data'. The limits of these standards reasonably ensure protection of the environment and corresponding noise immunity of the equipment. However, it is not absolutely warranted that the equipment will not be adversely affected by electromagnetic interference during operation.

To minimize the probability of electromagnetic interference as far as possible, the following recommendations should be followed:

- Install the equipment in accordance with the operating instructions. Use the supplied accessories.
- In the system and in the vicinity where the equipment is installed, use only components (systems, equipment) that also fulfill the above EMC standards.
- Use a system grounding concept that satisfies the safety requirements (protection class I equipment must be connected with a protective ground conductor) that also takes into consideration the EMC requirements. When deciding between radial, surface or combined grounding, the advantages and disadvantages should be carefully evaluated in each case.

- Benutzen Sie abgeschirmte Kabel für die Verbindungen, für welche eine Abschirmung vorgesehen ist. Achten Sie auf einwandfreie, grossflächige, korrosionsbeständige Verbindung der Abschirmung zum ensprechenden Steckeranschluss resp. zum Steckergehäuse. Beachten Sie, dass eine nur an einem Ende angeschlossene Kabelabschirmung als eine Sende- resp. Empfangsantenne wirkt (z.B. bei wirksamer Kabellänge von 5m oberhalb von 10 MHz) und dass die Flanken der digitalen Kommunikationssignale hochfrequentige Aussendungen verursachen (z.B. LS oder HC-Logik bis 30 MHz).
- Vermeiden Sie Bildung von Stromschlaufen oder vermindern Sie deren unerwünschte Auswirkung, indem Sie die Fläche der Schlaufe möglichst klein halten und den in der Schlaufe fliessenden Störstrom durch Einfügen einer zusätzlichen Impedanz (z.B. Gleichtaktdrossel) reduzieren.

Elektrostatische Entladung (ESD) bei Wartung und Reparatur

Viele IC und andere Halbleiter sind empfindlich gegen elektrostatische Entladung (ESD). Unfachgerechte Behandlung der entsprechenden Komponenten bei Wartung und Reparatur kann deren Lebensdauer drastisch vermindern.

Bei der Handhabung der ESD-empfindlichen Komponenten sind u.a. folgende Regel zu beachten:

- ESD-empfindliche Komponenten müssen ausschliesslich in dafür bestimmten und bezeichneten Verpackungen gelagert und transportiert werden.
- Unverpackte ESD-empfindliche Komponenten dürfen nur in den dafür eingerichteten ESD-Schutzzonen (EPA, z. B. Gebiet für Feldservice, Reparaturplatz oder Serviceplatz) gehandhabt und nur von Personen berührt werden, die über ein Pulsarmband mit Widerstand mit dem Massepotential des Reparatur- oder Serviceplatzes verbunden sind. Das gewartete oder reparierte Gerät wie auch sämtliche Werkzeuge, Hilfsmittel, EPA-taugliche (elektrisch halbleitende) Arbeits-, Ablage- und Bodenmatten müssen ebenfalls mit diesem Massepotential verbunden sein.
- Anschlüsse der ESD-empfindlichen Komponenten dürfen unkontrolliert weder mit elektrostatisch aufladbaren (Gefahr von Spannungsdurchschlag), noch mit metallischen Oberflächen (Schockentladungsgefahr) in Berührung kommen.
- Um undefinierte transiente Beanspruchung der Komponenten und deren eventuelle Beschädigung mit unerlaubter Spannung oder Ausgleichsstrom zu vermeiden, dürfen elektrische Verbindungen nur am abgeschalteten Gerät nach dem Abbau allfälliger Kondensatorladungen erstellt oder getrennt werden.

• Use screened cables where screening is specified. The connection of the screening to the corresponding connector terminal or housing should have a large surface and be corrosion-proof. Please note that a cable screen connected at only one side acts and a transmitting or receiving antenna (e.g. with an effective cable length of 5 m the frequency is above 10 MHz) and that the edges of the digital communication signals cause high-frequency radiation (e.g. LS or HC logic up to 30 MHz).

Avoid current loops or prevent their adverse effects by keeping the loop surface as small as possible and reduce the noise current flowing through the loop by inserting an additional impedance (e.g. common-mode rejection choke).

Electrostatic discharge (ESD) during maintenance and repair

Many ICs and semiconductors are sensitive to electrostatic discharge (ESD). Their life can be drastically reduced by improper handling of such components during maintenance and repair work.

Please observe the following rules when handling ESD sensitive components:

- ESD sensitive components should only be stored and transported in the packing material specifically provided for this purpose.
- Unpacked ESD sensitive components should only be handled in ESD protected zones (EPA, e.g. area for field service, repair or service bench) and only be touched by persons who wear a wristlet that is connected to the ground potential of the repair or service bench. The equipment to be repaired or serviced and all tools, aids, electrically semiconducting work, storage and floor mats should also be connected to this ground potential.
- The terminals of ESD sensitive components should not come in uncontrolled contact with electrostatically chargeable (voltage puncture) or metallic surfaces (discharge shock hazard).
- To prevent undefined transient stress of the components and possible damage due to inadmissible voltages or compensation currents, electrical connections should only be established or separated when the equipment is switched off and after any capacitor charges have decayed.

Inhalt

1	_	emeines - Installation	
	1.1	Prinzip der CD-Aufnahme	3
		CD-Recorder D740	3
		CD-R	3
		Schreibvorgang	4
	1.2	Handhabung der beschreibaren CD-R	
	1.3	Installation	
		Lieferumfang	
		Netzanschluss	
		Eingänge	
		Ausgänge	
		Parallele Schnittstelle	
	1.4	Technische Daten CD-R (STUDER)	
	1.5	Technische Daten D740	٥
	1.5		
		1.5.1 Beschreibung	
		1.5.2 Elektrische Daten	
		1.5.3 Peripherie–Anschluss	
		1.5.4 Stromversorgung	
		1.5.5 Betriebsbedingungen	
		1.5.6 Abmessungen	
		1.5.7 Sicherheit	
	1.6	Blockdiagramm CD-Recorder D740	
	1.7	Masszeichnung CD-Recorder D740	13
2	Bed	lienung	14
	2.1	Bedienungselemente	14
		Anzeigefeld	
		Anschlussfeld	
	2.2	Wiedergabe	19
	2.3	Aufnahmefunktionen	
		Program Memory Area (PMA)	
		Analoge Aufnahmen	
		Digitale Aufnahmen	
		SKIP / UNSKIP	
	24	Parallele Fernbedienung 1.328.660	
3		omatisiertes Überspielen	
3		·	
	3.1	Analoge Zuspielgeräte	
		Digitale Zuspielgeräte	
		CD-Mehrfachkopierstation	
4	Ser	viceanleitung	
	4.1	Arbeitshinweise	
		4.1.1 Prüfmodus	
		4.1.2 Elektrostatisch empfindliche Bauteile "ESD"	
		4.1.3 Umrechnungstabelle Spannungspegel ↔ Dezibel	37
	4.2	Demontage	38
	4.3	Schaltungsbeschreibung	40
	4.4	Reinigung	
	4.5	Elektrische Einstellungen	
		4.5.1 Trafoeinheit 1.629.609	
		4.5.2 Netzteil 1.629.620.00	
		4.5.3 XLR-Board 1.629.630	
		4.5.4 Parallele Fernbedienung	
5	Ersa	atzteile	
_			
114	- -∧.	***************************************	ິວວ

STUDER D740 ALLGEMEINES

1 Allgemeines - Installation

1.1 Prinzip der CD-Aufnahme

CD-Recorder D740

Ohne zusätzliche Bediengeräte kann mit dem CD-Recorder D740 eine CD WRITE ONCE DISC (CD-R) beschrieben werden. Die Bedienung ist mit bekannten Aufnahmegeräten vergleichbar. Ebenso können die Aufnahmen sequentiell erfolgen. Es besteht die Möglichkeit während der Aufnahme Anfangspunkte und anschliessend Skip-Punkte zu programmieren. Zuletzt wird die Table of Contents (TOC) erstellt und die CD-R ist schliesslich auf jedem CD-Spieler abspielbar. Die Anwendungsbereiche sind weit gestreut, ob im Produktionsbetrieb oder Radiostudio. Anstelle eines Masters auf Magnetband (analog oder digital) tritt nun die beschreibbare CD-R, die einheitlich ohne Qualitätseinbussen und ohne Anpassung an unterschiedliche Normen weltweit abzuspielen ist. Der Programmaustausch ist durch die beträchtliche Verbreitung der CD-Spieler um einiges einfacher geworden.

CD-R

Die beschreibbare CD-R ist prinzipiell gleich einer bespielten konventionellen CD. Der Träger ist eine Scheibe aus Polycarbonat, in die FM-modulierte Führungsrillen zur Laserführung eingraviert sind. Darauf befindet sich die Absorptionsschicht, welche der Information entsprechend zerstört wird. Die Reflektionsschicht besteht infolge höherer Anforderungen an die Reflektionseigenschaften aus Gold. Abgeschlossen wird mit einer Schutzschicht und dem Labelaufdruck.




Fig. 1.1 Aufbau einer CD-R

ALLGEMEINES STUDER D740




Fig. 1.2 Aufbau einer konventionellen CD

Schreibvorgang

Beim Schreibvorgang erhitzt sich durch den Laser die Absorptionsschicht auf circa 250° C. Dies ist die Zersetzungstemperatur dieser Schicht. Durch die Wärme dringt das Polycarbonat in die zerstörte Absorptionsschicht. In der Art entstehen die Pits auf der CD-R.

Der CD-R-Standard ("Orange Book") erlaubt einen zusätzlichen Sektor vor dem Lead-In, die Program Memory Area (PMA). Dieses provisorische Inhalts-verzeichnis gilt für eine unvollständig bespielte CD-R und ermöglicht das sequentielle Bespielen. Erst wenn die CD-R vollständig bespielt ist, wird die "TOC" generiert und aufgeschrieben. Danach entspricht die aufgenommene CD-R der "Red-Book"-Norm und kann auf jedem beliebigen CD-Spieler abgespielt werden.

1.2 Handhabung der beschreibaren CD-R

Die CD-R ist besonders empfindlich gegen Kratzer und Verschmutzung auf beiden Seiten. Wird die CD-R nur an der Peripherie oder an der Peripherie und dem Mittelloch angefasst, lassen sich Fingerabdrücke vermeiden. Als Reinigungsmittel sind handelsübliche CD-Flüssigreiniger oder auch Äthylalkohol geeignet. Bei geringerer Verschmutzung reicht ein weiches trockenes Tuch. Entgegen mancher Vorstellung ist die Labelseite ebenso gegen Kratzer empfindlich, weil sich direkt unter der Schutzlackschicht die reflektierende Goldschicht befindet. Daher empfehlen wir dringend, zur Beschriftung nur den von STUDER gelieferten CD PEN zu benutzen. Kratzende Schreibwerkzeuge wie Kugelschreiber, Bleistifte oder ähnliche führen zu irreparablen Schäden. Sonneneinstrahlung bzw. übermässige Feuchte-, Wärme- und Kälteeinflüsse sollten möglichst vermieden werden.

D/4 EDITION: 21. September 1992

STUDER D740 INSTALLATION

1.3 Installation

Lieferumfang

Zum Lieferumfang des D740 gehört folgendes Zubehörset.

Position	Stk.	Teil.Nr.	Bezeichnung
1	1	89.20.5001	CD-R
2	1	10.95.3220	STUDER CD-Pen
3	2	54.02.0280	XLR-Stecker (male)
4	2	54.02.0281	XLR-Stecker (female)
5	2	51.01.0115	Sicherung: T630mA/250V
6	2	51.01.0112	Sicherung: T315mA/250V
7	2	51.01.0113	Sicherung: T600mA/250V
8	1	10.258.003.09	Inbusschraubendreher
9	1	10.258.003.46	Torxschraubendreher
10	1	10.27.1880	Bedienungsanleitung

Netzanschluss

Vor jeglicher Inbetriebnahme überprüfen Sie bitte den eingestellten Spannungswert. Dieser ist unter dem Netzeingang sichtbar. Um den Spannungswert zu ändern oder die Primärsicherungen auszutauschen, kann nach ziehen des Netzkabels die Klappe unten mit einem Schraubenzieher geöffnet werden. Der gewünschte Spannungswert wird so eingestellt: die kleine Trommel herausziehen und in der richtigen Position wieder einsetzen, der richtige Spannungswert muss anschliessend durch das Sichtfenster sichtbar sein. Die Sicherungen sind darüber angeordnet und können durch ziehen des jeweiligen Faches mit Pfeil ausgetauscht werden. Im Zuge der Vereinheitlichung der Normspannung auf 230V in Europa empfehlen wir, dann am Gerät die Umstellung von 220V auf 240V vorzunehmen.




Fig. 1.3 Netzanschluss mit Sicherungswerten

EDITION: 21. September 1992

INSTALLATION STUDER D740

Eingänge

■ Analog

Die Eingänge sind übertragersymmetriert und als XLR-Buchsen ausgeführt. Der maximale Eingangspegel ist ab Werk +15dBu, er ist geräteintern von +6 bis +24dBu einstellbar. Zusätzlich besteht die Möglichkeit, den Pegel in einem Bereich von -∞ bis Cal+10dB mit den Eingangsreglern INPUT LEVEL links[34] und rechts[33] getrennt an der Frontplatte zu verändern. Dazu muss der darunter angeordnete Schalter auf UNCAL[32] stehen. In der Stellung CAL werden diese Eingangsregler überbrückt.

■ Digital

Es stehen drei Eingänge zur Verfügung. Ein optischer und ein elektrischer SPDIF-Eingang (Cinchstecker) decken die Consumerformate ab. Der XLR-Eingang DI verarbeitet das AES/EBU- wie auch das SPDIF-Format.

Vorsicht:

Die digitalen Eingänge SPDIF und DI (AES/EBU) dürfen **nie** gleichzeitig belegt sein!

Es muss zwischen dem optischen und den beiden anderen Eingängen mittels des Schalters an der Geräterückseite gewählt werden. Im CD-Format ist nur die Sampling-Frequenz von 44,1 kHz möglich.

STUDER D740 INSTALLATION

Ausgänge

■ Analog

An den XLR-Chassisstecker liegt das übertragersymmetrierte Ausgangssignal mit einem Maximalpegel von +15dBu an. Der Ausgangspegel kann geräteintern zwischen +6dBu und +24dBu geregelt werden. Zusätzlich findet sich ein Cinchstereoausgang mit einem Pegel von 2 Vrms.

■ Digital

Auch für den digitalen Ausgang sind drei Möglichkeiten gegeben: optischer, Cinch- und XLR-Ausgang stehen zur Verfügung. Es liegt das SPDIF-Format an. Mit dem Schalter zwischen dem optischen und SPDIF Ausgang können die digitalen Ausgänge ein- bzw. ausgeschaltet werden.



1 = Schirm 2 = a - Ader3 = b - Ader



Fig. 1.4 Ein- und Ausgangsbelegung

Alle internen Einstellungen an diesem Produkt sind geschulten Fachleuten vorbehalten!

Da während Servicearbeiten gefährliche Laserstrahlung auftritt, müssen umfassende Sicherheitsvorkehrungen getroffen werden.

Hinweis


Netzunterbrechungen können in seltenen Fällen dazu führen, dass die Anzeige WAIT dauernd leuchtet. In dem Fall ist das Gerät auszuschalten und während dem nachfolgenden Einschalten gleichzeitig LOAD zu drücken.

EDITION: 21. September 1992 D/7

INSTALLATION STUDER D740

Parallele Schnittstelle

Der CD-Recorder kann durch die parallele Schnittstelle (25-Pol D-type Buchse) ferngesteuert werden.



PinBelegung
1
BR – Bulb remote

1.4 Technische Daten CD-R (STUDER)

CD-R

Durchmesser	. 120 mm
Plattendicke	. 1,2 mm
Spurabstand	. 1,6 μm
Reflexionsfaktor	
Aufnahmebereich	. Ø 44,7mm bis Ø 118mm
Trägermaterial	. Polykarbonat
Aufnahmeschicht	
Reflexionsschicht	. Gold
Aufnahmekapazität	. 63 Minuten
Verwendungszweck nach ATIP	. professionell
Auslesesicherheit mit STUDER A727, A730	. >1'000'000 Wiederholungen
Betriebstemperatur	
Luftfeuchtigkeit	. 5-95%RH
Lebensdauer	. >10 Jahre unter normalen
	Bedingungen (25°C, 65%RH)

Platte nie direkter Sonneneinwirkung aussetzen

1.5 Technische Daten D740

1.5.1 Beschreibung

Gerätetyp Compact-Disc-Recorder

Kompatibilität Red Book und Orange Book

Anzeigen

Tracktime: Titelspielzeit in Std./min./s

■ Remaining Tracktime: Titel-Restzeit

■ Total Rem. Time: Restzeit der CD(-R)

1.5.2 Elektrische Daten

Audiodaten: Frequenzgang ± 0,3dB 20Hz ...20kHz, Aufnahme

und Wiedergabe

Abtastrate 44,1kHz

A/D Wandler Delta-Sigma

64-fach Oversampling

D/A Wandler Bitstreamwandler

Klirrfaktor (THD + Noise) < 0,008% -1 dB, 20Hz...20kHz, Auf-

nahme und Wiedergabe

Kanaltrennung > 80dB 20Hz...20kHz, Aufnahme

und Wiedergabe

Kanalgleichlauf < 0,2dB 20Hz...20kHz, Aufnahme

und Wiedergabe

Phasengang < ±3° 20Hz...20kHz, Aufnahme

und Wiedergabe

Phasengang $< \pm 1^{\circ}$ 20Hz...20kHz, nur

Wiedergabe

Eingänge analog: INPUT left / right Übertrager symmetriert, erdfrei, XLR

 $\label{eq:continuous} \textbf{Eingangsimpedanz} \qquad \qquad > \textbf{10k}\Omega \qquad \qquad 20\text{Hz...20kHz, 0dBu}$

Max. Eingangsspannung +24dBu (symmetrisch)

Empfindlichkeit CAL: +6...+24dBu für Vollaussteuerung,

intern einstellbar

Werkseinstellung: $+15dBu \pm 0,1dBu$

Empfindlichkeit UNCAL: max. +10dB Verstärkung

EDITION: 21. September 1992

TECHNISCHE DATEN STUDER D740

Eingänge digital: AES/EBU Übertrager symmetriert, erdfrei, XLR

Impedanz 110 Ω

Erlaubte Abtastrate 44.1kHz ± 100 ppm

SPDIF coaxial asymmetrisch auf Cinch

Impedanz 75Ω SPDIF optisch Toslink

Ausgänge analog: OUTPUT left / right Übertrager symmetriert, erdfrei, XLR

Ausgangsimpedanz 40Ω 20Hz...15kHz, 0dBu

Ausgangspegel +6...+24dBu bei Vollaussteuerung

Werkseinstellung: $+15dBu \pm 0,1dBu$

Ausgangspegel maximal+24dBu600Ω Last

+22dBu 200Ω Last

Fixed OUTPUT left / right asymmetrisch auf Cinch-Buchsen

Ausgangspegel 2Vrms bei Vollaussteuerung

Ausgangsimpedanz $< 250\Omega$

Kopfhörer: Ausgangsspannung 0 ...6V (ohne Last)

Ausgangsimpedanz $< 150\Omega$

Ausgänge digital: AES/EBU Übertrager symmetriert auf XLR

Impedanz 110Ω

SPDIF coaxial mit Übertrager, asymmetrisch auf Cinch

Impedanz 75Ω SPDIF optisch Toslink

1.5.3 Peripherie-Anschluss

Parallele Fernsteuerung auf 25-poligem D-Stecker.

■ Faderstart-Logik

Laufwerksfunktionen und Rückmeldungen

1.5.4 Stromversorgung

Spannungswähler

Netzspannungen

100V, 120V, 220V, 240V ±10%

Netzfrequenz

50 ...60 Hz

Leistungsaufnahme

< 40 VA

Netzsicherung

100... 120V:

T 630mA (IEC)

100... 120V USA, CND

T 600mA (UL / CSA)

220... 240V:

T315mA (IEC)

Netzanschluss

3-polig mit Schutzerde

1.5.5 Betriebsbedingungen

Umgebungstemperatur

+15° ... +40°C

(Funktion)

+15° ... +35°C

(Spezifikation)

Rel. Luftfeuchtigkeit

Klasse F

(DIN 40040)

Betriebslage

horizontale Lage ±5 Grad

Netzunterbrüche

80 ms

1.5.6 Abmessungen

Masse:

Aussenabmessungen

483 \times 132,5 \times 351 mm (B \times H \times T)

mit Rackwinkeln

Einbauhöhe

132,5 mm

(3HE)

Einbaubreite

420 mm

ohne Rackwinkel

Gewicht:

10 kg

1.5.7 Sicherheit

Sicherheits-Standard

EN 60065 / IEC 65

EMV-Standard

EN 50081-1 / EN 50082-1

Laser

IEC 825 Klasse 3B

1.6 Blockdiagramm CD-Recorder D740




Fig.1.5 Blockdiagramm CD-Recorder D740

1.7 Masszeichnung CD-Recorder D740







Fig.1.6 Abmessungen vom CD-Recorder D740

EDITION: 22. September 1992 D/13

STUDER D740







D/14 EDITION: 20. September 1991

2 Bedienung

2.1 Bedienungselemente

Frontansicht		Bedienungselemente
[1]	POWER	Netzschalter; mit dem Schalter wird die Netzspannung ein- bzw. ausgeschaltet.
[2]	PHONES	Stereo-Klinkenbuchse zum Anschluss eines Kopfhörers (200 α -600 α).
[3]	VOLUME	Potentiometer zur Lautstärke-Einstellung des Kopfhörers.
[4]	CD-Schublade	Durch die Taste LOAD[5] wird die Schublade geöffnet. Die CD (auch CD-Single möglich) wird mit der Labelseite nach oben auf die geöffnete Schublade gelegt. Das Schliessen kann durch erneutes Drücken der Taste LOAD[5], leichtes einschieben der Schublade, direkter Titelanwahl mittels des Zahlenfeldes oder durch Drücken der Tasten PLAY[8] oder RECORD[9] erfolgen.
[5]	LOAD	LOAD öffnet oder schliesst die CD-Schublade.
[6]	PREVIOUS	Zurückspringen auf den vorangehenden Titel; die Anwahl funktioniert im Pausen- wie im Playmodus.
[7]	NEXT	Springen auf den nächstfolgenden Titel; ebenso im Pausen- wie im Playmodus möglich.
[8]	PLAY	Der Abspiel- bzw. Aufnahmevorgang wird ausgelöst. Die darüber liegende grüne LED leuchtet während des Abspielvorgangs. In Aufnahme leuchtet die rote LED über RECORD[9] kontinuierlich.
[9]	RECORD	Durch RECORD wird der Laser an das Ende der zuletzt aufgenommenen Stelle positioniert (bei unbespielter CD-R an den Anfang). Das Display informiert über die verbleibende Aufnahmezeit und die neue Titelnummer. Der CD-Recorder ist nun aufnahmebereit und zeigt dies durch die darüber angeordnete rot blinkende LED an. Mit dem Drücken der Taste PLAY[8] beginnt die Aufnahme.
[10]	REC MUTE	Die Funktion erlaubt die Erzeugung von Pausen mit digital Null. Dazu muss der Recorder im Record–Standby–Modus sein. Ein erstes Betätigen gibt eine Pausenlänge von 3 Sekunden. Mit jedem folgenden kurzen Drücken der Taste kann die Pausendauer um je eine Sekunde verlängert werden. Das Display zeigt jeweils die Länge in Sekunden an. Wird die Taste länger als eine Sekunde nicht betätigt, wird die Pause physikalisch geschrieben und der Recorder steht für die Aufnahme des nächsten Titels zur Verfügung.
[11]	PAUSE	Die Taste unterbricht den Abspiel- und Aufnahmevorgang. Die aktuelle Position wird beibehalten und im Display werden die entsprechenden Zeitinformationen angezeigt. War das Gerät vorher in Aufnahme, geht es in den Record-Standby-Modus. Die Pausenfunktion wird durch PLAY[8] gelöscht.

STUDER D740 BEDIENUNG

[12]	STOP/CM	Der Abspiel- bzw. Aufnahmevorgang wird beendet. Ein weiteres Auslösen löscht den Programmspeicher (CM; Clear memory).	
[13]	•	Mit dem Suchlauf-Vorwärts kann jede Stelle der CD zum Ende hin angefahren werden. Kontinuierlicher Vorlauf ist durch Gedrückt halten möglich. Der Suchlauf funktioniert im Pausen- und Play-Modus.	
[14]	FAST	Es sind zwei Suchlaufgeschwindigkeiten vorhanden. Mit FAST kann zwischen den beiden Geschwindigkeiten hin und her gewechselt werden. Im Display leuchtet FAST im Falle der höheren Suchlaufgeschwindigkeit.	
[15]	•	Die Suchlauf-Rückwärtstaste erlaubt das Anfahren jeder Stelle der CD zum Anfang hin. Kontinuierlicher Rücklauf ist durch gedrückt halten der Taste möglich. Der Suchlauf funktioniert im Pausen- und Play-Modus.	
[16]	SCAN	Durch SCAN werden von jedem Titel die ersten 10 Sekunden angespielt. Mit einem erneuten Drücken wird die CD sogleich normal abgespielt.	
[17]	REVIEW END	Im Pausen-Modus werden die letzten 8 Sekunden des aktuellen Titels abgespielt, danach fährt die Abtasteinheit in die Ausgangsposition zurück.	
[18]	START REVIEW	Solange diese Taste gedrückt wird, spielt das Gerät ab der aktuellen Position. Beim Loslassen fährt die Abtasteinheit in die Ausgangsposition zurück.	
[19]	DISPLAY	 Ermöglicht das Umschalten zwischen drei verschiedenen Zeitangaben. verstrichene Zeit des aktuellen Titels restliche Zeit bis zum Titelende (nur beim Abspielen möglich) restliche Zeit bis CD-Ende, respektive während der Aufnahme, die noch vorhandene Aufnahmekapazität. 	
[20]	PEAK RESET	Zurücksetzen der Peak-Anzeige.	
[21]	Zehner Tastatur	 Direktanwahl eines Titels mittels Eingabe der Titelnummer Eingabe der Titelnummern bei der Programmierung 	
[22]	PROGRAM/PLAY	Wechselschalter zwischen Abspielvorgang mit direktem Titelzugriff und direktem Programmieren.	
[23]	REVIEW	Die Programmreihenfolge wird angezeigt. Bei einmaligem Drücken wird jeder programmierte Titel je eine Sekunde lang angezeigt. Die Programmreihenfolge lässt sich schneller prüfen, indem mit jedem weiteren Auslösen von REVIEW der nächst programmierte Titel in der Anzeige folgt.	
[24]	CLEAR	 Weglassendes Programmieren; die nicht gewünschte Titelnummer im Zahlenfeld eingeben und mit CLEAR bestätigen. Die Ziffernmatrix im Anzeigefeld zeigt die verbleibenden Titelnummern. Im SCAN-Modus ist ein (in der von der CD vorgebenen Reihenfolge) weglassendes Programmieren möglich. Die auszulassenden Titel durch Drücken. 	

EDITION: 21. September 1992

Ziffernmatrix.

sendes Programmieren möglich. Die auszulassenden Titel durch Drücken von CLEAR kennzeichnen; die gelöschten Titelnummern verschwinden in der

[25]	STORE	 Aufbauendes Programmieren; die gewünschte Titelnummer im Zahlenfeld eingeben und mit STORE bestätigen. Die Ziffernmatrix im Anzeigefeld zeigt die gewählten Titelnummern. Im SCAN-Modus ist ein (in der von der CD vorgebenen Reihenfolge) aufbauendes Programmieren möglich. Die gewünschten Titel durch Drücken von STORE kennzeichnen; die gewählten Titelnummern erscheinen in der Ziffernmatrix. 	
[26]	INPUT SELECT	Wahl zwischen dem digitalen und analogen Eingang mit Rückmeldung durch LED.	
[27]	NEW TRACK	Zum Erzeugen von neuen Titel sind zwei Möglichkeiten verfügbar. Über den eingestellten Zustand informiert je eine LED.	
		 AUTO Bei einer analogen Aufnahme wird ein neuer Track gesetzt, wenn der Audiopegel nach mindestens 3 Sekunden –60dB wieder überschreitet. Nach dem gleichen Prinzip wird auch bei einer digitalen Überspielung ein neuer Track gesetzt, ausser der Zuspieler sei ein CD-Player. 	
		 In Verbindung mit den STUDER CD-Playern (auch Recorder) übernimmt der Recorder bei digitaler Überspielung automatisch die Trackwechsel des Zuspielgeräts. 	
		 MANUAL – In diesem Status wird ein neuer Titel bei jedem Drücken von NEXT [7] generiert. 	
[28]	SKIP	Auslösen der SKIP-Funktion. Damit werden unerwünschte Stellen nach definieren von Springpunkten beim Abspielen ausgelassen. In aktivierter Stellung leuchtet SKIP im Display. Entweder über die Titelanwahl oder den Suchlauf die entsprechende Stelle bestimmen.	
[29]	UNSKIP	Auslösen der UNSKIP-Funktion. Vorher definierte Springpunkte werden gelöscht. In aktivierter Stellung leuchtet UNSKIP im Anzeigefeld. Entweder über die Titelanwahl oder den Suchlauf die entsprechende Stelle bestimmen.	
[30]	A - B	Festlegen von Anfangs- und Endpunkt einer zu wiederholenden Passage.	
[31]	FIX-UP	Nachdem eine CD-R endgültig fertig beschrieben ist, wird durch das Auslösen von FIX-UP die Table of Contents aufgezeichnet. Die CD-R entspricht danach der Red-Book-Norm. Sie ist auf jedem CD-Spieler wie eine herkömmliche CD abspielbar. Sie kann allerdings nicht weiter bespielt werden.	
[32]	UNCAL	Umschalten zwischen fest eingestelltem und mit den beiden Eingangsreglern [32] und [33] einstellbarem analogem Eingang. Rückmeldung durch LED.	
[33]	RIGHT	Eingangsregler für den rechten Kanal, aktiv bei UNCAL.	
[34]	LEFT	Eingangsregler für den linken Kanal, aktiv bei UNCAL.	

STUDER D740 BEDIENUNG

Anzeigefeld

[40]	Zahlenmatrix	Die noch abzuspielenden Titelnummern werden angezeigt, sofern die Titelanzahl 20 nicht übersteigt. Schon abgespielte oder wegprogrammierte Titelnummern verschwinden von der Anzeige.	
[41]	(((•	Leuchtet sobald Fernbedienung aktiviert ist.	
[42]	PLAY DIRECT	Abspielmodus, direkte Titelanwahl über das Zahlenfeld[21] möglich.	
[43]	DIRECT PROGR.	Programmiermodus ist eingestellt.	
[44]	PROGRAM	Programm läuft ab.	
[45]	FIX-UP	Leuchtet während der Aufzeichnung der Table of Contents zum Abschliessen einer CD-R.	
[46]	A - B	Anfangs- und Endpunkt der Loop-Funktion bzw. des zu überspringenden Teils(SKIP).	
[47]	REPEAT	Wiederholen der Loop-Funktion.	
[48]	CD	Eine nicht (mehr) beschreibare CD ist eingelegt.	
[49]	CD RECORDABLE	Die eingelegte CD ist beschreibbar.	
[50]	REC SYNC	Falls ein digitales Zuspielgerät angeschlossen ist, bestätigt diese Anzeige die korrekte externe Word Clock Synchronisation. Das Gerät schaltet auf externe Synchronisation um, wenn während des Einschaltvorgangs die externe Quelle angeschlossen und aktiv ist. Dies gilt für den Aufnahme- wie für den Wiedergabebetrieb. Ansonsten synchronisiert das Gerät auf die interne Word-Clock-Quelle.	
[51]	Pegelanzeige	Zeigt den Pegel an, der nach DA-Stufe gemessen wird.	
[52] [53]	TOTAL REM TRACK TIME TRACK	Zeitangabe; je nach Einstellung verflossene Titel-, Titelrest- oder Restspielzeit bzw. die verfügbare Restkapazität bei einer beschreibaren CD-R. Zeigt aktuelle Titelnummer an.	

EDITION: 21. September 1992 D/17

BEDIENUNG STUDER D740

[54]	Funktionsanzeigen	Bedeutung	
	READING		
	OPEN	CD-Schublade wird geöffnet.	
	CLOSE SCAN	CD-Schublade wird geschlossen.	
	SCAN	SCAN-Funktion ist aktiviert, je Titel werden die ersten zehn Sekunden angespielt.	
	ERROR	Bedienungsfehler oder Defekt	
	NO DISC	Es wurde ein Abspiel- bzw. Aufnahmevorgang versucht, obwohl keine CD bzw. CD-R geladen ist.	
	NO CDR	Es wurde ein Aufnahmevorgang versucht, obwohl nur eine CD bzw. keine CD-R geladen ist.	
	RECORD	Der Recorder ist in Aufnahmebereitschaft, bzw. bei SKIP/UNSKIP wird der soeben eingegebene Punkt übernommen.	
	OPC	Nach einlegen einer CD-R wird selbsttätig die Schreibeinheit optimal eingestellt.	
	NO LOCK	Digitalgerät ist angeschlossen, jedoch kann nicht auf den externen Word Clock	
	synchronisiert werden. Gerät aus- und wieder einschalten.		
	NO SYNC	Kein digitaler Eingang mehr angeschlossen. Gerät aus- und wieder einschalten.	
	SKIP ON	Bei ausgelöster UNSKIP-Funktion wird der vorher übersprungene Teil	
		angezeigt.	
	SKIP	SKIP-Funktion ist ausgelöst.	
	SK	Skip wird während dem Abspielen ausgeführt.	
	UNSKIP	UNSKIP-Funktion ist ausgelöst.	
	USK	Unskip wird ausgeführt.	
	VERIFY	Probelauf einer programmierten SKIP/UNSKIP-Funktion.	
	WAIT	Update der PMA mit dem Inhalt aus dem EEPROM nach einer Stromunterbrechung	
	FULL	99 Titel oder die CD-R ist vollständig beschrieben	

D/18 EDITION: 21. September 1992

STUDER D740 **BEDIENUNG**

Anschlussfeld

Suchlauf ◀ ▶

[60]	FIXED OUTPUT	Cinch-Ausgang	
[61]	DIGITAL OUTPUT	Optischer und SPDIF-Cinch-Digitalausgang, durch den Schalter sind die Digitalausgänge ein-bzw. ausschaltbar.	
[62]	INPUT LEFT	Analoger Leitungseingang linker Kanal, übertragersymmetriert (XLR), werksseitig eingestellt +15dBu(1kHz, digital 0dB).	
[63]	INPUT RIGHT	Analoger Leitungseingang rechter Kanal, übertragersymmetriert (XLR), werksseitig eingestellt +15dBu(1kHz, digital 0dB).	
[64]	OUTPUT LEFT	Analoger Leitungsausgang linker Kanal, übertragersymmetriert (XLR), werksseitig eingestellt +15dBu(1kHz, digital 0dB).	
[65]	OUTPUT RIGHT	Analoger Leitungsausgang rechter Kanal, übertragersymmetriert (XLR), werksseitig eingestellt +15dBu(1kHz, digital 0dB).	
[66]	DI	Digitaler AES/EBU-Eingang	
[67]	DO	Digitaler Ausgang, SPDIF-Format	
[68]	PARALLEL REMOTE	Parallele Schnittstelle	
[69]	AC POWER	Netzstecker für Eurobuchse	
[70]	DIGITAL INPUT	Digitaler Cinch-Eingang	
		Vorsicht: Am digitalen Eingang dürfen nie der SPDIF- und der DI(AES/EBU)-Eingang gleichzeitig belegt sein!	
[71]	Wechselschalter	Umschalten zwischen optischem und Cinch/XLR Digitaleingang.	
[72]	OPTICAL	Optischer Digitaleingang	
2.2	Wiedergabe		
		Ausser dem Abspielen einer CD mit der PLAY-Taste[8] von Programmanfang bis -ende sind zahlreiche Varianten gegeben.	
Zeitangaben		Mit jedem Drücken von DISPLAY[19] sind drei verschiedenen Zeitangaben	

abrufbar, Restzeit zum CD-Ende, verflossene Zeit seit Titelbeginn und Restlaufzeit des aktuellen Titels.

Der Suchlauf ermöglicht beliebige Stellen zum Anfang und Ende der CD hin

anzufahren; es sind zwei Suchlaufgeschwindigkeiten über FAST[14] wählbar. Während dem Abspielen ist die Modulation bruchstückhaft zu hören. Im Pausen-Status ist der Suchlauf ebenso möglich und die dazugehörige Zeitangabe in der Anzeige sichtbar. Sind SKIP-Bereiche definiert, ist der Suchlauf nur innerhalb des Tracks möglich.

D/19 EDITION: 21. September 1992

WIEDERGABE STUDER D740

Titel anwählen

Die Anwahl der Titel erfolgt in verschiedener Weise. Mittels der Zehnertastatur[21] ist jeweils der gewünschte Titel direkt zu hören, sofern nicht der Programmiermodus gewählt ist (Anzeige durch **DIRECT PROGRAM** ansonsten **PLAY DIRECT**). Sollte der nächstfolgende oder der davorliegende Titel (respektive der jeweilige Titelanfang) abgespielt werden, stehen die Tasten NEXT[7] und PREVIOUS[6] zur Verfügung.

Programmieren

DIRECT PLAY
TiteInummer?
STORE / CLEAR
TiteInummer?
STORE / CLEAR
TiteInummer?
STORE / CLEAR
etc.
REVIEW
PLAY
(NEXT / PREVIOUS)
2x STOP/CM

PROGRAM/PLAY

TiteInummer ?
etc.
REVIEW
PLAY
(NEXT / PREVIOUS)
2x STOP/CM

Titel anspielen und programmieren

START REVIEW REVIEW END

Eine willkürliche Folge von Titeln ist zu programmieren. Zwei Möglichkeiten stehen zur Wahl.

- Im Direct-Play-Modus die gewünschte Abfolge der Titel numerisch eingeben und je mit STORE[25] bestätigen.
- Mit PROGRAM/PLAY den Status Direct Program aufrufen. Die Titel numerisch eingeben. Wird jeweils innerhalb von zwei Sekunden weder die Taste STORE[25] noch CLEAR[24] betätigt, wird der betreffende Titel selbsttätig in das Programm aufgenommen, ansonsten entsprechend aufgenommen bzw. gelöscht.

Die Zahlenmatrix im Display informiert über die Titelauswahl. Links neben der Zeitangabe wird die Positionsnummer angezeigt. Der Programmablauf kann mit REVIEW[23] überprüft werden. Bei einmaligem Drücken werden die Titelnummern 1 Sekunde lang angezeigt, ansonsten schrittweise mit jedem Drücken. Wenn anstelle von STORE[25] die Taste CLEAR[24] beim Programmieren benutzt wird, ist der betreffende Titel im Programmablauf gelöscht. Mit PLAY[8] startet das Programm. NEXT[7] und PREVIOUS[6] beziehen sich jetzt auf die Programmreihenfolge. Um ein Programm gesamthaft zu löschen, die STOP/CM-Taste[12] zweimal betätigen. In der Anzeige erscheint CLR PRG.

10 Sekunden von jedem Titelanfang werden über die Funktion SCAN[16] angespielt. Mit STORE[25] respektive CLEAR[24] lässt sich ein in der Reihenfolge der CD aufbauendes oder weglassendes Programm erstellen. Durch erneutes Auslösen von SCAN[16] wird die Funktion SCAN gelöscht.

Die beiden Funktionen REVIEW (-START; Anfang, -END; Ende) ermöglichen kurz das Probehören von einem Titelanfang oder einem -ende, ohne die Ausgangsposition des Abtast-Lasers zu verlieren. Bei REVIEW START[18] wird bis zum Loslassen der Taste abgespielt, bei REVIEW END[17] sind die letzten 8 Sekunden zu hören. Anschliessend fährt der Abtast-Laser in die Ausgangsposition zurück.

D/20 EDITION: 21. September 1992

STUDER D740 WIEDERGABE

A→B

Wiederholen einer Sequenz; Während des Abspielvorgangs A→B[30] drücken, der Anfangspunkt A der Sequenz ist bestimmt. Der Endpunkt B ergibt sich durch erneutes Drücken von A→B[30]. Um den Endpunkt schneller zu erreichen, kann er auch mit Vorlauf ►[13] angefahren werden. Die einprogrammierte Sequenz wird von A nach B als Schlaufe(Loop) wiederholt. Mit einem weiteren Auslösen von A-B[30] geht der CD-Recorder in die normale CD-Wiedergabe über.

Eine genauere Programmierung einer Sequenz als Schlaufe(Loop) ist im Pausenmodus möglich. Durch SEARCH REVERSE[15] bzw. FORWARD[13] den genauen Anfangspunkt A bestimmen. Erstmaliges Auslösen von A→B[30], blinkt A→ im Anzeigefeld. Jetzt mit SEARCH REVERSE[15] bzw. FORWARD[13] den Endpunkt B genau definieren. Durch ein zweites Auslösen von A→B[30] blinkt A→B im Anzeigefeld. Die einprogrammierte Sequenz wird von A nach B als Schlaufe(Loop) wiederholt, nachdem der Pausen-Modus mittels PLAY[8] beendet wurde. Mit einem weiteren Auslösen von A-B[30] geht der CD-Recorder in die normale CD-Wiedergabe über.

Single track jump

PAUSE → ► PAUSE In dieser Betriebsart lassen sich die Startzeitpunkte genau bestimmen. In dem Modus spielt das Gerät zu einem Cue-Punkt hin und anschliessend springt der Abtast-Laser um eine Spur zurück und spielt erneut bis zum Cue-Punkt. Das Einschalten erfolgt im Pausen-Status(PAUSE[11]) durch betätigen von SEARCH REVERSE[15] bzw. FORWARD[13]. Der Cue-Punkt verschiebt sich bei drücken von SEARCH REVERSE (FORWARD) entsprechend in Richtung von CD-Anfang oder -Ende. Mit PAUSE[11] schaltet der Single-track-jump Modus aus.

Fader-Start

An die parallele Schnittstelle (Kontakte 11 und 12) kann eine Fader-Start-Automatik angeschlossen werden. Der aktivierte Fader-Start löst aus jeder Position die Wiedergabe aus.




Fig. 2.1 Fader-Start Anschluss

Externe Synchronisation

Ist am digitalen Eingang ein Word-Clock Signal(AES/EBU oder SPDIF-Signal) während des Einschaltvorgangs angeschlossen (Beispielsweise Studioclock oder durch einen angeschlossenen CD-Player) synchronisiert der CD-Recorder bei Aufnahme und Wiedergabe auf die externe Word-Clock.

EDITION: 21. September 1992

AUFNAHME STUDER D740

2.3 Aufnahmefunktionen

Einleitend einige allgemeine Erklärungen zum Subcode der handelsüblichen CD. Die Struktur des Subcodes ist in sich abgeschlossen. Das Inhaltsverzeichnis (Lead-In) enthält die Startpunkte der Titel und das absolute Ende der Modulation. Am Ende der Modulation befindet sich das Lead-out. Diese für die CD verbindliche Anordnung des Subcodes lässt bei der CD-R kein sukzessives Bespielen zu. Deshalb wird bei der CD-R vorerst ein offenes Inhaltsverzeichnis(PMA) angelegt und erst nach Abschluss aller Aufnahmen das Lead-In und Lead-Out (durch FIX-UP) geschrieben. Der PCA-Bereich dient der optimalen Einstellung des Schreiblasers.




Fig. 2.2 Lead-In, Lead-Out einer konventionellen CD




Fig. 2.3 Lead-In, Lead-Out, PMA einer noch weiter bespielbaren CD-R




Fig. 2.4 Lead-In, Lead-Out einer abgeschlossenen (Fix-Up) CD-R

D/22

STUDER D740 AUFNAHME

2.3.1 Program Memory Area (PMA)

Die PMA wird vor dem Lead-In auf die CD-R geschrieben. Dieser Bereich ist ein Zwischenspeicher für unvollständig beschriebene CD-R. Er enthält zwei verschiedene Informationen:

- Inhaltsverzeichnis vom bespielten Teil der CD-R
- Skip/Unskip Befehle

Kapazität der PMA

■ Track max. 99

SKIP-TRACK max. 21 (bei 6-10 Tracks)

SKIP-SECTIONS max. 21

Bei unvorhergesehenem Stromausfall während einer Aufnahme bleiben die Daten im EEPROM erhalten und bei erneuter Stromzufuhr in die PMA geschrieben. Das Gerät zeigt dies mittels WAIT an. Danach kann die Aufnahme fortgesetzt werden, es wird ein neuer Track gesetzt.

Bevor die CD-R dem CD-Recorder entnommen wird, schreibt(respektive aktualisiert) dieser automatisch die PMA physikalisch auf den vor dem Lead-In vorgesehenen Spuren. Zuvor werden die Daten in einem RAM des CD-Recorders gespeichert. Erst wenn die CD-R vollständig bespielt ist, wird durch auslösen von FIX-UP das Lead-In und Lead-Out geschrieben. Danach ist die CD-R nicht weiter beschreibbar, dafür ist die Wiedergabe auf allen CD-Spielern möglich.

2.3.2 Analoge Aufnahmen

Anschluss

An den XLR-Eingängen die Quelle anschliessen. Den Eingangswahlschalter INPUT SELECT[26] auf ANALOG stellen. Soll die Eingangsempfindlichkeit manuell verstellbar sein, den Schalter unterhalb der Eingangsregler auf UNCAL[32] schalten und kanalweise mit den Reglern den Pegel einstellen.

Aufnahmebereitschaft

Das Gerät geht in Aufnahmebereitschaft, indem eine noch zu bespielende CD-R eingelegt und die RECORD-Taste[9] gedrückt wird. Die rot blinkende LED zeigt die Aufnahmebereitschaft an.

Aussteuerung

In Aufnahmebereitschaft liegt am Ausgang des Recorders das Eingangssignal nach der AD/DA-Wandlung an. Die Peakmetereinheit misst den Pegel auch an dieser Stelle. So kann direkt akustisch wie messtechnisch das auf die CD-R gehende Signal verfolgt werden. Übersteuerungen äussern sich akustisch durch hörbares Knacken. Für eine optimale Aussteuerung sollte (dabei PEAK RESET[20] wiederholt drücken) bei Maximalpegel an der Peakanzeige die rechte LED je Kanal kurz leuchten.

Externe Synchronisation

lst während des Einschaltvorgangs am digitalen Eingang ein Word-Clock Signal(AES/EBU oder SPDIF-Signal) angeschlossen (Beispielsweise Studioclock oder durch einen angeschlossenen angeschalteten CD-Player) synchronisiert der CD-Recorder bei Aufnahme und Wiedergabe auf den externen Clock. Die Verbindung darf während einer Aufnahme niemals unterbrochen werden.

Aufnahmestart

Das Gerät befindet sich in Aufnahmebereitschaft. Die Aufnahme wird durch Drücken von PLAY gestartet. Ein dauerndes Leuchten der roten LED bestätigt, dass die CD-R physikalisch beschrieben wird. Der Beginn der Aufnahme kann bis 600ms verzögert sein. Mit DISPLAY[19] ist während der Aufnahme die Restkapazität der CD-R abrufbar.

EDITION: 21. September 1992 D/23

AUFNAHME STUDER D740

Titelgenerierung

Die Titelgenerierung kann automatisch oder manuell erfolgen. Der Wechselschalter NEW TRACK[27] ermöglicht die Wahl zwischen AUTO oder MANUAL. Im Modus AUTO wird ein neuer Titel generiert, wenn der Audiopegel länger als drei Sekunden –60dB nicht überschreitet. Im Modus MANUAL wie AUTO wird mit jedem Drücken von NEXT[7] ein neuer Titel erzeugt. Während der Aufnahme kann der Modus gewechselt werden.

Aufnahme unterbrechen

Mit PAUSE[11] oder STOP/CM[12] unterbrechen Sie den Aufnahmevorgang.

Pausen

Vor dem Aufnehmen eines neuen Titels empfiehlt es sich, zur Erzeugung der Titelendmarke 00 eine Pause mit digital Null zu schreiben. Dies geschieht mit der Taste REC MUTE[10]. Die Pause beträgt mindestens drei Sekunden und kann mit wiederholtem Drücken je um eine Sekunde erweitert werden. Wird die Taste länger als eine Sekunde nicht betätigt, startet der Recorder selbsttätig, zeichnet die Pause physikalisch auf und geht in Aufnahmebereitschaft.

Aufnahme fortsetzen

Falls keine Pause erwünscht ist und ein weiterer Titel aufgespielt werden soll, das Gerät durch RECORD[9] in Aufnahmebereitschaft stellen. In beiden Fällen (mit oder ohne Pause) entsteht automatisch ein neuer Titel. Anschliessend den Aufnahmevorgang mit PLAY[8] starten.

Aufnahme beenden- CD-R weiterhin aufnahmebereit

Für den Fall, dass die CD-R weiter beschrieben werden soll, die CD-R mit LOAD[5] dem CD-Recorder entnehmen. Es erscheint die Anzeige **UPDATE**, die bestätigt, dass die PMA(→2.3.1) aufgezeichnet bzw. aktualisiert wird. Danach gibt das Gerät die CD frei.

Aufnahme beenden- CD-R abschliessen

Ist die CD-R mit dem gewünschten Programm bespielt, wird sie durch das Aufzeichnen der TOC(→2.3) abgeschlossen. Dies geschieht indem FIX-UP[31] und anschliessend innerhalb von zwei Sekunden RECORD[9] gedrückt wird. In der Anzeige erscheint FIX-UP. Der Vorgang dauert etwa drei Minuten. Das Display informiert aktuell über die Dauer des Vorgangs.

2.3.3 Digitale Aufnahmen

Digitalanschluss

Bedingt durch das CD-Format können nur Aufnahmen mit einer Abtastfrequenz von 44,1 kHz direkt überspielt werden. Für andere Abtastraten muss ein Abtastratenwandler zwischengeschaltet werden. Den digitalen Ausgang des Zuspielgerätes mit dem digitalen Eingang des Recorders verbinden. An der Rückseite des Gerätes den Wahlschalter(optischer oder CINCH/XLR-Eingang) in die entsprechende Stellung bringen.

Vorsicht:

Am digitalen Eingang dürfen nie der SPDIF- und der DI(AES/EBU)-Eingang gleichzeitig belegt sein!

Mit dem Wechselschalter INPUT SELECT[26], DIGITAL anwählen. Falls sich der Recorder nicht auf DIGITAL umschalten lässt, fehlt der Word Clock. Gewisse digitale Zuspielgeräte haben erst nach dem Abspielen einer kurzen Passage einen definierten Betriebszustand. Danach dürfte sich der Recorder in den digitalen Aufnahmemodus schalten lassen.

Aufnahmebereitschaft

Eine noch zu bespielende CD-R einlegen. Durch RECORD[9] den Recorder in Aufnahmebereitschaft bringen; rote LED blinkt über RECORD. Der Beginn der Aufnahme kann bis 600ms verzögert sein. Mit DISPLAY[19] ist während der Aufnahme die Restkapazität der CD-R abrufbar.

D/24 EDITION: 21. September 1992

STUDER D740 AUFNAHME

Aufnahmestart

Das Gerät befindet sich in Aufnahmebereitschaft. Mit PLAY[8] beginnt die Aufnahme; jedoch das Zuspielgerät erst starten, wenn die rote LED über RECORD dauernd brennt. Erst in dem Moment wird die CD-R physikalisch beschrieben.

Titelgenerierung

Der Wechselschalter NEW TRACK[27] gibt die Wahl der Titelgenerierung zwischen AUTO und MANUAL. Wird in Position AUTO ein STUDER CD-Player als Zuspielgerät benutzt, übernimmt der Recorder die Titelwechsel automatisch von der abspielenden CD. In Stellung MANUAL wie AUTO kann mit NEXT[7] zu jedem gewünschten Zeitpunkt ein neuer Titel gesetzt werden. Während der Überspielung kann der Modus gewechselt werden.

Aufnahme unterbrechen

Mit PAUSE[11] oder STOP/CM[12] unterbrechen Sie den Aufnahmevorgang.

Pausen

Vor dem Aufnehmen eines neuen Titels empfiehlt es sich, zur Erzeugung der Titelendmarke 00 eine Pause mit digital Null zu schreiben. Dies geschieht mit der Taste REC MUTE[10]. Die Pause beträgt mindestens drei Sekunden und kann mit wiederholtem Drücken je um eine Sekunde erweitert werden. Wird die Taste länger als eine Sekunde nicht betätigt, startet der Recorder selbsttätig, zeichnet die Pause physikalisch auf und geht in Aufnahmebereitschaft.

Aufnahme fortsetzen

Falls keine Pause erwünscht ist und ein weiterer Titel aufgespielt werden soll, in Aufnahmebereitschaft stellen durch RECORD[9]. In beiden Fällen (mit oder ohne Pause) entsteht automatisch ein neuer Titel. Anschliessend den Aufnahmevorgang mit PLAY[8] starten.

Aufnahme beenden- CD-R weiterhin aufnahmebereit

Für den Fall, dass die CD-R weiter beschrieben werden soll, die CD-R mit LOAD[5] dem CD-Recorder entnehmen. Es erscheint die Anzeige **UPDATE**, die bestätigt, dass die PMA(→2.3.2) aufgezeichnet bzw. aktualisiert wird. Danach gibt das Gerät die CD frei.

Aufnahme beenden- CD-R abschliessen

Ist die CD-R mit dem gewünschten Programm bespielt, wird sie durch das Aufzeichnen der TOC(→2.3) abgeschlossen. Dies geschieht indem FIX-UP[31] und anschliessend innerhalb von zwei Sekunden RECORD[9] gedrückt wird. In der Anzeige erscheint FIX-UP. Der Vorgang dauert etwa drei Minuten. Das Display informiert aktuell über die Dauer des Vorgangs.

2.3.4 SKIP / UNSKIP

Die CD-R ist einmal beschreibbar. Falls aus irgend welchen Gründen Passagen oder ganze Titel fälschlicherweise aufgenommen wurden, können diese durch die SKIP-Programmierung übersprungen werden. Mit UNSKIP werden die entsprechenden SKIP-Punkte gelöscht. Für die SKIP und UNSKIP Programmierung gibt es zwei Möglichkeiten.

1. Titelweise überspringen

Taste STOP/CM	Anzeige
TNO?	##
SKIP	TNO SKIP
RECORD	UPDATE

Im STOP-Modus die auszulassende Titelnummer mittels der Zehnertastatur[21] eingeben. SKIP[28]-Befehl auslösen. Falls der falsche Titel eingegeben wurde, über STOP/CM[12] mit der richtigen Titelnummer den Bedienvorgang wiederholen. Durch RECORD[9] wird die soeben eingegebene SKIP-Funktion gespeichert. Die Skip-Daten werden vorerst im RAM abgelegt. Beim Entnehmen der CD-R wird die PMA aktualisiert.

EDITION: 21. September 1992 D/25

2. Passagen überspringen

Taste PLAY	Anzeige
AAB	AA
AAB	AAB
Hören von	Loop AAB
SKIP	SKIP
J.C.	VERIFY
İ	SK
Hören bis	A – Sprung zu B
RECORD	SKIP
	RECORD
l	

Play-Modus

Erstmaliges Auslösen von A→B[30] bestimmt den Anfangspunkt A des auszulassenden Teils, ein zweites Auslösen den Endpunkt B. Jetzt ist der auszulassende Teil von Anfangspunkt A bis Endpunkt B wiederholt(Loop) hörbar. Durch Drücken von SKIP[28] diese Betriebsart wählen. Anstelle der Zeitanzeige erfolgt der Schriftzug SKIP im Anzeigefeld. Anschliessend wird automatisch SKIP-VERIFY aktiviert, Bestätigung im Anzeigefeld durch VERIFY. Dabei spielt das Gerät 3 Sekunden vor dem Punkt A bis A, führt die programmierte Skip-Funktion aus und spielt noch 3 Sekunden nach B ab. In der Anzeige erscheint SK. Falls das Ergebnis nicht befriedigt, nach einem STOP/CM[12]-Befehl Programmierung wiederholen. Ansonsten wird mittels RECORD[9] die eben eingegebene SKIP-Funktion gespeichert.

Taste PAUSE	Anzeige
∢ ► AAB	AA
AAB	AAB
PLAY Hören von Loop AAB	
SKIP	SKIP VERIFY SK
Hören bis A RECORD	Sprung zu B SKIP RECORD

Pausen-Modus

Durch SEARCH REVERSE[15] bzw. FORWARD[13] den genauen Anfangspunkt A bestimmen. Erstmaliges Auslösen von A→B[30], blinkt A→ im Anzeigefeld. Jetzt mit SEARCH REVERSE[15] bzw. FORWARD[13] den Endpunkt B genau definieren. Durch ein zweites Auslösen von A→B[30] blinkt A→B im Anzeigefeld. Der auszulassende Teil von Anfangspunkt A bis Endpunkt B ist wiederholt(Loop) nach auslösen von PLAY[8] hörbar. Durch drücken von SKIP[28] diese Betriebsart wählen. Anschliessend wird automatisch SKIP-VERIFY aktiviert, Bestätigung im Anzeigefeld durch VERIFY. Dabei spielt das Gerät 3 Sekunden vor dem Punkt A bis A, führt die programmierte Skip-Funktion aus und spielt noch 3 Sekunden nach B ab. Falls das Ergebnis nicht befriedigt, kann wieder erst der Punkt A und anschliessend der Punkt B entsprechend der vorigen Anleitung verändert werden. Durch RECORD[9] wird die eingegebene SKIP-Funktion gespeichert. (siehe Fig. 2.4)

Taste Anzeige ΡΙ ΔΥ AAB AA AAB AAB UNSKIP UNSKIP **VERIFY** USK Hören von Loop AAB SKIP ON USK RECORD UNSKIP RECORD Unskip

Die UNSKIP-Funktion dient zum Löschen von einprogrammierten SKIP-Funktionen. Die Programmierung erfolgt analog der SKIP-Funktionen, anstelle von SKIP ist jeweils UNSKIP[30] zu setzen. Die Anfangs- und Endpunkte müssen nicht so genau bestimmt werden, der Anfangspunkt muss eindeutig vor der zu löschenden Skipmarke sein und der Endpunkt eindeutig nach der zu löschenden Skipendmarke.

Die Skip/Unskip-Funktion ist nur auf einem CD-Recorder aktiv (oder CD-Spieler, die SKIP- und UNSKIP-Befehle lesen können) und kann von einem herkömmlichen CD-Spieler nicht ausgeführt werden.

D/26

AUFNAHME




Fig.2.5 Skip-Funktion im Pausen-Modus

EDITION: 22. September 1992

FERNBEDIENUNG STUDER D740

2.4 Parallele Fernbedienung

1.328.660

Diese Fernbedienung ist für die STUDER CD-Recorder D740 und R-DAT Recorder D780 einsetzbar.

Die Bedienung entspricht derjenigen am Gerät. Die nachfolgende Beschreibung gilt für die Werkseinstellung. Andere Funktionsmöglichkeiten entnehmen Sie dem Beiblatt zur Fernbedienung oder der Serviceanleitung. Weil die Funktion STOP auf der Fernbedienung fehlt, ist folgendes zu beachten:

RECORD gleiche Funktion wie die Record-Taste am Gerät.

Übergang von Play in

Record

- RECORD auslösen - Gerät stoppt

- RECORD ein zweites Mal

auslösen - Aufnahmebereitschaft

Play startet die Aufnahme

Übergang von Record in

Play

REVIEW auslösen – Gerät stopptPLAY auslösen – Wiedergabe

PAUSE Pause-Befehl

PLAY Wiedergabe-Befehl

REC MUTE Zeichnet aus dem Zustand Record bzw. Record Pause

eine kurze Stelle mit digital Null auf.

NEW TRACK Setzt in Aufnahme einen neuen Track

REVIEW Dient zur Kontrolle des Startpunktes; im

Aufnahmebetrieb wird die Aufnahme gestoppt

FADER Schaltet "FADER READY" ein (LED leuchtet) bzw. aus.

Suchlauf rückwärts unter Mithören

Suchlauf vorwärts unter Mithören

PREVIOUS Gerät geht zum Stückanfang zurück.

NEXT Gerät geht zum nächsten Stückanfang. Im

Aufnahmebetrieb wird ein neuer Track gesetzt.

Anschlüsse Die Fernsteuerung wird über den 25poligen D-Stecker mit dem D740

verbunden. Alle Leitungen sind auf der Fernsteuerung auf einen 26-poligen Flachkabelstecker durchgeschleift. Ein Faderstartschalter kann an der

Fernbedienung (Flachstecker P1 bis P3) direkt angeschlossen werden.

D/28 EDITION: 21. September 1992

STUDER D740 ANWENDUNGEN

3 Automatisiertes Überspielen

Über die parallele Schnittstelle sind automatische Überspielungen möglich. Der Automationsgrad ist vom Zuspielgerät abhängig und bezieht sich auf das Starten und Stoppen der Aufnahmefunktion. Je nach Gerät werden auch die Titel gesetzt. Im Display erfolgt jeweils die Rückmeldung.

3.1 Analoge Zuspielgeräte

Grundsätzliches

Vor Aufnahmebeginn muss der Überspielpegel eingestellt werden (siehe Kapitel 2.3.2 Seite 18). Anschliessend den Zuspieler in Startposition bringen.

Es empfiehlt sich vor dem Aufnehmen eines neuen Titels, zur Erzeugung der Titelendmarke 00 eine Pause mit digital Null zu schreiben. Dies geschieht mit der Taste REC MUTE[10]. Die Pause beträgt mindestens zwei Sekunden und kann mit wiederholtem Drücken je um eine Sekunde erweitert werden. Wird die Taste länger als eine Sekunde nicht betätigt, startet der Recorder selbsttätig, zeichnet die Pause physikalisch auf und geht schliesslich in Aufnahmebereitschaft.

STUDER Bandmaschinen (A807, A810, A812, A816, A820 Eine CD-R in den D740 einlegen und über RECORD[9] in Record-Standby-Modus schalten. Die Zuspielmaschine in die Startposition bringen. Am D740 mit PLAY[8] den Aufnahmevorgang starten. Sobald der D740 physikalisch die CD-R beschreibt, startet der Zuspieler automatisch, falls die Maschinen über die parallelen Schnittstellen entsprechend der Skizze verbunden sind. Ist die Aufnahme beendet, manuell über PAUSE[11] oder STOP/CM[12] den Vorgang unterbrechen.




Fig. 3.1 Verbindungskabel zwischen den beiden Parallel Remote von den Bandmaschinen und dem D740

EDITION: 21. September 1992 D/29

ANWENDUNGEN STUDER D740

Plattenspieler EMT938 EMT948

Eine CD-R in den D740 einlegen und über RECORD[9] in Record-Standby-Modus schalten. Den Zuspieler in die Startposition bringen, dabei ist die Hochlaufzeit des Plattenspielers zu berücksichtigen. Mit PLAY[8] den Aufnahmevorgang starten. Sobald der D740 physikalisch die CD-R beschreibt, startet der Plattenspieler automatisch. Ist die Aufnahme beendet, manuell über PAUSE[11] oder STOP/CM[12] am D740 den Vorgang unterbrechen.




Fig. 3.2 Verbindungskabel zwischen den beiden Parallel Remote von EMT 938 Plattenspieler zu D740




Fig. 3.3 Verbindungskabel zwischen den beiden Parallel Remote von EMT 948 Plattenspieler zu D740

STUDER D740 ANWENDUNGEN

3.2 Digitale Zuspielgeräte

Vor Aufnahmebeginn die digitale Verbindung herstellen (siehe Kapitel 2.3.3 Seite 19).

STUDER A730 STUDER D730/D731 Verbinden Sie den AUXILIARY Ausgang des CD-Players A730 (bei D730/D731 den parallel Remote Ausgang) mit dem Parallel Remote des CD-Recorders D740. Eine CD-R in den D740 einlegen und über RECORD[9] in Record-Standby-Modus schalten. Den Zuspieler in die Startposition bringen. Mit PLAY[8] den Aufnahmevorgang starten. Sobald der D740 physikalisch die CD-R beschreibt, startet der CD-Recorder den CD-Player automatisch. Trackwechsel werden automatisch übernommen, wenn NEW TRACK in Stellung AUTO ist. Die Überspielung kann jederzeit manuell über PAUSE[11] oder STOP/CM[12] vom D740 unterbrochen werden. Ist der CD-Player in Stellung AUTOPAUSE, wird der Überspielvorgang bei Trackende automatisch unterbrochen, ansonsten wird erst am Ende der CD die Überspielung automatisch beendet.




Fig. 3.4 Verbindungskabel zwischen dem Auxiliary Port vom CD-Player A730 und der Parallel Remote vom D740. (Bestell-Nr. 1.629.690.00)




Fig. 3.5 Verbindungskabel zwischen den beiden Parallel Remote vom CD-Player A730 zu D740

EDITION: 24. September 1992

ANWENDUNGEN STUDER D740

STUDER A727

Eine CD-R in den D740 einlegen und über RECORD[9] in Record-Standby-Modus schalten. Den Zuspieler in die Startposition bringen. Mit PLAY[8] den Aufnahmevorgang starten. Sobald der D740 physikalisch die CD-R beschreibt, startet der CD-Recorder den CD-Player automatisch. Trackwechsel werden automatisch übernommen, wenn NEW TRACK in Stellung AUTO ist. Die Überspielung kann jederzeit manuell über PAUSE[11] oder STOP/CM[12] vom D740 unterbrochen werden.




Fig. 3.6 Verbindungskabel zwischen den beiden Parallel Remote von CD-Player A727 zu D740

STUDER D780

Eine CD-R in den D740 einlegen und über RECORD[9] in Record-Standby-Modus schalten. Den DAT-Recorder D780 in die Startposition bringen. Mit PLAY[8] den Aufnahmevorgang starten. Sobald der D740 physikalisch die CD-R beschreibt, startet der CD-Recorder den DAT-Recorder automatisch. mit jedem START-ID wird ein Trackwechsel generiert, falls NEW TRACK in Stellung MANUAL ist. Die Überspielung kann vorzeitig über PAUSE[11] oder STOP/CM[12] abgebrochen werden. Allerdings ist ein automatischer Stoppvorgang möglich, indem beim DAT-Master vorher ein END-ID gesetzt wurde, ansonsten muss der Überspielvorgang manuell abgebrochen werden.




Fig. 3.7 Verbindungskabel zwischen den beiden Parallel Remote von R-DAT-Recorder D780 zu D740 (Bestell-Nr. 1.629.691.00)

D/32 EDITION: 24. September 1992

STUDER D740 ANWENDUNGEN

3.3 CD-Mehrfachkopierstation

Mehrere CD-Recorder STUDER D740 können mit einem D780 R-DAT Recorder zu einer Kopierstation für CD-R verbunden werden. Das DAT-Masterband steuert mit den Start-ID's die neuen Trackanfänge auf der CD-R. Die END-ID stoppt alle angeschlossenen Geräte.

Steuerkabel

Das Steuerkabel muss der Anzahl Geräte entsprechend individuell angefertigt werden. Die integrierte Starttaste löst den Kopiervorgang bei allen Geräten aus. Am Ende der Überspielung erfolgt durch die END-ID auf dem DAT-Master ein automatischer Stop. Der D780 ist während der Überspielung nicht bedienbar.




Fig. 3.8 Verbindungsleitung mit Starttaste für eine CD-Mehrfachkopierstation mit DAT-Masterband.

Audioverbindungen

Der digitale Ausgang DIG OUT des D780 wird auf den digitalen Eingang DI des ersten CD-Recorders geführt. Von dessen Digitalausgang DO geht es kaskadenartig weiter zum Digitaleingang des zweiten CD-Recorders usw.

EDITION: 21. September 1992

ANWENDUNGEN STUDER D740

Einstellung DAT-Zuspieler

- Der D780 muss an PIN 7 der Parallel Remote Buchse die START-ID's ausgeben. Dazu muss der DIP-Schalter 8 auf dem Main Board in Stellung "ON" gesetzt werden (PNO COPY MODE).
- Faderstart-Modus A muss eingestellt sein. Nach dem Start sind die Bedienfunktionen gesperrt und die rote LED 'ON AIR' leuchtet.
- Abtastrate des Masterbandes: 44,1kHz. Abweichende Werte erfordern den Einsatz eines Abtastratenwandlers.
- START-ID's sollten rund eine halbe Sekunde vor dem Modulationsbeginn gesetzt sein, damit die Trackanfänge der CD-R auch auf jedem CD-Spieler exakt wiedergegeben werden können.
- Das Band auf die erste Start-ID am Programmbeginn in PAUSE positionieren.

Einstellung CD-Recorder

- Die Funktion NEW TRACK muss auf MANUAL eingestellt sein!
- Die digitale Aufnahme vorbereiten und Aufnahmebereitschaft mit [RECORD]
 + [PAUSE] erstellen.

Koordinierter Start

Die Starttaste am Steuerkabel löst bei allen CD-Recordern die Aufnahme aus. Sobald diese bereit sind, die CD-R zu beschreiben, wird der R-DAT Recorder mit einem Faderstart-Signal gestartet. Die LED "ON AIR" leuchtet rot.

Abschluss des Vorgangs

- Mit dem Erreichen der END-ID wird die Überspielung abgebrochen. Alle CD-Recorder schalten auf PAUSE, der D780 auf STOP.
- Bei Bedarf kann nun eine weitere Überspielung auf die eingelegten CD-R's folgen.
- Zum Schluss wird der 'FIX UP' bei allen CD-Recordern wie folgt ausgelöst:
 [STOP] [FIX UP] [RECORD]

D/34 EDITION: 21. September 1992

STUDER D740 SERVICE

4 Serviceanleitung

4.1 Arbeitshinweise

4.1.1 Prüfmodus

Prüfmodus aktivieren

Während der D740 eingeschaltet wird, zwei Tasten wie NEXT und PREVIOUS gleichzeitig drücken. Es erfolgt die Anzeige SERVICE. Die Abspiel- und Aufnahmefunktionen sind gesperrt. Der Prüfmodus enthält sieben verschiedene Aussagen. Anstelle der Tracknummer erscheint die Servicestufe, im restlichen Display die Serviceinformation.

Servicestufe	Anzeige	Beschreibung
0	SERVICE	Servicefunktion aktiviert
1	hhhhh:mm	Betriebsstunden der Lasereinheit in Aufnahmefunktion
2	hhhhh:mm	Betriebsstunden der Lasereinheit in Wiedergabefunktion
3	nn	OPC Reset Nummer
4	ERR NR	Systemfehler (nachfolgende Aufstellung)
5	BURN-IN	Burn-in Test; Vorsicht! Diese Servicestufe ist ausschliesslich für die Produktion vorgesehen; falls versehentlich dieser Modus angewählt wurde, kann er durch Ausschalten des Gerätes mit offener Schublade verlassen werden. In diesem Modus kann eine leere CD-R mit 99 Tracks automatisch vollgeschrieben werden. Dabei wird nach jedem Track die Schublade geöffnet und wieder geschlossen, um die PMA nach jedem Track zu ergänzen.
6	OPC CLR	Rücksetzen aller OPC-Daten, diese Funktion ist ausschliesslich bei einem Laufwerkswechsel durchzuführen. Durch Drücken der CLEAR-Taste wird

Mittels NEXT oder PREVIOUS können die oben aufgeführten Servicestufen aufgerufen werden. Durch STOP verlassen Sie den Servicemode.

Optimum Power der Lasereinheit zurückgesetzt. Gleichzeitig wird der Betriebsstundenzähler auf Null gesetzt und der OPC Reset Counter um 1 erhöht.

Im Servicemode über die Servicestufe 4 werden folgende möglichen Systemfehler angezeigt. Bei Servicestufe 4 wird durch PLAY der normale Wiedergabe aktiviert und falls ein Fehler vorliegt, erscheint die Anzeige ERR nn (nn = Nummer des Fehlers).

nn	Fehlerbeschreibung
02	Fehler Servo
03	ATIP Fehler
04	Subcode Fehler
05	PMA Fehler
06	TOC Fehler
07	Discinfo Formatfehler
80	OPC Fehler
09	Linkingfehler
11	Monitor Fehler
13	Überschreibfehler

EDITION: 21. September 1992

SERVICE STUDER D740

4.1.2 Elektrostatisch empfindliche Bauteile "ESD"

Statische Elektrizität:

Viele Materialien der heutigen Arbeitswelt sind mögliche Quellen statischer Elektrizität. Unter geeigneten Voraussetzungen können sich dadurch Gegenstände und Personen auf sehr hohe Potentiale aufladen. Bei Entladung dieser Potentiale können Impulse von beachtlicher Spitzenleistung auftreten. Findet auch nur ein kleiner Teil dieser Energie seinen Weg in Bauelemente der Elektronik, werden diese zerstört oder beschädigt.

Umgang mit ESD-Platinen:

Es muss deshalb unser Ziel sein, unsere Produkte vor Fehlern und Mängeln durch elektrostatische Entladung zu bewahren. Richtiger Umgang mit elektronischen Baugruppen ist im Bereich der Gerätewartung von grösster Wichtigkeit. Dabei gilt es einige einfache Verhaltenshinweise zu befolgen:

- 1. Entladen Sie sich durch Anfassen von Erde, bevor Sie eine elektronische Baugruppe in die Hand nehmen.
- 2. Geben Sie dem Partner zuerst die Hand und dann die Baugruppe.
- 3. Fassen Sie einen bestückten Print grundsätzlich nur am Rand oder an der Frontplatte an.
- Berühren Sie niemals Leiterbahnen, Anschlusspunkte oder Bauelemente, ohne sich vorher zu entladen.
- Schalten Sie die Netzspannung aus, bevor Sie eine ESD-Baugruppe herausnehmen oder einstecken.
- Transportieren und lagern Sie ESD-Baugruppen immer in ESD-Verpackungen.
- 7. Arbeiten Sie nur mit ESD-geeigneten und geprüften Werkzeugen.
- 8. Tragen Sie bei Arbeiten an elektrischen Baugruppen, egal ob ESD oder nicht, immer das Erdungsarmband.
- **9.** Halten Sie Styropor, PVC-Folien, Plastiksäcke und ähnliche Materialien weit entfernt von ESD-Baugruppen.

Wir empfehlen, den Arbeitsplatz mit einer geerdeten Unterlage auszurüsten:

ESD-Schutzmatte

Dieses Kit enthält eine Schutzmatte (60×70 cm) mit Erdungskabel und Erdungsarmband für Arbeiten an elektrischen Baugruppen.

Best. Nr. **20.020.001.44**

D/36

EDITION: 21, September 1992

4.1.3

Umrechnungstabelle: Spannungspegel ↔ Dezibel

<u> </u>	μ۷ —					μV —			- IB
U ₁	mV —			dBu	<u>U</u> 1	mV —		dBu	dBu
U ₂	V —	dBu	dBu		U ₂		—dBu	abu	
1	0,775	±0	-60	-120	31,6	24,5	+30	-30	-90
1,12	0,87	+1	- 59	– 119	35,5	27,5	+31	-29	-89
1,26	0,98	+2	-58	-118	39,8	30,8	+32	-28	-88
1,41	1,09	+3	-57	-117	44,7	34,6	+33	-27	-87
1,59	1,23	+4	-56	-116	50,1	38,8	+34	-26	-86
1,78	1,38	+5	-55	- 115	56,2	43,6	+35	-25	-85
2,00	1,55	+6	-54	-114	63,1	48,9	+36	-24	-84
2,24	1,73	+7	-53	-113	70,8	54,8	+37	-23	-83
2,51	1,95	+8	-52	-112	79,4	61,5	+38	-22	-82
2,82	2,18	+9	-51	-111	89,1	69,0	+39	-21	– 81
3,16	2,45	+10	-50	-110	100	77,5	+40	-20	-80
3,55	2,75	+11	-49	-109	112	86,9	+41	-19	-79
3,98	3,08	+12	-48	-108	126	97,5	+42	-18	–78
4,47	3,46	+13	-47	-107	141	109,4	+43	-17	–77
5,01	3,88	+14	-46	-106	159	122,8	+44	-16	- 76
5,62	4,36	+15	-45	-105	178	137,7	+45	-15	– 75
6,31	4,89	+16	-44	-104	200	154,5	+46	-14	-74
7,08	5,48	+17	-43	-103	224	173,4	+47	-13	-73
7,94	6,15	+18	-42	-102	251	194,6	+48	-12	-72
8,91	6,90	+19	-41	-101	282	218,3	+49	-11	-71
10,0	7,75	+20	-40	-100	316	244,9	+50	-10	- 70
11,2	8,69	+21	-39	-99	355	274,8	+51	- 9	-69
12,6	9,75	+22	-38	-98	398	308,4	+52	-8	-68
14,1	10,9	+23	-37	-97	447	346,0	+53	- 7	-67
15,8	12,3	+24	-36	-96	501	388,2	+54	-6	-66
17,8	13,8	+25	-35	-95	562	435,6	+55	-5	-65
20,0	15,5	+26	-34	-94	631	488,7	+56	-4	-64
22,4	17,3	+27	-33	-93	708	548,4	+57	-3	-63
25,1	19,5	+28	-32	-92	794	615,3	+58	-2	-62
28,2	21,8	+29	-31	-91	891	690,4	+59	-1	– 61
31,6	24,5	+30	-30	-90	1000	774,6	+60	±0	-60

Die fettgedruckte Kolonne enthält Spannungswerte. Die drei anschliessenden Kolonnen zeigen die entsprechenden Dezibelwerte bei Interpretation der Spannungen als Volt, Millivolt oder Mikrovolt. Die erste Kolonne zeigt Spannungsverhältnisse, deren Entsprechung in dB in der auf Volt bezogenen Dezibelreihe abzulesen ist.

Der Tabelle liegt die Definition $\mbox{ 0dB} \cong \mbox{ 0,775V}_{\mbox{\scriptsize eff.}}$ zugrunde.

EDITION: 23. September 1992

DEMONTAGE STUDER D740

4.2 Demontage

Sicherheit



Alle internen Einstellungen an diesem Produkt sind geschulten Fachleuten vorbehalten!

Da während Servicearbeiten gefährliche Laserstrahlung auftritt, müssen umfassende Sicherheitsvorkehrungen getroffen werden. **GEFAHR!**

Unsichtbare Laserstrahlung, direkte Bestrahlung vermeiden! Laser Klasse 3b bei geöffnetem Gerät.

- Vor der Demontage ist der Netzstecker zu ziehen.
- Beachten Sie die Arbeitshinweise für den Umgang mit elektronischen Bauteilen "ESD" (4.1.3)

Gehäuseabdeckung entfernen

- Die zwei Inbusflachrundschrauben beider Rackwinkel lösen und Rackwinkel entfernen.
- Die Befestigungsschrauben (Kreuzschlitzschrauben) der Abdeckung entfernen; seitlich je zwei, an der Rückseitenoberkante weitere drei Schrauben. Nun lässt sich die Abdeckung nach hinten ziehen abheben.

Bedienpanel ausbauen

- Abdeckung Schublade entfernen, dazu Schublade hinausziehen, von unten rechts und links aussen die Laschen eindrücken und die Abdeckung nach oben drücken.
- Abschlussleiste entfernen, dazu die drei Inbusschrauben lösen.
- Die oberen zwei Torxschrauben des Bedienpanels lösen, den Stecker des Einschalters sowie Verbindungen zu Phones- wie Level-Board lösen und Bedienpanel abziehen.

Bedienpanel einbauen

- Entsprechende Stecker mit Bedienpanel verbinden und in die drei Führungen am Chassis stecken.
- Mit zwei Torxschrauben Bedienpanel oben befestigen.
- Abschlussleiste mit drei Inbusschrauben befestigen.

Software-Tausch

- Bedienpanel ausbauen
- EPROM ist auf dem Encoder PCB angeordnet und kann von vorne ausgetauscht werden

Servoboard

Das Servoboard ist über dem Laufwerk mittels vier Torxschrauben befestigt. Zu reinen Servicezwecken lässt sich das Servoboard senkrecht in die dafür vorgesehene Halterung stellen. Die Steckverbindungen sind farblich gekennzeichnet und so codiert, dass sie automatisch richtig gesteckt werden.

Laufwerk ausbauen

- Abdeckung und Bedienpanel entfernen (s.o.)
- Servoboard ausbauen
- Die je vier Torxschrauben am Laufwerk und der mit dem Laufwerk verbundenen Platine(WOSP-Board) lösen und die Einheit vorsichtig herausnehmen, da die fest mit dem Laufwerk verbundene Platine auf der Lötseite ebenso bestückt ist.

D/38 EDITION: 28. September 1992

STUDER D740 DEMONTAGE

Laufwerk einbauen

- Kabelbaum wieder in die hintere Führung legen.
- Die Einheit vorsichtig mit der Schubladenführung unter dem XLR-Board einschieben ohne die Platinenunterseite der Laufwerkseinheit zu verletzen.
- Die vier langen Torxschrauben dienen der Befestigung des Laufwerkes, vier weitere der Platine(WOSP-Board)
- Kabelverbindungen entsprechend auf dem Laufwerkboard wie dem Servoboard wiederherstellen, dabei die Stecker in die jeweils gleichfarbige Buchse führen und verriegeln
- Servoboard mittels vier Torxschrauben befestigen

Decoder PCB

Das Decoderboard ist von oben mit vier Torxschrauben befestigt, ebenso sind an der Geräterückseite zwei Torxschrauben zu lösen. Zu Servicezwecken kann die Baugruppe in der rechten Halterungen senkrecht gestellt werden.

XLR-Board ausbauen

- Sechskantmuttern (Schlüssel 5) der PARALLEL REMOTE an der Geräterückseite lösen
- Verriegelung der XLR-Anschlüsse lösen, ¼ Drehung im Gegenuhrzeigersinn mit 00-Schraubenzieher
- Trafoabdeckung entfernen, zwei Torxschrauben seitlich entfernen
- Zwei Torxschrauben des XLR-Boards lösen
- XLR-Board vorsichtig in Richtung der Gerätevorderseite schieben bis die aufgelöteten XLR-Einsätze vollständig aus den Steckergehäusen ragen, danach kann das XLR-Board herausgenommen werden.

XLR-Board einbauen

- Steckerverbindungen herstellen
- Die aufgelöteten XLR-Einheiten in die Steckergehäuse führen und mit einer ¼-Drehung im Uhrzeigersinn verriegeln
- PARALLEL REMOTE-Stecker mit den zwei Sechskantmuttern befestigen
- Das Board mittels der zwei Torxschrauben sichern
- Trafoblech aufsetzen und mit den zwei seitlichen Torxschrauben festziehen

Rückseite entfernen

- XLR-Board ausbauen
- Steckergehäuse von Eingang Links und Ausgang Rechts ausbauen
- Zwei Torxschrauben von Netzteil-Kühlblech (unter der vorher gelösten Steckergehäusen) lösen
- 5 Torxschrauben Geräterückseite, je 3 Schrauben unten und oben des Rückseitenblechs lösen und Rückseite kann abgenommen werden Zusammenbau in umgekehrter Reihenfolge

Trafoeinheit

- XLR-Board ausbauen
- Servoboard lösen
- Stecker von Netzteil und Netzschalter lösen
- Leicht nach vorne schieben und herausnehmen

Netzteil

- XLR-Board ausbauen
- Rückseite entfernen
- Stecker abziehen, drei Torxschrauben lösen
- Das Netzteil lässt sich nach oben herausnehmen

Einbau erfolgt in umgekehrter Reihenfolge

Encoder PCB

Diese Platine ist nur von der Geräteunterseite her auszubauen. Dazu die Abdeckung entfernen und die 4 Torxschrauben der Platine lösen.

EDITION: 21. September 1992 D/39

4.3 Schaltungsbeschreibung

Die Schaltungsbeschreibung ist in der Reihenfolge so, dass sie mit dem Schemateil übereinstimmt.

Trafoeinheit 1.629.609

Die Baugruppe besteht aus Netzfilter, Transformator, primärer und sekundärer Verdrahtung. Das Netzfilter enthält den Netzkabeleingang, das Filter, zwei Sicherungshalter, Spannungswähler und die Neztschaltkontakte. Die gültige Schaltkontaktbelegung für Ihr Land entnehmen Sie bitte dem Schemateil. Die sekundären Transformatorwindungen sind auf zwei Spulenkörper aufgeteilt.

Windung	Spannung	Zweck
1	7,65 V	Digitale AC-Speisung
2	7,65 V	Digitale AC-Speisung
3 17,8 V		Analoge AC-Speisung
4 4,3 V		Display AC-Speisung

Die Aufteilung der digitalen AC-Speisung dient der symmetrischen Belastung der Spulen und der gegenseitigen Kompensation der Störfelder. Die Widerstände R1 und R2 schützen die 4,3V Wicklungen vor sekundären Kurzschlüssen.




Fig.4.1 Blockschaltbilder Netzteil

D/40 EDITION: 24. September 1992

Netzteil 1.629.620 Das Netzteil enthält Strombegrenzungswiderstände, Spannungsregler für je ± 9 V, 10V und –5V. Separate Spannungsregler stehen der Audio von ± 15 V zur Verfügung. Je für die Logik und den Mikroprozessor wird ein separater Spannungsregler für +5V sowie ein unabhängiger Regler für die Anzeigeversorgung eingesetzt. Das Netzteil hat weiter einen Spannungsausfallsdedektor.




Fig.4.2 Servo Blockschaltbild

EDITION: 24. September 1992




Fig.4.3 Servo Blockschaltbild

Servoboard 3104.113.0005 Bestell-Nr. 15.162.001 Auf dem Servoboard sind folgende Schaltungsteile untergebracht: Servo-Mikroprozessor, Radial-Regelung, Ausfallsdedektorschaltung, Fokus-Regelung, Discmotor-Regelung und Tray Motor Regelung.

Der Servo-Mikroprozessor übernimmt die Signalverwaltung des Servoboards. Er erhält seine Befehle vom Mikropozessor. Die Radialregelung beinhaltet die Spurnachführung mittels Auswertung zweier Radialfehlersignale. Durch die Ausfallsdedektorschaltung hält die Spurnachführung vorherige Werte, falls kurzzeitig die Steuersignale fehlen. Die Fokusregelung dient der Schärfeeinstellung der Laserlinse. Die Drehzahl der Compact Disc wird so geregelt, dass der Datenstrom konstant bleibt. Im Wiedergabebetrieb wird die Regelgrösse dem EFM-Signal entnommen, in Aufnahme dem aufmodulierten Wobble der CDR.

D/42 EDITION: 21. September 1992




Fig.4.4 Blockschaltbilder WOSP

WOSP (Write once signal prozessor) 15.162.000.00 (incl.CDM-14) Der WOSP ist fest mit dem Laufwerk verbunden. Die Einheit Laufwerk/WOSP sollte nicht zerlegt werden, da die Abgleiche kostspielige Messeinrichtungen voraussetzen. Der WOSP übernimmt die Signalaufbereitung für die Schreibeinheit.




Fig.4.5 Blockschaltbilder Encoder

Encoder PCB 3104.113.0085 Bestell-Nr. 15.162.004 Das EPROM mit der System-Software liegt auf diesem Print. Hier erfolgt die Signalumsetzung von Analog nach Digital wie die Codierung in den digitalen Datenstrom des CD-Formats (EFM-Codierung). Ebenso wird zwischen digitalem und analogem Eingang umgeschaltet. Im weiteren befinden sich auf diesem Print die Pegelmessschaltung, die Steuerung des Mikroprozessor und die Schaltungen für die Systemclock.

D/44 EDITION: 21. September 1992




Fig.4.6 Blockschaltbild Decoder

Decoder PCB 3104.113.0007 Bestell-Nr. 15.162.002 Der serielle Datenstrom in EFM-Codierung wird wieder in ein 16 bit Signal für den linken und rechten Kanal decodiert und in analoge Signale gewandelt. Der digitale Ausgang (SDIF und optical) und die analogen Cinch-Ausgänge sind ebenso auf diesem Print angeordnet.




Fig.4.7 Blockschaltbild XLR-Board

EDITION: 21. September 1992

REINIGUNG STUDER D740

XLR-Board 1.629.630 Das XLR-Board enthält die Übertragersymmetrierung und Pegelanpassung der analogen wie digitalen Ein- und Ausgänge. Weiter befindet sich auf dem XLR-Board die parallele Schnittstelle.

Level-Board 1.629.635 Das Levelboard dient der analogen Eingangspegelanpassung. In kalibrierter Stellung wird der Pegel des analogen Signals ohne weitere Verstärkung dem A/D-Wandler zugewiesen. In unkalibrierter Stellung kann das Signal in einem Bereich von -∞ bis cal+10dB geregelt werden.




Fig.4.8 Blockschaltbild Bedien- und Anzeigeeinheit

Bedien- und Anzeigeeinheit 1.629.635 Die Tastenbefehle werden aufgenommen, gespeichert und weitergeleitet. Ebenso erfolgt die Ausgabe der optischen Rückmeldungen an das Display.

BSDAC-board 3104.113.90100 Bestell-Nr. 15.162.003 Bitstream Digital-Analog-Wandler

Headphone-board 3104.113.0009 Bestell-Nr. 15.162.006 Kopfhörerverstärker

4.4 Reinigung

Notwendigkeit

Falls OPC-Probleme (OPC-ERROR) auftauchen oder der Trackwechsel längere Zeit dauert bis ein Signal hörbar wird, kann die Laserlinse verschmutzt sein.

D/46 EDITION: 21, September 1992

STUDER D740 EINSTELLUNGEN

Reinigung

Das Laufwerk laut Demontageanleitung ausbauen (s. 4.2). Die vier Torxschrauben der WOSP-Platine lösen und den Stecker wie das Laufwerk vorsichtig entfernen. Die Schreib-/ Leseeinheit lässt sich durch eindrücken von vier Laschen vom Schubladenkörper trennen. Die Linse ist nun frei zugänglich. Sie ist aus Kunststoff gefertigt und darf nur mit einem trockenen Wattestäbchen im rechten Winkel zur Laufrichtung vorsichtig ohne drücken gesäubert werden.

4.5 Elektrische Einstellungen



Alle internen Einstellungen an diesem Produkt sind geschulten Fachleuten vorbehalten!

Da während Servicearbeiten gefährliche Laserstrahlung auftritt, müssen umfassende Sicherheitsvorkehrungen getroffen werden. **GEFAHR!**

Unsichtbare Laserstrahlung, direkte Bestrahlung vermeiden! Laser Klasse 3b bei geöffnetem Gerät.

4.5.1 Trafoeinheit 1.629.609

Prüfen

Die Trafoeinheit an einen Regeltransformator anschliessen. Die Spannung so einstellen, dass die Primärspannung an Pin 7&8 ihrer Landesspannung entspricht (zuvor auf diese einstellen) . Folgende Spannungen müssen am Steckverbinder (GR 4) anliegen:

Pin	Spannung
1&2	4,4 V ±10%
2&3	4,4 V ±10%
4&5	18,1 V ±10%
5&6	18,1 V ±10%
7&8	15,5 V ±10%
8&9	15,5 V ±10%

Mögliche Fehler

Falls diese Spannungen nicht anliegen, zuerst die Primärspannung messen. Ansonsten die Sicherungen des Regeltransformators und der Trafoeinheit überprüfen. Falls immer noch keine Spannung anliegt (weil die Sicherungen beim Einschalten durchbrennen), den Primärleerlaufstrom messen. Ist dieser höher als 20mA, deutet dies auf einen Wicklungsfehler bzw. einen Kurschluss in der Sekundärseite hin. Im weiteren die Sicherungswiderstände R1 & R2 wie die Verdrahtung der Trafoeinheit überprüfen.

EDITION: 30. September 1992

EINSTELLUNGEN STUDER D740

4.5.2 Netzteil 1.629.620.00

Voraussetzung

KO mit zweiter Zeitbasis

Prüfen

Netzteil mit Trafoeinheit und Lastboard verbinden. Folgende Gleichspannungen sind gegen den TP8(GND) zu messen:

TP1	-26,5 V ±1V	
TP2	-15V ±0,5V	
TP3	+15V ±0,5V	
TP4	-10V ±0,25V	
TP5	-9V ±0,25V	
TP6	+9V ±0,25V	
TP7	+5V ±0,25V	
TP9	+5V ±0,25V	
TP10	+10V ±0,25V	
TP11	-5V ±0,25V	
TP13	+20V unstab. ripple ±2V	

Mögliche Fehler

- DC-Spannung fehlt, Spannung am Regler kontrollieren, UDC > 14V
- AC-Spannung fehlt, vor und hinter den Strombegrenzungswiderständen messen, UAC > 15Vrms

4.5.3 XLR-Board

1.629.630

Pegelabgleich der analogen Ein- und Ausgänge; Werkseitig ist der CD-Recorder auf einen Analogpegel von +15dBu ein- und ausgangsseitig abgeglichen. Dieser Pegel lässt sich geräteintern verstellen. Dazu müssen vorerst die Rackwinkel abgeschraubt werden. Nach dem Lösen der je zwei Torxschrauben auf beiden Seiten des Recorders lässt sich das Gehäuseblech entfernen (Fig 1.3). Das XLR-Board ist sofort erkennbar im hinteren Teil des Gehäuses.

Abgleich Ausgang

- Dazu ein Millivoltmeter (Last >10MΩ) an den Analogausgang des linken Kanals OUTPUT LEFT[64] schliessen.
- Eine Test-CD einlegen.
- Abspielen von 1kHz Sinus Vollpegel (digitaler Headroom 0dB).
- Mit dem Trimmregler R117 den gewünschten Pegelwert (von +6dBu bis 24dBu regelbar) einstellen.
- Dasselbe für den rechten Kanal OUTPUT RIGHT[65] jedoch mit dem Trimmregler R217 und am rechten Ausgang gemessen wiederholen.

D/48 EDITION: 30. September 1992

STUDER D740 EINSTELLUNGEN

Abgleich Eingang

Zuerst muss der Ausgang abgeglichen werden.

- Der Eingangswahlschalter steht auf ANALOG und der UNCAL-Wechselschalter in Position CAL.
- Testgenerator 1kHz Sinus mit einem Millivoltmeter auf OdBu (symmetrisch) einstellen.
- Den Testgenerator mit dem linken Eingangskanal INPUT LEFT[62] verbinden.
- Am linken Ausgang OUTPUT LEFT[64] das Millivoltmeter anschliessen.
- Eine CD-R einlegen und mit RECORD[9] auf Aufnahmebereitschaft stellen.
- Mit dem Trimmregler R140 auf den Pegel von 0dBu einstellen.
- Dasselbe für den rechten Kanal INPUT RIGHT[63] jedoch mit dem Trimmregler R240 und am rechten Ausgang OUTPUT RIGHT[65] gemessen wiederholen.




Fig.4.9 XLR-Board, Position der Trimmregler für Aus- und Eingang

EINSTELLUNGEN STUDER D740

Gleichtaktunterdrückung der analogen Eingänge

Die Gleichtaktunterdrückung lässt sich mit dem folgenden Messaufbau einstellen.




Fig. 4.10 Messaufbau für die Gleichtaktunterdrückung

Abgleich

- Mit dem Signalgenerator ein 16kHz Signal von +15dBm (4,355Vrms) einspeisen, vorerst linker Eingang
- Die Spannung am Stecker P5 zwischen den Kontakten P5–1 (Left–In) und P5–2 (Left GND) wird mittels C123 auf Minimum abgeglichen. Die Mindestanforderung ist für CMRR > 60 dB bei 16kHz.
- Für den rechten Kanal die Messung mit demselben Einganssignal am rechten Eingang und zwischen P5-7 (Right in) und P5-6 (Right GND) gemessen wiederholen. Mittels C223 die gemessenen Spannung auf Minimum abgleichen.

D/50 EDITION: 23. September 1992

STUDER D740 EINSTELLUNGEN

4.5.4 Parallele Fernbedienung; Jumpereinstellung




Fig. 4.11 Jumper und Anschlüsse der parallelen Fernbedienung

Keyboard 1.328.661

J2 Der Jumper J2 erlaubt in Verbindung mit dem D740, dass während der Aufnahme auch mit der Taste "NEXT" ein neuer Trackindex geschrieben werden kann (gleiche Bedienung wie am Gerät).

P3/4 gesetzt:

"NEXT" während der Aufnahme nicht aktiv.

P4/5 gesetzt:

"NEXT" setzt während der Aufnahme einen neuen

Track.

J3 Mit dem Jumper J3 kann die Taste "NEWTRACK" inaktiv gesetzt werden.

P9/10 gesetzt:

NEWTRACK-Taste ausser Betrieb.

P10/11 gesetzt:

NEWTRACK setzt während der Aufnahme einen

neuen Track.

J4 Der Jumper J4 erlaubt alle Aufnahmefunktionen inklusive RECMUTE und NEWTRACK zu sperren.

P6/7 gesetzt:

Record-Funktionen aktiv

P7/8 gesetzt:

Record-Funktionen nicht aktiv

Supply Board 1.328,662 J1 Der Jumper J1 erlaubt die Speisung für den Faderstarteingang von der Fernsteuerung zu benützen, so dass nur noch ein Schalter angeschlossen werden muss, oder ohne interne Speisung, dass eine Gleichspannung beliebiger Polarität zwischen 10 und 30 Volt angelegt werden muss.

P4/5 verbunden:

externe Speisung des Faderstart

P5/6 verbunden:

Der Faderstart ist mit der internen Speisung verbunden, so dass nur ein Schalter für den

Faderstart benützt werden muss.

J2 Der Jumper J2 muss je nach angeschlossenem Gerät D740 bzw. D780 umgeschaltet werden.

P7/8 verbunden:

Stellung für D740. Die FaderReady-Funktion ist aktiv.

P9/10 verbunden: Stellung für D780

Fett: Werkseinstellung

EDITION: 21. September 1992

EINSTELLUNGEN STUDER D740

Anschluss eines Faderschalters an die parallele Fernbedienung

Die parallele Fernbedienung ist mit Anschlüssen für einen Faderschalter ausgerüstet. Die Spannung zur Schaltung des Faderstarts kann entweder intern abgezweigt oder von extern zugeführt werden.

Faderstart mit interner Speisung




Fig. 4.12 Anschluss des Faderschalters an die parallele Fernbedienung.

Faderstart mit externer Speisung




Fig. 4.13 Anschluss des Faderschalters an die parallele Fernbedienung.

D/52 EDITION: 21. September 1992

5 Ersatzteile

		y		
POS.	UOM	ORDER- NO	NAME	
1	Stk	15.162.000.00	CDM-14 Disk-Drive with WOSP and Tray	
2	Skt	15.162.001.00	Servo-Board	
3	Stk	15.162.002.00	Decoder Board	
4	Stk	15.162.003.00	BS-DAC-Board	
5	Stk	15.162.004.00	Encoder Board	
6	Stk	15.162.005.00	Keyboard	
7	Stk	15.162.006.00	Headphone PCB	
8	Stk	15.162.007.00	Switch-Board	
9	Stk	15.162.008.01	Decoder Conn 1150 (H1) to Var Headphone	
			Conn 1580 (D1)	8 Pin
10	Stk	15.162.008.02	XLR-Board Conn P5 (L27) to Level+Balance P1 (X27)	7 Pin
11	Stk	15.162.008.03	Encoder Conn 1400 (D4) to Decoder Conn 1230 (E4)	10 Pin
12	Stk	15.162.008.04	Encoder Conn 1500 (D5) to Decoder Conn 1090 (E5)	15 Pin
13	Stk	15.162.008.05	Servo Conn 1602 (W15) to Wosp Conn 1001 (S15)	7 Pin
14	Stk	15.162.008.06	Encoder Conn 1505 (L8) to Control+Display	
			Conn 1801 (E8)	7 Pin
15	Stk	15.162.008.07	Power Conn P2 (C9) to Control+Display Conn 1800 (P9)	7 Pin
16	Stk	15.162.008.08	Encoder Conn 1502 (P10) to Power Conn P1 (E10)	9 Pin
17	Stk	15.162.008.09	Encoder Conn 1503 (S11) to Servo Conn 1603 (E11)	9 Pin
18	Stk	15.162.008.10	Power Conn P3 (S13) to Servo Conn 1601 (P13)	9 Pin
19	Stk	15.162.008.11	Cable (P25-X25)	
20	Stk	15.162.008.12	Cable (E26-X26)	
21	Stk	15.162.008.13	Cable (D27-X27)	
22	Stk	15.162.008.14	Cable (D25-X25)	
23	Stk	15.162.008.15	Cable (E3-L3)	
24	Stk	15.162.008.16	Cable (A28-D28)	
25	Stk	15.162.008.17	Cable (A29-D29)	
26	Stk	15.162.008.18	Cable (W6-D6)	
27	Stk	15.162.008.19	Cable (W14-S14)	l
28	Stk	15.162.008.20	Cable (E7-D7)	
29	Stk	15.162.008.21	Cable (W12-E12)	
30	Stk	15.162.009.00	Frontpanel Alu	
31	Stk	15.162.010.00	Cover	
32	Stk	15.162.011.00	Rear Panel	
33	Stk	15.162.012.00	Cover for Disk Tray	
34	Stk	15.162.013.00	Tray Front	
35	Stk	15.162.014.00	Profile, Frame for Disk Tray	
36	Stk	15.162.015.00	Lifter Plate	
37	Stk	15.162.016.00	Disk Tray	
38	Stk	15.162.017.00	Loading Frame for Disk Tray	
39	Stk	15.162.018.00	Pressure Plate	
40	Stk	15.162.019.00	Pressure Ring	

EDITION: 24. September 1992 D/53

POS.	иом	ORDER- NO	NAME	
41	Stk	15.162.020.00	Spring, Tension, for Disk Tray	
42	Stk	15.162.021.00	Compression Spring "140" for Disk Tray	
43	Stk	15.162.022.00	Foam	
44	Stk	15.162.023.00	Compression Spring for Disk Tray	
45	Stk	15.162.024.00	Motor for Disk Tray	
46	Stk	15.162.025.00	Belt	
47	Stk	15.162.026.00	Lens Play/Rec	
48	Stk	15.162.027.00	Lens Cal/Uncal	
49	Stk	15.162.028.00	Window	
50	Stk	15.162.029.00	Button Unit Right	
51	Stk	15.162.030.00	Button Unit Left	
52	Stk	15.162.031.00	Plastic Front	
53	Stk	15.162.032.00	Key Cal/Uncal	
54	Stk	15.162.033.00	Key Power Switch	
55	Stk	15.162.034.00	Phones Knob	
56	Stk	15.162.035.00	Foot	
57	Stk	15.162.036.00	Feltring	
58	Stk	15.162.037.00	Pan Head Screw IS, M 3 × 8 CU	
59	Stk	15.162.038.00	Pan Head Screw 3 × 10 Black for Plastic	
60	Stk	15.162.039.00	Self Tapping Screw KS, 3.5 × 10 Black	
61	Stk	15.162.040.00	CS-Screw IS, M 3 × 6 Black for XLR Connector	
62	Stk	15.162.041.00	Button Unit Left	
63	Stk	15.162.042.00	Cooling Radiator	

D/54 EDITION: 21. September 1992

INDEX

A→B21	Parallele Schnittstelle
Abspielen19	Passagen überspringen26
Anwahl der Titel20	Pausen24, 25
Aufnahme beenden- CD-R abschliessen 24, 25	PCA-Bereich22
Aufnahme beenden- CD-R aufnahmebereit 24, 25	Pegelabgleich48
Aufnahme fortsetzen24, 25	PMA23
Aufnahme unterbrechen24, 25	Program Memory Area (PMA)4
Aufnahmebereitschaft23, 24, 25	Programmieren20
Aufnahmestart25	Prüfmodus aktivieren35
Ausgang7	
Ausgangspegel7	Reinigung47
Aussteuerung23	
Automatische Überspielungen29	SCAN20
. 0	Servicestufe35
Bedien- und Anzeigeeinheit46	Servoboard
Bedienpanel ausbauen	Single track jump2
Bedienpanel einbauen	SKIP und UNSKIP29
Bedienungselemente	Software-Tausch38
BSDAC-board46	Spannungswert
7	START REVIEW20
CD WRITE ONCE DISC (CD-R)3	Stromausfall 23
OB WITE ONCE BIOG (OB TI)	Suchlauf
Decoder45	Odoriidai
Decoder PCB	Table of Contents
Digitalanschluss	Technische daten
Digitalariscrituss24	Titelendmarke 00
Eingangspegel6	•
• • •	Titelgenerierung
Eingänge 6 Encoder 44	Titelweise überspringen 25
	Trafoeinheit
Ersatzteile	Übersteuerungen
Externe Synchronisation21, 23	Übersteuerungen23
Fader-Start21	WAIT
FIX-UP	WAIT
Funktionsanzeigen	Wiedergabe19
runktionsanzeigen18	Word Clock24
Gahäussahdsakung antfornan	WOSP43
Gehäuseabdeckung entfernen	VID Board
Gielchiaktunterdruckung50	XLR-Board39, 46
Headphone-board46	
Kopfhörer14	
Kopierstation für CD-R33	
Ropierstation ful CD-n33	
Laufwerk ausbauen	
Laufwerk einbauen39	
Lead-In	
Lead-out	
Loop21	
Netzeingang5	
Netzschalter 14	
Netzteil39, 41	

Contents

1	Ger	neral - Installation	3
	1.1	Principle of CD recording	3
		CD Recorder D740	3
		CD-R	
		Recording process	
	1.2	Handling the recordable CD-R	
	1.3	Installation	
		Scope of delivery	
		Power connection	
		Inputs	
		Outputs	
		Parallel interface	
	1.4	Technical data of the CD-R (STUDER)	
	1.5	Technical data of the D740	
		1.5.1 Description	
		1.5.2 Electrical data	
		1.5.3 Peripheral connections	
		1.5.4 Power supply	
		1.5.5 Environmental operating specifications	
		1.5.6 Dimensions	
		1.5.7 Safety	
	1.6	Block diagram CD-Recorder D740	
	1.7	Dimensions CD-Recorder D740	
2	Ope	eration	14
	2.1	Operator controls	
		Display	
		Connections	19
	2.2	Playback	19
	2.3	Record functions	22
		Program memory area (PMA)	
		Analog recordings	
		Digital recordings	
		SKIP / UNSKIP	
	2.4	Parallel remote control 1.328.660	28
3	Aut	omated recording	29
	3.1	Analog source units	
	3.2	Digital source units	31
		CD Multicopy station	
4		vice instructions	
•	4.1	Work instructions	
		4.1.1 Test mode	
		4.1.2 Electrostatically Sensitive Device "ESD"	
		4.1.3 Conversion table for voltage levels volt ↔ dBu	
	4.2	Disassembly	
	4.3	Circuit description	
	4.4	Cleaning	
		Electrical alignments	
		4.5.1 Transformer unit 1.629.609	
		4.5.2 Power supply 1.629.620.00	
		4.5.3 XLR board 1.629.630	
		4.5.4 Parallel remote	
5	Spa	re parts	
			_

1 General - Installation


1.1 Principle of CD recording

CD Recorder D740

A CD WRITE ONCE DISC (CD-R) can be written with the D740 CD recorder without additional equipment. The procedure is similar to conventional recording equipment. Recordings can be made sequentially. It is also possible to define start points and skip points during a recording. On completion of the recording a table of contents (TOC) is created and the CD-R can subsequently be played on a conventional CD player. The fields of application are far ranging, be they in audio production or radio studios. Instead of a tape master (analog or digital) a CD-R can be produced which can be played back worldwide without loss of quality and without requiring adaptation to different standards. This greatly simplifies the exchange of programs because CD players are in wide use throughout the world.

CD-R

The recordable CD-R is basically identical to a conventional read-only CD. The substrate is a disc made of polycarbonate in which FM modulated grooves for guiding the laser are engraved. This substrate is coated with an absorption layer which is correspondingly destroyed when the information is recorded. Because of the more stringent reflection properties, the reflective film is made of gold. This film is sealed with a protective coating on which also the label is printed.



GENERAL STUDER D740




Fig. 1.2 Structure of the conventional CD

Recording process

During the recording operation the laser heats the absorption layer to a temperature of approx. 250°C. This is the destruction temperature of this layer. Through this heat the polycarbonate penetrates into the destroyed absorption layer. This is the way pits are created on the CD–R.

The CD-R standard (orange book) allows an additional sector, the Program Memory Area (PMA), which is located before the lead-in. This provisional contents list applies to a CD-R that has not been completely recorded yet and is available for sequential recording of information. Only when the CD is fully recorded is the TOC generated and written. The CD-R then corresponds to the red book standard and can be played back on any CD player.

1.2 Handling the recordable CD-R

The CD-R is highly sensitive to scratches and contamination on both sides. Fingerprints can be avoided by touching the CD-R only on the edges or on the edges and the center hole. They can be cleaned with commercially available liquid CD cleaner or ethyl alcohol. If the contamination is less severe, a soft, dry piece of cloth should suffice. In contrast to frequently held opinions, the label side is just as sensitive to scratches because the reflective gold film is located directly underneath. For labelling only the STUDER supplied CD PEN should be used. Writing tools such as ball-point pens and pencils cause irrepairable damage. Solar radiation or excessive humidity, heat and cold should be avoided.

EDITION: 21. September 1992

STUDER D740 INSTALLATION

1.3 Installation

Scope of delivery

The following accessories are included with the D740:

Itom	Quantity	Part No.	Designation
1 2 3 4 5 6 7 8	1 1 2 2 2 2 2 2 2	89.20.500001 10.95.3220 54.02.0280 54.02.0281 51.01.0115 51.01.0112 51.01.0113 10.258.003.09	CD-R STUDER CD-Pen XLR connector (male) XLR connector (female) Fuse: 630mA slow 250 V Fuse: 315mA slow 250 V Fuse: 600mA slow 250 V Hex. socket-screw key
9	1 1	10.258.003.46 10.27.1881	Torx screw driver Operating instructions

Power connection

Before you put the equipment into service, check the line voltage setting which is visible below the power inlet. For changing the voltage rating or for replacing the primary fuses, the hinged cover can be opened with a screwdriver after the power cord has been pulled out. Procedure for adjusting the line voltage rating: Pull out the small drum and reinsert it in the appropriate position. The correct voltage rating should be visible through the window. The fuses are located on top and can be removed by pulling the compartment marked with an arrow. When the voltage in Europe is standardized to 230 V, the line voltage selector should be changed to 240 V.




Fig. 1.3 Power connection with fuse ratings

EDITION: 22. September 1992

INSTALLATION STUDER D740

Inputs

■ Analog

The inputs are transformer balanced and terminated on XLR sockets. The maximum input level is factory set to +15 dBu, but it can be changed internally to +6...+24 dBu. It is also possible to separately regulate the level within $-\infty$ to Cal+10 dB by means of the INPUT LEVEL left[34] and right[33] potentiometers on the front panel. For this purpose the switch located below must be set to UNCAL[32] because these input potentiometers are bypassed in the CAL setting.

■ Digital

Three inputs are available. The optical and the SPDIF input (cinch connector) conform to the consumer format. The XLR input DI is suited for the AES/EBU as well as the SPDIF format.

Caution:

Under no circumstance should the SPDIF and the DI(AES(EBU) input be used simultaneously!

You must select between the optical input and the two other inputs by means of the switch on the rear panel. The CD standard format allows only the sampling frequency of 44.1 kHz.

E/6 EDITION: 21. September 1992

STUDER D740 INSTALLATION

Outputs

■ Analog

The transformer balanced output signal with a maximum level of +15 dBu is available on the XLR chassis connectors. The output level can be internally adjusted between +6dBu and +24 dBu. In addition there is a cinch stereo output with a level of 2 Vrms.

■ Digital

Also for the digital output there are three possibilities: optical, cinch and XLR outputs have been provided. The SPDIF format is available. With the selector switch for the optical and SPDIF output the digital outputs can be switched on or off.




Fig. 1.4 Input and output assignment

Any internal adjustment of this product is reserved for qualified service personnel only!

Multiple safety precautions are required since dangerous laser radiation occurs during maintenace operation.

Hint


In rare cases of power interruption the message "WAIT" could be displayed permanently. Switching off the equipment and pressing LOAD during the power up will reset the unit.

EDITION: 22. September 1992

INSTALLATION STUDER D740

Parallel interface

The CD recorder can be remote controlled via the parallel interface (25-pin D-type socket).



Pinassignment
1
23SR-Pause 24Key 25+20V unstab. (max 100mA) SR – Switch remote BR – Bulb remote

1.4 Technical data of the CD-R (STUDER)

CD-R

Diameter	120 mm
Disc thickness	1,2 mm
Track pitch	1,6 μm
Reflection factor	>70%
Recording area	Ø 44,7mm bis Ø 118mm
Substrate material	
Recording film	organic
Reflective film	
Recording capacity	63 or 74 min.
Application according to ATIP	
Readback reliability	>1'000'000 read operations
Operating temperature	5°-70°C
Humidity	
Life	
	operating conditions
	(25°C,65%RH)

Never expose the disc to direct sunlight!

E/8 EDITION: 21. September 1992

TECHNICAL DATA

1.5 Technical data of the D740

1.5.1 Description

Equipment typ
Compatibility
Display

Compact-Disc-Recorder

Red Book and Orange Book part II

■ Tracktime: Elapsed time in Min./s

■ Remaining Tracktime: Remaining tim to the

end of a title

■ Total Rem. Time: Remaining tim to the end of

the CD (CD-R)

1.5.2 Electrical data

Audiodata:	Frequency response	± 0,3dB	20Hz20kHz, record and reproduce
	Sampling frequency	44,1kHz	
	A/D converter	Delta-Sigma 64x oversampling	
	D/A converter	1-bit-stream-con	verter
	THD and noise	< 0,008%	-1dB, 20Hz20kHz record and reproduce
	Channel seperation	> 80dB	20Hz20kHz record and reproduce
	Channel balance	< 0,2dB	20Hz20kHz record and reproduce
	Phase response	< ±3°	20Hz20kHz record and reproduce
	Phase response	< ±1°	20Hz20kHz, reproduce

Inputs, analog:

Input left / right
Input impedance

Transformer balanced, floating, XLR $> 10k\Omega$ 20Hz...20kHz, 0dE

only

Max. input voltage

+24dBu

20Hz...20kHz, 0dBu (balanced)

Sensitivity CAL:

+6...+24dBu

for peak level recording

internally adjustable

Standard factory setting:

+15dBu $\pm 0,1$ dBu

Sensitivity UNCAL:

max. +10dB Gain

EDITION: 21. September 1992

TECHNICAL DATA STUDER D740

Inputs, digital: AES/EBU Transformer balanced, floating, XLR

Input impedance 110Ω

Sampling rate 44.1kHz ±100 ppm

SPDIF coaxial Unbalanced on cinch

 $\begin{array}{ll} \text{Input impedance} & \textbf{75}\Omega \\ \textbf{SPDIF optical} & \text{Toslink} \end{array}$

Outputs, analog: OUTPUT left / right Transformer balanced, floating, XLR

Output impedance40Ω20Hz...15kHz, 0dBu

Output level +6...+24dBu for full scale recording

Standard factory setting: +15dBu ±0,1dBu

 Output level
 +24dBu
 600Ω Load

 +22dBu
 200Ω Load

Fixed OUTPUT left / right unbalanced on Cinch-sockets

Output level 2Vrms for full scale recording

Output impedance $< 250\Omega$

Phones: Output level 0 ...6V (open)

Ausgangsimpedanz150Ω

Outputs, digital: AES/EBU Transformer balanced, floating, XLR

Impedance 110Ω

SPDIF coaxial With transformer, unbalanced, on cinch

Impedance 75Ω SPDIF optical Toslink

1.5.3 Peripheral connections

Parallel-Remote Parallel remote on 25-pin D-type connector.

Fader start logic

■ Feedback for tape deck functions

E/10 EDITION: 21. September 1992

STUDER D740 TECHNICAL DATA

1.5.4 Power supply

Voltage selector Line voltages 100V, 120V, 220V, 240V ±10%

Mains frequency 50 ...60 Hz

Power consumption < 40 VA

Power fuses 100... 120V: T 630mA (IEC)

100... 120V USA, CND T 600mA (UL / CSA)

220... 240V: T 315mA (IEC)

Power connection 3–Pole with protective ground

1.5.5 Environmental operating specifications

Ambient air temperature +15° ... +40°C (Function)

+15° ... +35°C (Specificationen)

Relative humidity Category F (DIN 40040)

Operation position Horizontal (±5 degrees)

Power failure 80 ms

1.5.6 Dimensions

Dimensions: Overall dimensions $483 \times 132,5 \times 351 \text{ mm}$ $(W \times H \times D)$

including rack ears and pads

Installation clearance, height 132,5 mm (3HE)

Installation clearance, height 420 mm without rack ears

Weight: 10 kg

1.5.7 Safety

Safety standard EN 60065 / IEC 65

EMC-Standard EN 50081-1 / EN 50082-1

Laser IEC 825 Class 3B

EDITION: 23. September 1992

BLOCK DIAGRAM STUDER D740

1.6 Block diagram CD-Recorder D740




Fig.1.5 Block diagram CD-Recorder D740

E/12 EDITION: 22. September 1992

DIMENSIONS

1.7 Dimensions CD-Recorder D740







Fig.1.6 Dimensions CD-Recorder D740

EDITION: 22. September 1992 E-/13







E/14 EDITION: 20. September 1991

2 Operation

2.1 Operator controls

Front panel		Operator controls				
[1]	POWER	Power switch for switching the line voltage on or off.				
[2]	PHONES	Stereo jack socket for connecting the headphones (200 α -600 α).				
[3]	VOLUME	Potentiometer for adjusting the headphones volume.				
[4]	CD drawer	The drawer can be opened by pressing the LOAD[5] key. The CD (also CD single possible) is placed with the label facing upward into the open drawer. The drawer can be closed either by pressing the LOAD[5] key again, by lightly pushing in the drawer or by selecting a title directly via the numeric keypad or by pressing the PLAY[8] or RECORD[9] keys.				
[5]	LOAD	LOAD opens or closes the CD drawer.				
[6]	PREVIOUS	Return to the start of the track; possible in pause mode as well as play mode.				
[7]	NEXT	Jump to the next title; possible in pause mode as well as play mode.				
[8]	PLAY	The play or record operation is initiated. The LED above this key is light during the play operation. While a recording is in progress the red LED above the RECORD[9] key is continuously light.				
[9]	RECORD	The RECORD command positions the laser at the last recorded address (at the start of the CD-R if it is completely new). The display supplies information on the remaining recording time and the new title number. The CD recorder is now ready to record. This status is confirmed by the red flashing LED located above this key. To start the recording press the PLAY[8] key.				
[10]	REC MUTE	With this function you can create pauses containing digital zeros. For this purpose the recorder must be in record standby mode. The first actuation of this key produces a pause with a duration of 2 seconds. Each brief depression of this key increase the pause by one second. The display shows the corresponding time in seconds. If the key is released for more than one second, the pause is physically written and the recorder is ready for recording the next title.				
[11]	PAUSE	This key interrupts the play and record operations. The current position is retained and the corresponding time informations will be displayed. If the unit was previously operating in record mode, it switches to record standby mode. The pause function can be cancelled with PLAY[8].				

STUDER D740 OPERATION

[12]	STOP/CM	Cancels the play or record operation. If this key is pressed a second time, the program memory is cleared (CM; clear memory).			
[13]	>	With the forward search you can move the laser pickup from any position toward the end of the CD. Continuous forward search is possible by holding this key down. The search can be activated in pause and play mode.			
[14]	FAST	Two search speeds exist. With FAST you can toggle between the two speeds. When FAST search is active, the word FAST is visible on the display.			
[15]	∢	With the search backward function you can position the laser pickup from any position toward the start of the CD. Continuous backward search is possible by holding this key down. The search can be activated in pause and play mode.			
[16]	SCAN	This function plays the first 10 seconds of each title. Normal play mode can be activated immediately by pressing this key again.			
[17]	REVIEW END	In pause mode the last 8 seconds of the current title are played. The laser then returns to the starting position.			
[18]	START REVIEW	The player reproduces the CD from the current position for as long as this key is pressed. When this key is released the laser pickup returns to the starting position.			
[19]	DISPLAY	With this key the display can be changed over to one of three time indications: Elapsed time of the current title Remaining time to the end of the title (only possible in play mode) Remaining time to the end of the CD. In record mode this corresponds to the remaining recording capacity.			
[20]	PEAK RESET	Resets the peak indicator.			
[21]	Numeric keypad	 Direct selection of a title by entering the title number Input of the title number during the programming 			
[22]	PROGRAM/PLAY	This switch toggles between playing with direct title access and direct programming.			
[23]	REVIEW	When this key is pressed each programmed title is displayed for one second. If a quicker look through the program is desired the next title appears each time the REVIEW key is pressed.			
[24]	CLEAR	 Programming by deletion; enter the unwanted title number on the numeric keypad and confirm with CLEAR. The number matrix in the display field shows the remaining title numbers. In SCAN mode, programming by deletion is possible (in the sequence given by the CD). Mark the title to be skipped by pressing CLEAR; the deleted title number disappears from the number matrix. 			
[25]	STORE	 Programming by addition; enter the number of the desired title on the numeric keypad and confirm with STORE. The number matrix in the display field shows the selected title numbers. In SCAN mode, programming by addition is possible (in the sequence given by the CD). Mark the desired titles by pressing STORE; the selected title numbers appear on the number matrix. 			

OPERATION STUDER D740

[26]	INPUT SELECT	Selection between the digital and analog input with feedback by status LED.			
[27]	NEW TRACK	There are two possibilities for creating new titles. The selected status is indicated by one LED each.			
		 AUTO For an analog recorder a new track is set if the audio level again exceeds -60 dB for at least 3 seconds. The same principle is used for setting a new track in a digital recording, except when the source is a CD player. 			
		 When a STUDER CD player (also recorder) is used as the source, the recorder automatically accepts the track change of the source in a digital copying process. 			
		■ MANUAL - In this status a new title is created whenever NEXT[7] is pressed.			
[28]	SKIP	Initiates the SKIP function. Unwanted sections are automatically skipped when corresponding skip points have been defined. When this function is selected, the word SKIP is visible on the display. The corresponding skip point can be determined either via the title selection or the search function.			
[29]	UNSKIP	Initiates the UNSKIP function. Previously defined skip points are cancelled. When this function is selected, the word UNSKIP is visible in the display. The skip points to be deleted can be determined either via the title selection or the search function.			
[30]	A→B	Determines the start and end point of a run to be repeated.			
[31]	FIX-UP	After a CD-R has been completely recorded, the table of contents can be recorded by pressing the FIX-UP key. The CD-R then corresponds to the red book standard and can be played back on a conventional CD player. However, no further recording is possible on this CD.			
[32]	UNCAL	Changeover between analog input with fixed level and input adjustable with the potentiometers [32] and [33]. Feedback with status LEDs.			
[33]	RIGHT	Input level control for the right-hand channel, active when UNCAL is set.			
[34]	LEFT	Input level control for the left-hand channel, active when UNCAL is set.			

E/16 EDITION: 21. September 1992

OPERATION

Display

STUDER D740

[40]	Number matrix	The numbers of the title still to be played are shown, provided the number of titles does not exceed 20. Titles that have already been played or which have been programmatically deleted disappear from the display.
[41]	(((•	Lights up as soon as the remote control is activated.
[42]	PLAY DIRECT	Play mode, direct title selection via the numeric keypad[21] possible.
[43]	DIRECT PROGR.	Programming mode is active.
[44]	PROGRAM	Program execution.
[45]	FIX-UP	This word is light while the table of contents for completing a CD-R is being recorded.
[46]	A→B	Start and end point of the loop function or of the section to be skipped (SKIP).
[47]	REPEAT	Repetition of the loop function.
[48]	CD	A non-recordable CD is inserted.
[49]	CD RECORDABLE	A recordable CD is inserted.
[50]	REC SYNC	If a digital audio source is connected, this indicator confirms the correct word clock synchronization. The CD recorder automatically switches to external sync if an active external clock source is connected during the power up. This setting is valid for both record and play mode. Otherwise the internal clock reference is used as a synchronisation source.
[51]	Level indication	Indicates the level that is measured after the DA stage.
[52]	TOTAL REM TRACK TIME	Time indication; depending on the setting, this is either the elapsed title time, remaining title time or remaining playing time or the remaining capacity of a recordable CD-R.
[53]	TRACK	Indicates the current title number.

EDITION: 21. September 1992 E/17

OPERATION STUDER D740

[54]	Function indicators	Signification
	READING	Table of contents (TOC) on CD or PMA on CD-R is being read.
	OPEN	The CD drawer is opened.
	CLOSE	The CD drawer is closed.
	SCAN	The scan function is activated, the first 10 seconds of each title are played.
	ERROR	Operating error or defect.
	NO DISC	A play or record operation was attempted even though no CD or CD-R is in the drawer.
	NO CDR	A record operation was attempted even only a CD or no CD-R is in the drawer.
	RECORD	The recorder is ready for recording. In SKIP/UNSKIP mode the currently entered point is stored.
	OPC	After a CD–R has been inserted the write laser is automatically aligned.
	NO LOCK	A digital audio source is connected but does not supply a word clock.
	NO SYNC	No digital input; switch off and on the line voltage
	SKIP	The SKIP function is activated.
	SK	Skip is performed during playback.
	SKIP ON	Indicates the deleted SKIP command during UNSKIP function
	UNSKIP	The UNSKIP function is activated.
	USK	Unskip is being performed.
	VERIFY	Rehearsal of a programmed SKIP/UNSKIP function.
	WAIT	Update PMA after a power interruption, download from EEPROM
	FULL	99 titles or the CDR is full
	FULL	33 titles of the opn is full

E/18 EDITION: 23. September 1992

STUDER D740 OPERATION

Connections

[60]	FIXED OUTPUT	Cinch output			
[61]	DIGITAL OUTPUT	Optical and SPDIF cinch digital output. The digital outputs can be switched on or off with the switch.			
[62]	INPUT LEFT	Analog line input, left-hand channel, transformer balanced (XLR), factory set to			
[63]	INPUT RIGHT	+15 dBu (1 kHz, digital 0 dB) Analog line input, right-hand channel, transformer balanced (XLR), factory set to +15 dBu (1 kHz, digital 0 dB).			
[64]	OUTPUT LEFT	Analog line output left-hand channel, transformer balanced (XLR), factory set to +15 dBu (1 kHz, digital 0 dB).			
[65]	OUTPUT RIGHT	Analog line output right-hand channel, transformer balanced (XLR), factory set to +15 dBu (1 kHz, digital 0 dB).			
[66]	DI	Digital AES/EBU input			
[67]	DO	Digital output, SPDIF format			
[68]	PARALLEL REMOTE	Parallel interface			
[69]	AC POWER	AC-Connector			
[70]	DIGITAL INPUT	Digital cinch input			
		Caution: Under no circumstances should the SPDIF and the DI(AES/EBU) input be used simultaneously!			
[71]	Toggle switch	Changeover between optical and cinch/XLR digital input			
[72]	OPTICAL	Optical digital input			
2.2	Playback				
		In addition to playing a CD with the PLAY[8] key from the beginning to the end there are various other possibilities.			
Time indication		Three different times can be read out by pressing the DISPLAY[19] key: Remaining time to the end of the CD, elapsed time since the start of the title, and remaining time of the current title.			
Search ◀ ►		With this function you can search any position toward the start or the end of the CD; two different search speeds can be selected via FAST[14]. When the search is performed in play mode, the modulation can be heard intermittently. Searching is also possible in pause mode and the corresponding time information is shown on the display.			

EDITION: 21. September 1992 E/19

PLAYBACK STUDER D740

Title selection

There are different ways of selecting a title. When the title number is entered via the numeric keypad[21], the corresponding title will be played immediately unless the programming mode is selected (status indication **DIRECT PROGRAM**, otherwise **PLAY DIRECT**). If the next or the preceding title (i.e. the start of the corresponding title) is to be played, the keys NEXT[7] or PREVIOUS[6] can be pressed.

Programming

DIRECT PLAY
Title-number ?
STORE / CLEAR
Title-number ?
STORE / CLEAR
Title-number ?
STORE / CLEAR
etc.
REVIEW
PLAY
(NEXT / PREVIOUS)
2x STOP/CM

PROGRAM/PLAY
Title-number?
etc.
REVIEW
PLAY
(NEXT / PREVIOUS)
2x STOP/CM

Playing and programming a title

START REVIEW REVIEW END

A→B

Assuming a random sequence of titles is to be programmed. This can be accomplished in two different ways.

- Numerically enter the sequence of the desired titles in direct play mode and press STORE[25] after each title selection.
- Press PROGRAM/PLAY to activate the direct program status. Enter the titles numerically. If within 2 seconds neither the STORE[25] key nor the CLEAR[24] key is actuated, the corresponding title is automatically included in the program, otherwise it will be included or cancelled.

The number matrix in the display provides information on the title selection. To the left of the time information the item number is indicated. The program sequence can be monitored with REVIEW[23]. When this key is pressed the title numbers are displayed for 1 second, otherwise step by step with each key depression. If instead of the STORE[25] key the CLEAR[24] key is pressed during the programming, the corresponding title will be deleted from the program sequence. The program can be started with PLAY[8]. NEXT[7] and PREVIOUS[6] now refer to the programmed sequence of titles. To cancel the complete program press the STOP/CM key[12] twice. This is confirmed on the display with CLR PRG.

The first 10 seconds of a title can be played by activating the SCAN[16] function. With STORE[25] or CLEAR[26] the title can be included or deleted from the program sequence. To cancel the SCAN function press SCAN[16] again.

With the two functions REVIEW (-START; -END) the start or end of a title can be reviewed without losing the starting position of the laser pickup. With REVIEW START[18] the selection is played for as long as the key is pressed. With REVIEW END[17] the last 8 seconds are played. The laser pickup then returns to the starting position.

Repetition of a sequence; in play mode press $A \rightarrow B[30]$, this defines that starting point A of the sequence. The end point B is set when $A \rightarrow B[30]$ is pressed again. The end point can be searched more quickly by pressing fast forward \blacktriangleright [13]. The programmed sequence is repeated as a loop from A to B. When $A \rightarrow B[30]$ is pressed again, the CD player returns to normal CD play mode.

More accurate programming of a sequence (loop) is possible in pause mode. Determine the exact starting point A by pressing SEARCH REVERSE[15] or FORWARD[13]. When $A \rightarrow B[30]$ is pressed the first time, $A \rightarrow$ flashes in the display field. You can now accurately define the end point B with SEARCH REVERSE[15] or FORWARD[13]. When $A \rightarrow B[30]$ is pressed again, $A \rightarrow B$ flashes in the display field. The programmed sequence is repeated as a loop after pressing PLAY from A to B. When $A \rightarrow B[30]$ is pressed again, the CD player returns to normal CD play mode.

E/20 EDITION: 21. September 1992

PLAYBACK

Single track jump

PAUSE → ► PAUSE In this mode you can accurately define a starting point. The CD player plays up to a cue point and the laser pickup then jumps backward by one track and plays again up to the cue point. This function is activated by pressing SEARCH REVERSE[15] or FORWARD[13] in pause[11] mode. When SEARCH REVERSE (FORWARD) is pressed, the cue point is shifted in the corresponding direction toward the start or end of the CD. The single-track jump mode can be deactivated by pressing PAUSE[11].

Fader start

A fader start device can be connected to the parallel interface (contacts 11 and 12). The activated fader starts initiates the play function from any position.




Fig. 2.1 Fader start connection

External synchronization

If a word clock signal (AES/EBU or SPDIF) is connected to the digital input (e.g. studio clock or supplied by another CD player), the CD recorder automatically switches to the external sync if the external source is activ during the power up.

RECORDING STUDER D740

2.3 Record functions

As an introduction we shall provide some general information on the subcode of conventional CDs. The structure of the subcode is fixed. The table of contents (lead-in) contains the starting point of the titles and the absolute end of the modulation. At the end of the modulation there is a lead-out. This mandatory arrangement of the CD subcode is not suited for consecutive recording of the CD-R. For this reason an open table of contents (PMA) is first created and the lead-in and lead-out are created (with FIX-UP) only when all information has been recorded. The PCA area is used for optimizing the alignment of the recording laser.




Fig. 2.1 Lead-in, lead-out of a conventional CD




Fig. 2.2 Lead-in, lead-out, PMA of an incompletely recorded CD-R




Fig. 2.3 Lead-in, lead-out of a completely recorded CD-R (Fix-up)

E/22 EDITION: 22. September 1992

STUDER D740 RECORDING

2.3.1 Program memory area (PMA)

The PMA is written on the CD-R before the lead-in. This memory level is a buffer for incompletely recorded CD-Rs. It contains two types of information:

- Table of contents corresponding to the recorded part of the CD-R
- Skip/unskip commands

PMA limitation

■ Track max 99

■ SKIP-TRACK max 21 (between 6-10 Tracks)

■ SKIP-SECTIONS max 21

The PMA is limited to 99 data sets totally. Every track number, every skip or unskip command is counted as a data set. If there happens to be a power line interruption during record the data in the EEPROM will remain valid. On power return the EEPROM data will be copied into the PMA. The D740 indicates "WAIT" during this process. After the transfer has been completed recording may continue and a new track number will be set.

Before the CD-R is removed from the CD recorder, the latter automatically updates the PMA physically on the tracks reserved for this purpose which are located before the lead-in. For this purpose the data are stored in a RAM of the CD recorder. Only when the CD-R has been completely recorded are the lead-in and lead-out recorded by activating the FIX-UP function. Once this has been done, no further information can be recorded on the CD but the CD can now be played back on all CD players.

2.3.2 Analog recordings

Connection

Connect the source to the XLR inputs. Switch INPUT SELECT[26] to ANALOG. If the input sensitivity is to be adjusted manually, set the switch below the input potentiometers to UNCAL[32] and adjust the level for each channel with the level potentiometers.

Record ready

The recorder is ready for recording when an incompletely recorded CD-R is inserted and the RECORD[9] key is pressed. This status is signalled by the red flashing LED.

Level control

In record ready mode the input signal is available at the output after AD/DA conversion. The peak meter unit also measures the level at this point. The signal going to the CD-R can thus be monitored audibly as well as with measuring instruments. Overloads manifests itself audibly by crackling sounds. The optimum recording level is achieved if in loud runs (press PEAK RESET[20] repetitively) the right-hand LED of each channel lights up only momentarily on the peak indicator.

External synchronization

If a word clock signal (AES/EBU or SPDIF) is connected to the digital input is active during the power up (for example studio clock or synchronized by an external CD player), the CD-Recorder synchronizes to the external clock in record and play mode. While a recording is in progress with external clock synchronization, the connection should never be interrupted.

Record start

The D740 is ready for recording. The recording is started by pressing PLAY. Continuous light of the red LED indicates that information is physically recorded on the CD-R. The start of the recording can be delayed by up to 600 ms. The remaining capacity of the CD-R can be read out with DISPLAY [19] while the recording is in progress.

RECORDING STUDER D740

Title generation

Titles can be generated automatically or manually. With the toggle switch NEW TRACK[27] you can select between AUTO and MANUAL. In AUTO mode a new title is generated when the audio level remains below –60 dB for over 3 seconds. In MANUAL mode a new title is generated whenever NEXT[7] is pressed. The mode can be changed while a recording is in progress.

Record interruption

The recording operation can be interrupted with PAUSE[11] or STOP/CM[12].

Pause

Before the start of a new title, a pause with digital zero should be written for creating the title end mark 00. This is accomplished by pressing the REC MUTE[10] key. The pause is at least 2 seconds long and can be extended by one second with each additional depression of this key. If this key is not actuated for over 1 second, the recorder automatically starts to write the pause and switches to record ready.

Record continuation

If no pause is desired and an additional title is to be recorded, switch the unit to record ready by pressing the RECORD[9] key. In either case (with or without pause) a new title is automatically created. To start the record operation press the PLAY[8] key.

Stop recording - leave CD-R open for additional recording

If additional information is to be written on the CD-R, press LOAD[5]. The message **UPDATE** is displayed which confirms that the PMA (→2.3.1) has been recorded or updated. The CD can then be removed from the drawer.

Stop recording - close CD-R

When the CD-R has been completely recorded with the desired program, it can be closed by recording the TOC (\rightarrow 2.3). This is accomplished by pressing FIX-UP[31] and within two seconds also RECORD[9]. The display shows **FIX-UP**. This process takes approx. 3 minutes. The display shows the duration of the process.

2.3.3 Digital recordings

Digital connection

Because of the CD format direct recording is only possible with a sampling frequency of 44.1 kHz. For other sampling frequencies a converter must be connected. Connect the digital output of the audio source to the digital input of the recorder. On the rear panel set the selector switch (optical or CINCH/XLR input) to the appropriate position.

Caution:

Under no circumstances should the SPDIF and the DI(AES/EBU) input be used simultaneously!

Change to DIGITAL with the INPUT SELECT[26] toggle switch. If the recorder cannot be switched to DIGITAL, the word clock is missing. Some digital equipment assumes a defined operating state only after they have played a brief sequence. The recorder should subsequently be switchable to digital record mode.

Record ready

Insert a recordable CD-R. Switch the player to record ready by pressing RECORD[9]; the red LED above the RECORD key flashes. The start of the recording can be delayed by up to 600 ms. By pressing DISPLAY[19] the remaining recording capacity of the CD-R can be read out also while a recording is in progress.

E/24

STUDER D740 RECORDING

Record start

The player is in record ready mode. Press PLAY[8] to start the recording; however, the audio source should only be started when the red LED above the RECORD key is steady light. Only then will the CD-R be physically written.

Title generation

With the toggle switch NEW TRACK[27] the title generation can be switched between AUTO and MANUAL. If in the AUTO position a STUDER CD player is used as the source, the recorder copies the title changes automatically from the source CD. In the MANUAL position a new title can be set at any time by pressing NEXT[7]. The title generation mode can be changed also when a recording is in progress.

Record interruption

The recording operation can be interrupted with PAUSE[11] or STOP/CM[12].

Pause

Before the start of a new title, a pause with digital zero should be written for creating the title end mark 00. This is accomplished by pressing the REC MUTE[10] key. The pause is at least 2 seconds long and can be extended by one second with each additional depression of this key. If this key is not actuated for over 1 second, the recorder automatically starts to write the pause and switches to record ready.

Record continuation

If no pause is desired and an additional title is to be recorded, switch the unit to record ready by pressing the RECORD[9] key. In either case (with or without pause) a new title is automatically created. To start the record operation press the PLAY[8] key.

Stop recording leave CD-R open for additional recording

If additional information is to be written on the CD-R, press LOAD[5]. The message **UPDATE** is displayed which confirms that the PMA (\rightarrow 2.3.2) has been recorded or updated. The CD can then be removed from the drawer.

Stop recording - close CD-R

When the CD-R has been completely recorded with the desired program, it can be closed by recording the TOC (\rightarrow 2.3). This is accomplished by pressing FIX-UP[31] and within two seconds also RECORD[9]. This process takes approx. 3 minutes. The display shows the duration of the process.

2.3.4 SKIP / UNSKIP

The CD-R can only be recorded once. If for any reasons certain runs or complete titles have been recorded incorrectly, these can be bypassed by programming the SKIP function. With UNSKIP the corresponding SKIP points can be cancelled. There are two possibilities for programming SKIP and UNSKIP.

1. Skipping a complete title

Key STOP/CM	Display
TNO?	##
SKIP RECORD	TNO SKIP UPDATE

In STOP mode enter the title number to be skipped on the numeric keypad[21]. Activate the SKIP[28] command. If the wrong title has been entered, press STOP/CM[12] and repeat the procedure with the correct title number. RAM. The SKIP function is not executed until RECORD[9] is pressed. The SKIP data are initially stored in RAM. The PMA is updated when the CD is unloaded.

2. Skipping a run

Key Display PLAY A→B A→B A-→B Monitoring loop A→B SKIP SKIP **VERIFY** sĸ Monitoring to A -jump to B RECORD SKIP RECORD

Play-Modus

When A→B[30] is pressed the first time, the starting point A of the run to be skipped is defined. Pressing this key again defines the end point B. The run to be skipped between A and B can now be monitored as a loop by pressing SKIP[28]. Instead of the time the wording SKIP is displayed. Subsequently SKIP VERIFY is automatically activated. This status is confirmed on the display with VERIFY. The recorder plays the last 5 seconds before A, executes the SKIP function and then plays the first five seconds after B. This is confirmed on the display with SK. If the result is not satisfactory, enter the STOP/CM[12] command and repeat the procedure, otherwise press RECORD[9] to store the SKIP function.

Pause modus

Find the exact starting point A by pressing SEARCH REVERSE[15] or FORWARD[13]. When A→B[30] is pressed for the first time, A→ flashes in the display field. Press SEARCH REVERSE[15] or FORWARD[13] to define the end point B. The run to be skipped between A and B can be monitored as a loop by pressing PLAY[8]. The SKIP-Function is activated by pressing SKIP[28]. This status is confirmed on the display with VERIFY. The recorder plays the last 5 seconds before A, executes the SKIP function and then plays the first five seconds after B. This mode is confirmed on the display with SK. If the result is not satisfactory, point A and then point B can be changed as described above. To store the SKIP function press RECORD[9].(Fig. 2.4)

Key Display PAUSE 4 Þ A→B **A**→ A→B A→B Monitoring the Loop A→B SKIP SKIP VERIFY SK Monitoring to A - jump to B RECORD SKIP RECORD

Unskip

The UNSKIP function is used for cancelling a programmed SKIP. The programming is analogous to the SKIP function except that UNSKIP[30] is to be used rather than SKIP. The start and end points do not have to be defined exactly as long as the start point is before the skip start mark and the end point after the skip end mark.

Kev Display **PLAY** A→B A→ A→B A→B UNSKIP UNSKIP VERIFY USK Monitoring the Loop A→B SKIP ON USK RECORD **UNSKIP** RECORD

The skip/unskip function is only active on a CD recorder and cannot be executed on a conventional CD player.

RECORDING




Fig.2.5 Skip-function in pause-modus

REMOTE STUDER D740

2.4 Parallel remote control

1.328.660

This remote control can be used for the STUDER D740 CD recorder and D780 R-DAT recorder.

The remote control is operated similar as the equipment itself. This description is valid for factory setting of the jumpers. For further options please read the supplement to the remote control or the service instructions. The functions of missing stop key are controlled in the following way:

RECORD

Same functions as the record key on the D740 itself.

PLAY - RECORD

press RECORD – stop mode

TRANSITION

- press RECORD a second time - record ready mode

- press PLAY to start recording

RECORD - PLAY TRANSITION

press REVIEW to stop recording

- press PLAY - play mode

PAUSE

Pause command

PLAY

Play command

REC MUTE

Records a short segment with digital zeros, provided

the unit is in record or record ready mode.

NEW TRACK

Sets a new start ID in record mode.

REVIEW

Used for checking the starting point. REVIEW stops the

record mode.

FADER

Switches FADER READY on (LED is light)

Search backward

Search forward

PREVIOUS

Return to the start of the track.

NEXT

Spool to the start of the next track.

Connections

The remote control is hooked up to the D780 via the 25-pin D-type connector. All lines of the remote control are connected to a 26-pin flat cable connector. A fader start switch can be connected directly to the remote control (flat pin terminals P1 to P3).

STUDER D740 APPLICATIONS

3 Automated recording

Semiautomatic recording is possible via the parallel interface. The degree of automation depends on the source device and relates to the starting and stopping of the record function. Depending on the source unit also the titles are set. A feedback is given on the display.

3.1 Analog source units

Preparations

Before the start of the recording the source unit must be set up (refer to Section 2.3.2, page 18). The source unit should then be set to the start position of the recording.

Before a new title is recorded, a pause with digital zero should be written by creating a title end mark 00. This can be accomplished by pressing the REC MUTE[10] key. The pause is at least 2 seconds long and can be extended by one second with each additional depression of this key. If this key is not actuated for over 1 second, the recorder automatically starts to write the pause and switches to record ready.

STUDER Tape recorders (A807, A810, A812, A816, A820) Insert a CD-R into the D740 and switch to record standby mode by pressing RECORD[9]. Spool the tape on the source machine to the start position. Start the recording operation on the D740 by pressing PLAY[8]. As soon as the D740 physically writes on the D740, the tape recorder starts automatically if it is connected via the parallel interface according to the diagram below. When the recording is completed, press PAUSE[11] or STOP/CM[12] to interrupt the operation.




Fig. 3.1 Connection cable between the two parallel remote controls of the tape recorder to the D740.

APPLICATIONS STUDER D740

Turntables EMT938 EMT948

Insert a CD-R into the D740 and switch to record standby mode by pressing RECORD[9]. Move the phono cartridge to the starting position, taking into consideration the acceleration time of the turntable. Start the recording operation on the D740 by pressing PLAY[8]. As soon as the D740 physically writes on the D740, the turntable starts automatically if it is connected via the parallel interface according to the diagram below. When the recording is completed, press PAUSE[11] or STOP/CM[12] to interrupt the operation.




Fig. 3.2 Connection cable between the two parallel remote controls of the EMT 938 to the D740.




Fig. 3.3 Connection cable between the two parallel remote controls of the EMT 948 to the D740.

E/30

STUDER D740 APPLICATIONS

3.2 Digital source units

Before the start of the recording establish the AES/EBU connection as described in Section 2.3.3, page 19.

STUDER A730/D730/D731

Connect the A730 AUXILIARY port (or the D730/D731 parallel remote port) to the parallel remote port of the D740. Insert a CD-R into the D740 and switch to record standby mode by pressing RECORD[9]. Set the CD player to the starting position. Start the recording operation on the D740 by pressing PLAY[8]. As soon as the D740 physically writes on the CD-R, the source CD player gets started. Track changes are automatically accepted if NEW TRACK is in the AUTO position. When the recording is completed, press PAUSE[11] or STOP/CM[12] on the CD-Recorder to interrupt the operation. In AUTOPAUSE-Mode the recording will automatically be stopped at the end of the track or other wise on the end of the CD.




Fig. 3.4 Connection cable between the AUXILIARY port of the source CD player A730 and the CD-Recorder D740.




Fig. 3.5 Connection cable between the parallel remote port of the source CD player D730 /D731 and the CD-Recorder D740.

APPLICATIONS STUDER D740

STUDER A727

Connect the parallel remote ports. Insert a CD-R into the D740 and switch to record standby mode by pressing RECORD[9]. Set the source CD player to the starting position. Start the recording operation on the D740 by pressing PLAY[8]. As soon as the D740 physically writes on the CD-R, the source CD player gets started. Track changes are automatically accepted if NEW TRACK is in the AUTO position. When the recording is completed, press PAUSE[11] or STOP/CM[12] to interrupt the operation.




Fig. 3.6 Connection cable between the two parallel remote controls of the source CD player A727 and the CD-Recorder D740.

STUDER D780

Connect the two parallel remote ports with the following cable (Order-no. 1.629.691.00). Insert a CD-R into the D740 and switch to record standby mode by pressing RECORD[9]. Set the source R-DAT-Recorder D780 to the starting position. Start the recording operation on the D740 by pressing PLAY[8]. As soon as the D740 physically writes on the CD-R, the source R-DAT-Recorder D780 starts automatically. Track changes are automatically accepted if NEW TRACK is in the MANUAL position. When the recording is completed, press PAUSE[11] or STOP/CM[12] to interrupt the operation. If the END-ID ist set on the DAT-MAster, the recording stops automatically.




Fig. 3.7 Connection cable between the two parallel remote controls of the source R-DAT-Recorder D780 and the CD-Recorder D740.

E/32 EDITION: 24. September 1992

STUDER D740 APPLICATIONS

3.3 CD Multicopy station

Several STUDER D740 CD recorders can be connected to a D780 R-DAT recorder to build a multicopy station for CDRs. The DAT master tape controls the new track begins on the CD-R by means of the start IDs. The END ID stops all connected recorders.

Control cable

The control cable must be individually fabricated in accordance with the number of connected units. The integrated start key initiates the copy operation on all units. At the end of the copy operation an automatic stop is initiated by the END ID on the DAT master. The D780 cannot be operated while copying is in progress.




Fig. 3.8 Connection line with start key for a CD-R multicopy station with DAT master tape.

Audio connections

The digital output DIG OUT of the D780 is connected to the digital input DI of the first CD recorder. The latter's digital output DO is connected to the digital input of the second CD recorder, etc.

DAT player setup

- The D780 must output the START IDs on PIN 7 of the parallel remote socket. For this purpose DIP switch 8 on the main board must be "ON" (PNO COPY MODE).
- Fader start mode A must be set. After the start the operating functions are inhibited and the red ON AIR LED lights up.
- Sampling frequency of the master tape: 44.1 kHz. For other frequencies a digital sampling frequency converter must be used.
- START IDs should only be set half a second before the modulation start so that the track begins of the CD-R can be reproduced exactly on any ordinary CD player.
- Position the tape at the first start ID of the program in PAUSE mode.

CD recorder setup

- The NEW TRACK function must be set to MANUAL.
- Preselect the digital recording with [RECORD] and [PAUSE].

APPLICATIONS STUDER D740

Coordinated start

The start key on the control cable starts the recording on all connected CD recorders. As soon as these are ready to write the CD-R, the R-DAT recorder is started with a faderstart signal. The ON AIR LED lights up.

Terminating the process

- When the END ID is reached, the copy operation is stopped. All CD recorders switch to PAUSE, The D780 switches to STOP.
- If desired additional material can be copied to the CD-Rs still in the trays.
- When all audio material has been copied, the FIX UP is initiated on all CD recorders by pressing [STOP] [FIX UP] [RECORD].

E/34 EDITION: 21. September 1992

SERVICE

4 Service instructions

4.1 Work instructions

4.1.1 Test mode

Activating the test mode

Service level Display

While switching on the D740, simultaneously press the NEXT and PREVIOUS keys. The wording SERVICE is displayed. The play and record functions are inhibited. The test mode provides information on seven different functions. The service level is displayed in place of the track number, and the service information in the remaining part of the display.

0	SERVICE	Service function is active
1	hhhh:mm	Cumulative hours the laser unit has been operated in record mode.
2	hhhh:mm	Cumulative hours the laser unit has been operated in play mode
3	nn	OPC reset number
4	ERR NR	System error (see list below)
5	BURN-In	Burn-in test; caution! This service level is reserved for production. If this mode is inadvertently selected, it can be canceled by switching off the CD player while the tray is open. In this mode a blank CD-R can be automatically written with 99 tracks. After each track the tray is opened and closed in order to update the PMA after each track.
6	OPC CLR	Reset all OPC data. This function should only be performed after a new player mechanism has been installed. Pressing the CLEAR key resets the optimum power of the laser unit. At the same time the operating hours counter is reset to

zero and the OPC reset counter incremented by 1.

Description

These service levels can be selected with the NEXT or PREVIOUS keys. To quit the service mode press the STOP key.

In service level 4 of the service mode the following system errors are indicated. When PLAY is pressed in service level 4 the normal play mode is activated and if an error exists, the ERR nn (nn = error number) is displayed.

nn	Error description
02	Servo error
03	ATIP error
04	Subcode error
05	PMA error
06	TOC error
07	Disk info format error
08	OPC error
09	Linking error
11	Monitor error
13	Overwrite error

SERVICE STUDER D740

4.1.2 Electrostatically Sensitive Device "ESD"

Static electricity

In our daily activities numerous materials may be a possible source of static electricity. If certain circumstances are given, a person and the various things that are being handled may build up considerable static charges. When it comes to a discharge of such a static potential, very high peak power pulses may result. Even a small portion of such energy, when finding its way into an electronic component, will result in damage or even destruction of that component.

Handling of ESD-assemblies

It must be our aim, therefore, to protect our products from damages and fault conditions that may be the result of electrostatic discharges. Correct handling of electronic assemblies when performing service work on equipment is of utmost importance. For this the following safe handling procedures have to be observed:

- 1. Discharge your body by touching earth before picking up an electronic assembly.
- 2. Touch your partner first (handshake) before handing an assembly to him.
- 3. When handling complete PC-boards, make it your standard practice to hold them only at their edge or at their front panel.
- **4.** Never touch the conductive tracks, terminal points or components on a circuit board without having first discharged yourself.
- 5. Switch off the electric current supply to the equipment before removing or inserting an ESD assembly.
- 6. Always use ESD packaging for transportation or storage of ESD assemblies.
- 7. Make sure to use only tools that are approved for ESD work.
- 8. An earthed wrist-band is to be carried whenever performing any work on or with electronic assemblies, irrespective of whether they contain ESD or not.
- 9. Keep Styropor, PVC folis, plastic bags, etc. far away from ESD assemblies.

ESD-kit This kit consists of an earthed protective base (60 \times 70cm) with earthed wrist-band for any work with electronic assemblies. Part No. 20.020.001.44

E/J36

SERVICE

4.1.3

Conversion table for voltage levels: volt ↔ dBu

<u>U</u> 1	μV — mV —	—dBu	dBu	dBu	<u>U</u> 1	μV — mV — V —	—dBu	dBu	dBu
1 1,12 1,26 1,41 1,59 1,78 2,00 2,24 2,51 2,82	V — 0,775 0,87 0,98 1,09 1,23 1,38 1,55 1,73 1,95 2,18	±0 +1 +2 +3 +4 +5 +6 +7 +8 +9	-60 -59 -58 -57 -56 -55 -54 -53 -52 -51	-120 -119 -118 -117 -116 -115 -114 -113 -112 -111	31,6 35,5 39,8 44,7 50,1 56,2 63,1 70,8 79,4 89,1	24,5 27,5 30,8 34,6 38,8 43,6 48,9 54,8 61,5	+30 +31 +32 +33 +34 +35 +36 +37 +38 +39	-30 -29 -28 -27 -26 -25 -24 -23 -22 -21	-90 -89 -88 -87 -86 -85 -84 -83 -82 -81
3,16 3,55 3,98 4,47 5,01 5,62 6,31 7,08 7,94 8,91	2,45 2,75 3,08 3,46 3,88 4,36 4,89 5,48 6,15 6,90	+10 +11 +12 +13 +14 +15 +16 +17 +18 +19	-50 -49 -48 -47 -46 -45 -44 -43 -42 -41	-110 -109 -108 -107 -106 -105 -104 -103 -102 -101	100 112 126 141 159 178 200 224 251 282	77,5 86,9 97,5 109,4 122,8 137,7 154,5 173,4 194,6 218,3	+40 +41 +42 +43 +44 +45 +46 +47 +48 +49	-20 -19 -18 -17 -16 -15 -14 -13 -12	-80 -79 -78 -77 -76 -75 -74 -73 -72 -71
10,0 11,2 12,6 14,1 15,8 17,8 20,0 22,4 25,1 28,2	7,75 8,69 9,75 10,9 12,3 13,8 15,5 17,3 19,5 21,8	+20 +21 +22 +23 +24 +25 +26 +27 +28 +29	-40 -39 -38 -37 -36 -35 -34 -33 -32 -31	-100 -99 -98 -97 -96 -95 -94 -93 -92 -91	316 355 398 447 501 562 631 708 794 891	244,9 274,8 308,4 346,0 388,2 435,6 488,7 548,4 615,3 690,4	+50 +51 +52 +53 +54 +55 +56 +57 +58 +59	-10 -9 -8 -7 -6 -5 -4 -3 -2 -1	-70 -69 -68 -67 -66 -65 -64 -63 -62 -61
31,6	24,5	+30	-30	-90	1000	774,6	+60	±0	-60

The column with the bold figures contains voltage values. The next three columns give the corresponding decibel values when interpreting the voltages as Volt, millivolt, or microvolt. The first column specifies the voltage ratios that correspond to the dBu values relative to Volt.

This table is based on the definition $~0~dBu \,\cong\, 0.775 V_{\text{eff.}}.$

SERVICE STUDER D740

4.2 Disassembly

Security



The internal settings of this product should only be adjusted by trained personnel!

Appropriate safety precautions must be taken because hazardous laser radiation occurs during the service work.

DANGER!

Invisible laser radiation when open, avoid direct exposure to beam! Laser class 3 b when open.

- Disconnect the power plug before you disassemble the unit.
- Please refer to the handling instructions concerning electrostatically sensitive components "ESE" (4.1.3).

Removing the housing cover

- Unfasten the two countersunk hexagon-socket-head screws of both rack ears and remove the rack ears.
- Unfasten the fixing screws (cross-recessed screws) of the cover, two on the side and three on the top edge of the back. You can now slide off the cover toward the back.

Removing the control panel

- Pull out the tray, press in the clips on the outer right and left, and press the tray cover upward so that it can be removed.
- Remove the terminal strip (unfasten three hexagon-socket-head screws).
- Unfasten the upper two Torx screws of the control panel, detach the connector of the power-on switch and separate the connections to the phones as well as the level board, then pull off the control panel.

Reinstalling the control panel

- Plug the corresponding connectors into the control panel and insert it into the three guides on the chassis.
- Fasten the control panel on top with two Torx screws.
- Fasten the terminal strip with three hexagon-socket-head screws.

Exchanging the software EPROM

- Remove the control panel
- The EPROM is located on the encoder PCB.

Servo board

The servo board is fixed above the player mechanism by means of four Torx screws. To facilitate the service work, the servo board can be positioned upright by putting it into the corresponding holder. The connectors have different colors and are coded in such a way that they can only be inserted in the correct direction.

Removing the player mechanism

- Remove the cover and the control panel (see above)
- Remove the servo board.
- Unfasten the four Torx screws each on the player mechanism and the WOSP board connected to the player mechanism. Remove the assembly with appropriate care because the circuit board attached to the player mechanism contains components also on the solder side.

STUDER D740 SERVICE

Reinstalling the player mechanism

- Reinsert the cable harness in the rear guide.
- Carefully slide the assembly with the tray guide under the XLR board without injuring the bottom side of the player mechanism circuit board.
- The four long Torx screws are used for fixing the player mechanism, the other four for fixing the WOSP board.
- Establish the cable connections on the player mechanism board as well as the servo board. Insert the connectors into the socket of the same color and lock them.
- Fasten the servo board by means of four Torx screws.

Decoder PCB

The decoder board is fastened from the top with four Torx screws. In addition the two Torx screws on the back of the unit must be unfastened. For service purposes this assembly can be positioned upright in the right-hand holder.

Removing the XLR board

- Unfasten the hexagon nuts (key size 5) of the PARALLEL REMOTE on the rear panel.
- Unlock the XLR connectors by giving them a ccw 1/4 turn with a screwdriver size 00.
- Remove the transformer cover, unfasten the two lateral Torx screws.
- Unfasten two screws of the XLR board.
- Carefully slide the XLR board toward the housing front until the soldered XLR inserts protrude completely out of the connector housing. The XLR board can now be removed.

Reinstalling the XLR board

- Establish the plug connections.
- Insert the soldered XLR units into the connector housings and lock them with a 1/4 cw turn.
- Fasten the PARALLEL REMOTE connector with the two hexagon nuts.
- Secure the board by means of two Torx screws.
- Mount the transformer cover and secure it with the two lateral Torx screws.

Removing the rear panel

- Remove the XLR board.
- Remove the connector housings of the input left and output right
- Unfasten two Torx screws from the power supply heat sink (below the previously unfastened connector housings).
- Unfasten 5 Torx screws on the back, 3 screws each on the bottom and top of the rear panel; the rear panel can now be removed. To reinstall the rear panel perform the above steps in the reverse order.

Transformer unit

- Remove the XLR board.
- Unfasten the servo board.
- Detach the connector from the power supply and the power switch.
- Lightly shift the transformer unit forward and remove it.

Power supply unit

- Remove the XLR board.
- Remove the rear panel.
- Detach the connector, unfasten three Torx screws.
- The power supply unit can be lifted out.

To reinstall the power supply perform the above steps in the reverse order. Encoder PCB

This board can only be removed from the bottom of the unit. For this purpose remove the cover and the 4 Torx screws of the circuit board.

4.3 Circuit description

The circuit description is given in such a sequence that it agrees with the diagrams.

Transformer unit 1.629.609

This assembly comprises the power filter, transformer, primary and secondary wiring. The power filter contains the power cable inlet, the filter, two fuse holders, the voltage selector and the power switch contacts. The switch contact assignment applicable to your country can be found on page 11 of the diagram Section. The secondary transformer windings are built on two coil forms.

Winding	Voltage	Purpose
1 7,65 V		Digital AC supply
2	7,65 V	Digital AC supply
3	17,8 V	Analog AC supply
4	4,3 V	Display AC supply

The digital AC supply is split in order to achieve a balanced coil load and for mutual compensation of the noise fields. Resistors R1 and R2 protect the 4.3 V winding against secondary short circuits.




Fig. 4.1 Power supply block diagrams

STUDER D740 SERVICE

Power supply 1.629.620

The power supply comprises the current limiting resistors, voltage regulators for $\pm 9V$, $\pm 10~V$ and -5~V. Separate voltage regulators are available to the audio for $\pm 15~V$. A separate +5~V regulator each is used for the logic and the microprocessor. The display is supplied via an independent regulator. The power supply is also equipped with a voltage failure detector.




Fig.4.2 Servo block diagram

SERVICE STUDER D740




Fig.4.3 Servo block diagram

Servo board 3104.113.0005 Part No. 15.162.001

The servo board contains the following circuit elements: Servo microprocessor, radial control, error detection circuit, focus control, disc motor control and tray motor control.

The servo processor is responsible for signal management of the servo board. It obtains its commands from the main microprocessor. The radial control is responsible for automatic track following by means of two radial error signals. The failure detection circuit supplies the radial control with old values in the event of a control signal failure. The focus control is responsible for focusing the laser lens. The rotational speed of the compact disc is controlled in such a way that the data stream remains constant. In play mode the controlled variable is obtained from the EFM signal, in record mode from the modulated CDR wobble.

E/42 EDITION: 21. September 1992

SERVICE




Fig.4.4 WOSP block diagrams

WOSP

(write once signal processor) 15.162.000.00 (incl. CDM-14)

The WOSP is permanently connected to the player mechanism. The player mechanism/WOSP unit should not be disassembled because costly measuring instruments are required for alignment. The WOSP is responsible for producing the signals for the write unit.

STUDER D740




Fig.4.5 Encoder block diagram

Encoder PCB 3104.113.0085 Part No. 15.162.004

This module converts the signals from analog to digital and codes the digital data into a stream corresponding to the CD format (EFM coding). It also switches between the digital and analog input. This board also contains the level measuring circuit, the software EPROM as well as the microprocessor control and the circuits for the system clock.

STUDER D740 SERVICE




Fig.4.6 Decoder block diagram

DECODER PCB 3104.113.0007 Part No. 15.162.002

The serial, EFM-coded data stream is decoded into a 16-bit signal for the left-hand and right-hand channel. The digital output (SDIF and optical) and the analog cinch outputs are also arranged on this board.




Fig.4.7 XLR board block diagram

XLR board 1.629.630 The XLR board contains the transformer balancing and the level matching of the analog as well as digital inputs and outputs. The parallel interface is also located on the XLR board.

SERVICE STUDER D740

Level board 1.629.635 The level board is responsible for matching the analog input level. In the calibrated position the level of the analog signal is input to the A/D converter without further amplification. In the uncalibrated position the signal can be adjusted within the range of $-\times$ to cal+10 dB.




Fig.4.8 Block diagram of the operating and display unit

Operating and display unit 1.629.635

The commands entered via the keys are decoded, stored, and forwarded. The optical feedbacks to the display are also output by this unit.

BSDAC board 3104.113.90100 Part No. 15.162.003 Bitstream digital-to-analog converter.

Headphone board 3104.113.0009 Part No. 15.162.006 Headphones amplifier

4.4 Cleaning

When required

If OPC problems occur (OPC ERROR) or if the track change requires a long time before a signal is audible, the laser lens may be contaminated.

Cleaning

Remove the player mechanism according to the disassembly instructions (see 4.2). Unfasten the four Torx screws of the WOSP board and carefully remove the connector as well as the player mechanism. The write/read unit can be disconnected by pressing in four clips on the tray body. The lens is now freely accessible. It is made of plastic and should be carefully cleaned with a dry cotton swab perpendicularly to the direction of movement without applying pressure.

E/46 EDITION: 21. September 1992

STUDER D740 ALIGNMENT

4.5 Electrical alignments



The internal settings of this product should only be adjusted by trained personnel!

Appropriate safety precautions must be taken because hazardous laser radiation occurs during the service work.

DANGER!

Invisible laser radiation when open, avoid direct explosure to beam! Laser class 3 b when open.

4.5.1 Transformer unit

1.629.609

Check

Connect the transformer unit to a regulating transformer. Adjust the voltage in such a way that the primary voltage on pins 7 & 8 corresponds to the line voltage of your country (make this adjustment first!). The following voltages should be available at the multipin connector (GR 4):

Pin	Voltage
1&2	4,4 V ±10%
2&3	4,4 V ±10%
4&5	18,1 V ±10%
5&6	18,1 V ±10%
7&8	15,5 V ±10%
8&9	15,5 V ±10%

Possible faults

If these voltages are not available, first measure the primary voltage. If the voltage is zero, check the fuse of the regulating transformer and the transformer unit. If the fuses blow when power is applied, measure the primary no-load current. If the current exceeds 20 mA, there is probably a winding fault or a short circuit in the secondary side. Also check the fuse resistors R1 & R2 as well as the wiring of the transformer unit.

ALIGNMENT STUDER D740

4.5.2 Power supply

1.629.620.00

Precondition

■ Cathode ray oscilloscope (CRO) with second time base

Test

Connect the power supply to the transformer unit and the load board. Measure the following DC voltages to TP8 (GND):

TP1	-26,5 V ±1V
TP2	-15V ±0,5V
TP3	+15V ±0,5V
TP4	-10V ±0,25V
TP5	-9V ±0,25V
TP6	+9V ±0,25V
TP7	+5V ±0,25V
TP9	+5V ±0,25V
TP10	+10V ±0,25V
TP11	-5V ±0,25V
TP13	+20V unstab. ripple ±2V

Possible faults

- DC voltage missing: Check the voltage supplied by the regulator, UDC > 14V
- AC voltage missing: Measure before and after the current limiting resistors,
 UAC > 15 Vrms

4.5.3 XLR board

1.629.630

Level alignment of the analog inputs and outputs

The CD recorder is factory aligned to an analog level of +15 dBu at the input and output. This level can be adjusted inside the recorder. For this purpose the rack ears must first be unscrewed. After the two Torx screws have been unfastened on both sides of the recorder, the housing panel can be removed (Fig. 1.3). The XLR is easily recognizable in the rear part of the housing.

Output alignment

- Connect a millivoltmeter (load > 10 MΩ) to the analog output of the left-hand channel OUTPUT LEFT [64].
- Insert a test CD.
- Play the 1 kHz sine wave full level (digital headroom 0 dB).
- With the trimmer potentiometer R117 set the desired level (adjustable from +6 dBu to 24 dBu).
- Repeat this procedure analogously for the OUTPUT RIGHT [65], but align with the trimmer potentiometer R217 and measure on the right-hand output.

E/48

ALIGNMENT

4.5.4 Parallel remote; Jumper setting




Fig. 4.11 Jumpers and connections on the parallel remote

Keyboard 1.328.661

J2 Jumper J2 enables the NEXT key to set a new track in record mode (same function as on the D740):

Position P3/4:

"NEXT"is disabled in record mode

Position P4/5:

"NEXT"starts a new track in record mode

J3 Jumper J3 disables the "NEWTRACK" key.

Position P9/10:

NEWTRACK disabled.

Position P10/11:

NEWTRACK enabled.

J4 Jumper J4 all recording functions including RECMUTE and NEWTRACK

Position P6/7:

Record-Mode enabled

Position P7/8:

Record-Mode disabled

Supply Board 1.328.662

Jumper J1 selects, weather to use the internal or external voltage (10 ... 30V DC) to activate the faderstart.

Position P4/5:

external voltage for faderstart command

Position P5/6:

internal voltage for faderstart command. only a faderswitch is required to operate faderstart mode.

J2 Jumper J2 has to be set according to the equipment used.

Position P7/8:

D740. The faderReady-function is active.

Position P9/10:

D780. The faderReady-function depends on the

faderstart mode of the D780.

Bold: factory setting

ALIGNMENT STUDER D740

Aligning the commonmode rejection of the analog inputs The common-mode rejection can be aligned with the following measuring arrangement.




Fig. 4.10 Measuring arrangement for common-mode rejection

Alignment

- With the signal generator feed a 16 kHz, +15 dBm signal (4.355 Vrms), first to the left-hand input.
- Align the voltage on connector P5 between the contacts P5–1 (left-in) and P5–2 (left GND) to the minimum by means of C123. The minimal requirement for CMRR is > 60 dB at 16 kHz.
- Repeat the measurement for the right-hand channel with the same input signal but measure between P5-7 (right-in) and P5-6 (right GND). Align the measured voltage to the minimum with C223.

E/50 EDITION: 23. September 1992

STUDER D740 ALIGNMENT

Input alignment

Make sure the output has been aligned first.

- Set the input selector to ANALOG and the UNCAL toggle switch to the CAL position.
- With a millivoltmeter adjust the 1 kHz sine wave test generator to 0 dBu (balanced).
- Connect the left-hand input channel of the test generator to the INPUT LEFT [62].
- Connect the millivoltmeter to the OUTPUT LEFT [64].
- Insert a CD-R and press RECORD [9] to activate the record mode.
- With the trimmer potentiometer R140 align to a level of 0 dBu.
- Repeat this procedure analogously for the INPUT RIGHT [63], but align with trimmer potentiometer R240 and measure on the OUTPUT RIGHT [65].




Fig.4.9 XLR board, position of the trimmer potentiometers for output and input

ALIGNMENT STUDER D740

Connection of a faderstart switch to the remote control module

A faderstart switch can be connected directly to the remote control module. The supply voltage for faderstart switching can be from an internal or external source.

Faderstart with internal supply




Fig. 4.12 Connection of a faderstart switch to the remote control module.

Faderstart with external supply




Fig. 4.13 Connection of a faderstart switch and an external supply voltage to the remote control.

E/52 EDITION: 21. September 1992

5 Spare parts

	<u></u>			
POS.	UOM	PRODUCT - NO	NAME	
1	Stk	15.162.000.00	CDM-14 Diek-Drive with WOSP and Tray	į
2	Skt	15.162.001.00	Servo-Board	
3	Stk	15.162.002.00	Decoder Board	1
4	Stk	15.162.003.00	BS-DAC-Board	l
5	Stk	15.162.004.00	Encoder Board	İ
6	Stk	15.162.005.00	Keyboard	
7	Stk	15.162.006.00	Headphone PCB	l
8	Stk	15.162.007.00	Switch-Board	1
9	Stk	15.162.008.01	Decoder Conn 1150 (H1) to Var Headphone	
			Conn 1580 (D1)	8 Pin
10	Stk	15.162.008.02	XLR-Board Conn P5 (L27) to Level+Balance P1 (X27)	7 Pin
11	Stk	15.162.008.03	Encoder Conn 1400 (D4) to Decoder Conn 1230 (E4)	10 Pin
12	Stk	15.162.008.04	Encoder Conn 1500 (D5) to Decoder Conn 1090 (E5)	15 Pin
13	Stk	15.162.008.05	Servo Conn 1602 (W15) to Wosp Conn 1001 (S15)	7 Pin
14	Stk	15.162.008.06	Encoder Conn 1505 (L8) to Control+Display	
			Conn 1801 (E8)	7 Pin
15	Stk	15.162.008.07	Power Conn P2 (C9) to Control+Display Conn 1800 (P9)	7 Pin
16	Stk	15.162.008.08	Encoder Conn 1502 (P10) to Power Conn P1 (E10)	9 Pin
17	Stk	15.162.008.09	Encoder Conn 1503 (S11) to Servo Conn 1603 (E11)	9 Pin
18	Stk	15.162.008.10	Power Conn P3 (S13) to Servo Conn 1601 (P13)	9 Pin
19	Stk	15.162.008.11	Cable (P25-X25)	
20	Stk	15.162.008.12	Cable (E26-X26)	
21	Stk	15.162.008.13	Cable (D27-X27)	
22	Stk	15.162.008.14	Cable (D25-X25)	
23	Stk	15.162.008.15	Cable (E3-L3)	
24	Stk	15.162.008.16	Cable (A28-D28)	
25	Stk	15.162.008.17	Cable (A29-D29)	
26	Stk	15.162.008.18	Cable (W6-D6)	
27	Stk	15.162.008.19	Cable (W14-S14)	
28	Stk	15.162.008.20	Cable (E7-D7)	
29	Stk	15.162.008.21	Cable (W12-E12)	
30	Stk	15.162.009.00	Frontpanel Alu	
31	Stk	15.162.010.00	Cover	l
32	Stk	15.162.011.00	Rear Panel	ĺ
33	Stk	15.162.012.00	Cover for Disk Tray	
34	Stk	15.162.013.00	Tray Front	
35	Stk	15.162.014.00	Profile, Frame for Disk Tray	
36	Stk	15.162.015.00	Lifter Plate	
37	Stk	15.162.016.00	Disk Tray	
38	Stk	15.162.017.00	Loading Frame for Disk Tray	
39	Stk	15.162.018.00	Pressure Plate	
40	Stk	15.162.019.00	Pressure Ring	

EDITION: 24. September 1992

STUDER D740

POS.	иом	PRODUCT - NO	NAME					
41	Stk	15.162.020.00	Spring, Tension, for Disk Tray					
42	Stk	15.162.021.00	Compression Spring "140" for Disk Tray					
43	Stk	15.162.022.00	oam					
44	Stk	15.162.023.00	Compression Spring for Disk Tray					
45	Stk	15.162.024.00	Motor for Disk Tray					
46	Stk	15.162.025.00	Belt					
47	Stk	15.162.026.00	Lens Play/Rec					
48	Stk	15.162.027.00	Lens Cal/Uncal					
49	Stk	15.162.028.00	Window					
50	Stk	15.162.029.00	Button Unit Right					
51	Stk	15.162.030.00	Button Unit Left					
52	Stk	15.162.031.00	Plastic Front					
53	Stk	15.162.032.00	Key Cal/Uncal					
54	Stk	15.162.033.00	Key Power Switch					
55	Stk	15.162.034.00	Phones Knob					
56	Stk	15.162.035.00	Foot					
57	Stk	15.162.036.00	Feltring					
58	Stk	15.162.037.00	Pan Head Screw IS, M 3 × 8 CU					
59	Stk	15.162.038.00	Pan Head Screw 3 × 10 Black for Plastic					
60	Stk	15.162.039.00	Self Tapping Screw KS, 3.5 × 10 Black					
61	Stk	15.162.040.00	CS-Screw IS, M 3 × 6 Black for XLR Connector					
62	Stk	15.162.041.00	Button Unit Left					
63	Stk	15.162.042.00	Cooling Radiator					

E/54 EDITION: 21. September 1992


INDEX

A→B	
Activating the test mode	35
Aligning the common-mode rejection	50
Automated recording	
Automatou recording	20
OD MOTE ONCE DICC (CD, D)	2
CD WRITE ONCE DISC (CD-R)	
CD-R multicopy station	
Circuit description	40
Cleaning	46
•	
Decoder PCB	39 45
Digital connection	24
Encoder PCB	
Exchanging the software EPROM	38
External synchronization	
	_ ,
Fader start	01
FIX-UP	
Function indicators	18
Headphones	14
Input level	6
Input level	
Jumpers and connections on the parallel remo	te 51
Lead-in	22
Lead-out	22
Lead-outLevel board	22 46
Lead-out Level board Level control	22 46 23
Lead-outLevel boardLevel controlLevel controlLine voltage	22 46 23 14
Lead-out Level board Level control Line voltage Line voltage selector	22 46 23 14
Lead-outLevel boardLevel controlLevel controlLine voltage	22 46 23 14
Lead-out Level board Level control Line voltage Line voltage selector Loop	22 46 23 14 5
Lead-out Level board Level control Line voltage Line voltage selector Loop	22 46 23 14 5
Lead-out	22 46 23 14 5 20
Lead-out	22 46 23 14 5 20 14
Lead-out	22 46 23 14 5 20 14
Lead-out	22 46 23 14 5 20 14 7
Lead-out	22 46 23 14 5 20 20 7 23
Lead-out	22 46 23 14 5 20 20 7 23
Lead-out	22 46 23 14 5 20 23 23 8 24, 25
Lead-out	22 46 23 14 20 20 23 23 8 24, 25 22
Lead-out	22 46 23 14 20 23 23 8 24, 25 22 19
Lead-out	22 46 23 14 7 20 23 8 24, 25 22 19
Lead-out	22 46 23 14 7 23 8 24, 25 22 19 14
Lead-out	22 46 5 20 14 7 23 8 24, 25 22 19 14 14
Lead-out	22 46 5 20 14 7 23 8 24, 25 22 19 14 14
Lead-out. Level board. Level control Line voltage Line voltage selector. Loop. Operator controls. Output level. Overloads. Parallel interface. Pause. PCA area Playback. Power supply. Power switch Program Memory Area (PMA) Programming	22 46 5 20 14 7 23 8 24, 25 22 19 41 4, 23 20
Lead-out	22 46 5 20 14 7 23 8 24, 25 22 19 41 4, 23 20
Lead-out	22 46 23 14 5 20 23 23 8 24, 25 22 19 14 4, 23 14 4, 23
Lead-out. Level board	22 46 23 14 20 23 23 8 24, 25 22 19 41 4, 23 20 24, 25 24, 25
Lead-out. Level board	22 46 23 14 7 23 8 24, 25 22 19 41 4, 23 20 24, 25 24, 25 24, 25 23, 24
Lead-out. Level board	22 46 23 14 7 23 8 24, 25 22 19 41 4, 23 20 24, 25 24, 25 24, 25 24, 25 23, 24
Lead-out. Level board	22 46 23 14 7 23 8 24, 25 22 19 41 14 4, 23 20 24, 25 24, 25 24, 25 23, 24 23, 25 38
Lead-out. Level board	22 46 23 14 7 23 8 24, 25 22 19 41 14 4, 23 20 24, 25 24, 25 24, 25 23, 24 23, 25 38


Removing the control panel	.38
SCAN	.19 .38 .20 .35 .42 .21 .25 .25 .26 .20 .25 .36
Stop recording – leave CD–R open	22
Technical data of the CD-R (STUDER)	25 25
Voltage rating	5
Word clock	.24 .43
XLR board39,	45


Section 6 Circuit Diagrams

Disassambly Views Trayfront1
Front
Tray3
Cabinet4
Frontpanel5
Loading and CD Mechanism (CDM)6
Write Once Signal Processing (WOSP) CDM7
General Block Diagram D7408
Abbreviations of Signal Names9
Wiring Diagram10
Circuit Diagrams and PCB Layouts
Trafo Unit 1.629.60911
Mains Switch13
Power Supply 1.629.62015
Servo Board17
Write Once Signal Processing22
Encoder Board26
Level Detection Board28
Decoder Board32
BS DAC Board36
XLR Board 1.629.63039
Headphone Board44
Level Board 1.629.63545
Control and Display Board47
Parallel remote control 1.328.660.0049
Flowcharts of the Start up Procedure53
Faultfinding Diagnosis55
Replacing the CDM-Unit or the Encoder PCB55





DISASSEMBLY FRONT






DISASSEMBLY VIEWS CABINET






DISASSEMBLY LOADING + CDM





DISASSEMBLY WOSP CDM




SERVICE HINTS


In the set chip componens have been applied. For disassembly and assembly of chip components see the figure below.







BLOCKDIAGRAM



STUDER D740

ATT - Attenuation CA - Central Apperture Signal CAN - Central Apperture Signal Normalized CE - Chip Enable - CIRC EFM Chip Select **CECS** CEFS - CIRC EFM Frame Sync CEPB - CIRC EFM Pause Bit CERES - CIRC EFM Reset - CIRC EFM Register Select CERS - CIRC EFM Subcode Sync CESSY CL - Clock CLAB - Clock Signal Decoder-A to Filter-B CLK - System Clock Input CRI - Counter Reset Inhit CS - Chip Select D0 - 7 - Data Bus Bit 0 - 7 DA - Data DAAB - Data Signal Decoder-A to Filter-B DACK - Display Acknowledge DDIN - Display Data Input DDOUT - Display Data Output - Deemphasis Control DEC DEEM - Deemphasis DIIRO - Digital Input Interrupt Request DO - Drop Out - Digital Out Signal DOBM DPD - Digital Power Down DSEL - Display Select DSSY - Decoder Subcode Sync - Error Flag Decoder-A to Filter-B FFAB FFM - EFM Serial Data - Eight to Fourteen Modulation **EFMCLK** - Eight to Fourteen Modulation Detect EFMD FEN - Focus Error Normalized - In Focus Signal **FOCOK** FOCON - Focus On FSA - Forward Sense Diode Anode - Forward Sense Diode Cathode FSC FSO - Laser Power Set GND - Ground HF - High Frequency HFI - High Frequency Input - 3 Spot Push Pull Diode Current IA - 3 Spot Push Pull Diode Current IB1-2 - 3 Spot Push Pull Diode Current IC1-4 - CA Current To Remainder Part Of CA Processor IHF INSEL - Input Selector ΙR - Infrared Receiver Signal IWREF - Laser Writing Power Reference L/R - Left/Right Select - Laser Write/Non Read LASWR - Analog Level Left High LEVLH LEVLL - Analog Level Left Low LEVRH - Analog Level Right High LEVRL - Analog Level Right Low LSRON - Laser On - Interface Data Bit Clock LTCLK LTCNT0-1 - Interface Control LTDAT - Interface Databus LTEN - Interface Enable MC - Motor Control Signal MCK - Master Clock - Master Clock NOT MCKN MCSEL - Motor Control Select MERR - Motor Control Error Signal

- RAM Addressbus Bit 0 - 10

- Left Channel Analog Input

- Absorption Loop Switch

- Absorption Integrator

- Analog Power Down

- Actual Absorption

- Absorption Set

- Additional Mute

- Right Channel Analog Input

A0-10

AINL

AINT

ALFA

AM


APD

ALFA0


ALFALS

MREADY - Turntable Motor Ready - External Motor Control Input MSC MSTCK - Master Clock MUSB - Soft Mute Signal - Mute Signal MUTE - Output Level Convertor RX1 NFR POWOK - Laser Power OK - Normalized Push Pull Signal PPN QCL - Q-Channel Clock Signal QDA - Q-Channel Data Signal QRA - Q-channel Request Acknowledge - Riaht RADJ - Radial Gain Adjust - Radial Brake Inhibit RRI - µP Read Signal RD - RAM Databus Bit 0 - 7 **RD0 - 7** REGAIN - Radial Gain Current REN - Radial Error Normalized RGH - Radial Gain High RIRES - Radial Integrator Reset RISET - Radial Integrator Preset B.IFN - Badial Jump Fnable **RJGAIN** - Radial Jump Gain RJV1-7 - Radial Jump Voltage RLS - Radial Loop Switch RP - Radial Polarity RPDIV - Radial Polarity Divider RPS - Radial Polarity Select RST - Hard Reset RTL - Radial Track Loss RX1 - IEC Format Digital Audio Data Input (Coaxial Input) RX2 - IEC Format Digital Audio Data Input (Optical Input) RXD - Serial Data - Selection RX1 Or RX2 RXSEL SACK - Servo Acknowledge SCAB - Subcode Clock Decoder-A to Filter-B SCK Serial Clock (IS) - Shift/Bit Clock Audio Data SCK/BCK SCLK - Serial Output Data Clock SD0 - 1 Serial Data (IS) SDAB - Subcode Data Decoder-A to Filter-B SDAT - Servo Data SDATA - Serial Data Output - Serial Data Output Audio Databus SDO SETSY - Setting Sync Signal SLBS - Slide Begin Switch SLIN - Slide Inwards Pulse - Slide Servo Loopswitch SLLS SLOR/RKDAC - Slide Outwards Request/ADC Determination Radial Amplitude SLOUT - Slide Outwards Pulse - Shift Register Clock Motor Control SRCMC SRCRG - Shift Register Clock Radial Gain SRDAT - Shift Register Data SREQ - Servo Request SRST - Servo Reset SSEL - Source Select SWAB/SSM - Subcode Word/Start-Stop Motor Signal TLN - Trackloss Normalized TRIN - Tray In Switch TRMOT - Tray Motor Control TROUT - Tray Out Switch - IEC Format Digital Data Output TX TXD - Serial Clock TXOE - Reset - Subcode U Channel UCH UNLOCK - Indication VCO Frequency USYNC01 - Indication Start New Frame WPCS - Wobble Processor Chip Select - uP Write Signal WR WRLASER - Write Mode/Non Read Mode Laser - Word Select Signal WS WS/LRCK - Word Select Audio Data WSAB - Word Select Decoder-A to Filter-B WSBD - Word Select Filter-B to DAC XSYS - Oscillator Signal


WIRING DIAGRAM




TRAFO UNIT



TRAFO UNIT




MAINS SWITCH



POWER SUPPLY CIRCUIT DIAGRAM D35 A 1N4002 D22 🛆 1N4002 TO XLR BDARD VFTD GND P1 1_ MC 79 L 45 AC 1N4002 1000U >J1 1VFIL1 VFTD +15V P1 2 R64 470K Φ D19 A 1N4448 --15V P1 3 J1 3VFIL2 D23 1N4002 △ 1 C1 C60 C61 22N 2100U Δ D24 A D 1N4448 KILL P1 4 Δ GND P1 5_ GN14 中 DV4 D34 ¥1N4002 MCE ▼ D32 A 1N4448 Δ Δ R45 C35 C31 27K 22N 470 D4 K) 1N4002 +5V P1 6 DELAY 6 +20V P1 7 -1 V- 50130300REF 16 A 1.6A C7 =22N TO FDT S10 C32 ₽4700U DZ2 A GND P2 1_ GN15 D12 680E 1N4002 >^{J1 8} ⚠ R30 \triangle C20 年4700U DRST P2 2 GN1...TD...GN21 DF-STARPDINT-GND IC4 LM317SP VFTD P2 3 QTP10 KL P2 4 C13 22N DZ1 2.2A/80V _______ отр13 +5V P2 5_ D11 1N4002 J1 5 R37 VFIL1P2 6 D9 1N4002 🛆 VFIL2P2 7 250U C21 4700U TD SERVD S11 C17 . SYN INH SST FRQ LIM GND -9v P3 1_ C15 =22N R25 220E C30 C26 R35 +9V P3 2 R36 15K D18 T1N5822 D6 ⚠ 1N4002 Δ C27 C29 33N 390P Δ GND P3 3_ GN17 1N4002 **РТРЗ** △ IC3 LM337KC -10V P3 4_ +10V P3 5 C5 =22N \triangle GND P3 6 GN18 R5 680E Δ --5V P3 7 D7 A DH 1N4002 D3 D 1N4002 +5V P3 8 Q TP2 Q TP4 ____GND P3 9 GN19 C3 C3 C12 ₽ C4 1000 D14 1N4002 R20 1K5 0 03.04.91 DEN/MOR 1 23.8.91 3 47.10.91 2 12,09,91 Δ Δ D740-CD-RECORDER PAGE 1 OF 1 1.629.620.00 STUDER SUPPLY BOARD

POWER SUPPLY PANEL




ATTACH PROPERTY OF THE SECOND SECTION FOR THE SECOND PROPERTY OF THE

	Ad POS	REF.No	OESCRIPTION	MANU FACTURER	Ad .	. POS	REF.No	DESCRIPTION				MANUFACTURES
	C1 C2 C3 C4 C5 C6 C6	59.99.1706 59.99.1709 59.06.0223 59.22.5101 59.06.0223 59.22.5101 59.06.0223 59.22.5101 59.06.0223	470u +/-20 *, 1000u +/-20 *, 22n 10 *, 100u -20/+50 *, 22n 10 *, 100u -20/+50 *, 22n 10 *, 100u -20/+50 *, 22n 10 *, 100u -20/+50 *, 22n 10 *,	50V 50V 63Y 25V 63Y 25V 63Y 25V 63Y	P. 000	13457	54.99.0231 50.03.0407 50.03.0407 50.03.0407 50.03.0601 50.03.0407	9-P 8C550C BC550C BC550C BC560C 8C550C	STR., NPN, NPN, NPN, PNP, NPN,	T092-1 T092-1 T092-1 T092-1 T092-1 T092-1	P-STOCKO,	WHITE
	C10 C12 C13 C14	59.22.5101 59.06.0223 59.22.5101 59.06.0223 59.22.5101 59.06.0223	22n 10 %, 100u -20/+50 %, 22n 10 %, 100u -20/+50 %, 100u -20/+50 %, 22n 10 %, 100u -20/+50 %,	25V 63V 25V 63V 25V 63V	R R R R	5 6 7 8	57.11.3392 57.11.3681 57.11.3682 57.11.3152 57.11.3682 57.11.3681	3 k9 680E 6 k8 1 k5 6 k8 680E	1 %, 1 %, 1 %, 1 %, 1 %,	0.6W, 0.6W, 0.6W, 0.6W, 0.6W,	MF MF MF MF	
	C16 C17 C18 C19 C20	59.22.5101 59.06.0223 59.99.1708 59.06.0104 59.99.1707	22n 10 %, 1000u +/-20 %, 100n 10 %, 4700u +/-20 %,	25Y 63Y 35V 63Y 50Y	R R R R R	11 12 13 14 15 16	57.11.3221 57.11.3101 57.11.3221 57.11.3101 57.11.3101 57.11.3102 57.11.3101	220E 100E 220E 100E 100E 1k 100E	1 %, 1 %, 1 %, 1 %, 1 %,	0.6W, 0.6W, 0.6W, 0.6W, 0.6W, 0.6W,	MF MF MF MF MF	
	C22 C23 C24 C25 C26 C27	59.99.1707 59.99.2705 59.06.0474 59.22.8229 59.06.0222 59.06.0333 59.99.1709 59.34.5391	4700u +/-20 %, 100u +/-20 %, 470n 10 %, 2u2 -20/+50 %, 2n2 10 %, 33n 10 %, 1000u +/-20 %.	50V 50V 63V 50V 63V 63V 50V	R R R R R R	20 21 22 24 25	57.11.3101 57.11.3152 57.11.3101 57.11.3102 57.11.3563 57.11.3221 57.11.3681	100E 1k5 100E 1k 56k 220E 680E	1 %, 1 %, 1 %, 1 %, 1 %, 1 %, 60V,	0.6W, 0.6W, 0.6W, 0.6W, 0.6W, 0.6W,	MF MF MF MF MF	
	C30 C31 C32 C33 C34	59.06.0104 59.22.4470 59.99.1707 59.99.1707 59.99.1709	390p 5 %, 100n 10 %, 47u -20/+50 %, 4700u +/-20 %, 4700u +/-20 %, 1000u +/-20 %, 22n 10 %,	63Y 63Y 16Y 50Y 50Y 50Y	R R R R	27	57.92.7020 57.92.7020 57.92.7016 57.92.7016 57.92.7016 57.11.3472 57.11.5565 57.11.3473	0.75A 0.75A 0.75A 1.6A 1.6A 4k7 5M6	50V, 50V,	R-PTC R-PTC R-PTC R-PTC		
	C35 C36 C60 C61 C62	59.06.0223 59.22.8479 59.06.0223 59.99.2705 59.22.8229	22n 10 %, 4u7 -20/+50 %, 22n 10 %, 100u +/-20 %, 2u2 -20/+50 %, 1N4004 D041,REC	50V 63V 50V 50V	A A A A	33 34 35 36 37 38	57.11.3473 57.11.3104 57.11.3104 57.11.3153 57.11.3103 57.11.3103 57.11.3392 57.11.3000	47k 100k 4k3 15k 10k 3k9 0E	1 %, 5 %, 1 %, 1 %, 1 %, 1 %, 1 %,	0.6W, 0.6W, 0.6W, 0.6W, 0.6W, 0.6W,	MF MF MF MF MF MF	
	01 02 03 04 05 06 07 08	50.04.0105 50.04.0105 50.04.0105 50.04.0105 50.04.0105 50.04.0105 50.04.0105 50.04.0105	1M4004 0041,REC1 1M4004 0041,REC1 1M4004 0041,REC1 1M4004 0041,REC1 1M4004 0041,REC1 1M4004 0041,REC1 1M4004 0041,REC1 1M4004 0041,REC1 1M4004 0041,REC1 1M4004 0041,REC1	IFIER IFIER IFIER IFIER IFIER IFIER IFIER IFIER	02	41 42 43 44 45 46 46	57.11.3103 57.11.3154 57.11.3103 57.11.3223 57.11.3223 57.11.3223 57.11.3222 57.11.3223	10k 150k 10k 22k 27k 22k 2k2 2k2	1 %, 1 %, 1 %, 1 %, 1 %, 1 %,	0.6M, 0.6M, 0.6M, 0.6M, 0.6M, 0.6M,	MF MF	
-	011 012 013 014 015 016 017	50.04.0105 50.04.0105 50.04.0125 50.04.0519 50.04.0125	1N4004 D041, REC 1N4004 D041, REC 1N4004 D041, REC 1N4004 0041, REC 1N4004 0041, REC 1N4004 0041, REC 1N4048 D035, REC 1N5822 SCHOTTKY 1N4448 D035, REC	CIFIER CIFIER CIFIER CIFIER CIFIER CIFIER CIFIER CIFIER CIFIER CIFIER	03 I 03 I 01 I	864 865 866 867 868	57.11.3474 57.11.3223 00.00.0000 00.00.0000 57.92.7020 50.10.0120 54.02.0320	1-P	STR	0.6W, 0.6W, R-PTC -15V. RI	ĦF	2.8*0.8
	020 021 022 023 033 033	50.04.0105 50.04.0105 50.04.0105 50.04.0125 50.04.0125 50.04.0125 50.04.0125 50.04.0125	1N4004 D041,REC 1N4004 D041,REC 1N4004 D041,REC 1N4004 D041,REC 1N4448 D035,REC 1N4448 D035,REC 1N4448 D041,REC 1N4004 D041,REC	TIFIER TIFIER TIFIER TIFIER TIFIER TIFIER TIFIER TIFIER TIFIER		FP2 FP3 FP4 FP5 FP6 FP7 FP8 FP9 FP9	54.02.0320 54.02.0320 54.02.0320 54.02.0320 54.02.0320 54.02.0320 54.02.0320 54.02.0320	1-P 1-P 1-P 1-P 1-P 1-P 1-P 1-P	STR., STR., STR., STR., STR., STR., STR., STR., STR.,	MALE, MALE, MALE, MALE, MALE, MALE	FLATPIN FLATPIN FLATPIN FLATPIN FLATPIN FLATPIN	2.8*0.8 2.8*0.8 2.8*0.8 2.8*0.8 2.8*0.8 2.8*0.8 2.8*0.8
	0V2 0V2 0V3	50.04.1215 50.04.1101 50.04.1123 50.04.1117	9.1V 5 %, 3.9V 5 %, 4.7V 5 %, 12 V 5 %,	1.3W, 0041, ZENER 0.5W, 0035, ZENER 0.5W, 0035, ZENER 0.5W, 0035, ZENER	ENO	TP11 TP12 TP13	54.02.0320 54.02.0320 54.02.0320	1-P 1-P 1-P	STR., STR., STR.,	MALE MALE MALE	FLATPIN FLATPIN FLATPIN	2.8*0.8 2.8*0.8 2.8*0.8
	0Z 0Z 1C 1C 1C 1C 1C 1C 1C	70.01.0236 2 50.10.0105 3 50.10.0105 4 50.10.0104 5 50.10.0104 5 50.10.0104 7 50.10.0105 5 50.10.0105 9 50.10.0115	2.2A C3700, 3.3A C3700, 3.3K T0220-9, SE H3337KC T0220-9, SE H3115P T0220, SE H3115P T0220, SE H3137KC T0220-9, SE H3337KC T0220-9, SE H3337KC T0220-9, SE L296 SILX158, PK	80V, BRIOGE RECTIFIER 80V, BRIOGE RECTIFIER R. REG1 R. REG1 RIC-REG. +1 RIC-REG. +1 RIC-REG. +1 R. REG1 R. REG1 MER SMITCHIMG REGUL. VOLITAGE REGULATOR				ic, PETP≖Polyes: SUPPLY 80ARD 0			MF=Metalfi 0R91/10/17	
	J	1 54.99.0234	9-P STR.,	MALE, P-RFK-PLUG, GREY								
	L L	2 62.03.0015		ROIDAL CHOKE ROIOAL CHOKE								
	MP MP MP MP MP MP MP	2 1.629.620.10 3 1.629.620.10 43.01.0108 5 1.629.620.01 6 21.46.0354 7 37.01.0101 8 50.20.0318 9 50.20.2006 21.48.0356	1 pcs EMPTY Pc 1 pcs MUMBER 1 1 pcs ESE WARI 1 pcs HEATSIN 1 pcs SCREM M: 1 pcs PRESSURI 6 pcs MICA 1SI 6 pcs SPRING 3 2 pcs SCREM M:	FOR LM 317-337 8 8 8EL ING LABEL FOR LM 293 6 TORX RING LATOR 111 1 10 TORX								
	P P P	1 54.99.0239 2 54.99.0230	2 pcs RING 7-P STR., 7-P STR., 9-P STR.,	MALE, P-STOCKO, BLACK MALE, P-STOCKO, WHITE MALE, P-STOCKO, BLACK								


SERVO CIRCUIT DIAGRAM (SERVO-1) COMMEN, 1600 TO COMMEN 1802 ON MOSP CIRCUIT SERVO - 1 DISC MOTOR CONTROL MOTOR ON/OFF DETECTION LPF FOCUS SERVO CONTROL PRESET CONTROL TRAY MOTOR CONTROL RADIAL POLARITY TRACK JUMP COUNTER 3104 118 000526-A 9144

SERVO CIRCUIT DIAGRAM (SERVO-1)


SERVO PANEL COMPONENT SIDE




	,										
C2502 C2520 C2520 C2526 C2526 C2620 C2620 C2620 C2640 C2640 C2641 C2666 C2668 C2669 C2770 C2751 C2751 C2752 C2770 C2795 C2830 D6531 D6531 D6530 D6581 D6562 D6660 D6681 D6662 D6660 D6681 D6741 D6750 D6791 D6790 D6871 D6791 D6792 D6833 D6881 D6881 D6741 D6751 D6790 D6871 D6970 D6871 D6970 D6871 D6970 D6871 D6970 D6971 D6970 D6971 D6970 D6971 D6970 D6971 D6970 D6971 D6970 D6971	G6 E10 D10 E12 G10 F3 C12 F3 C7 D4 C11 E4 B6 C5 D6 C4 E9 C10 B10 B10 C12 D13 C12 D13 C12 D13 C13 D13 C13 D13 C13 C12 D13 C13 C12 C11 C11 F4 D12 E13 B11 E9 C7 F9 F10 F11 E19 F10 F11 E9	J9017 J9018 J9019 J9020 J9021 J9022 J9023 J9024 J9026 J9026 J9027 J9033 J9031 J9033 J9033 J9034 J9035 J9036 J9036 J9037 J9038 J9039 J9030 J9031 J9039 J9030 J9031 J9032 J9038 J9039 J9030 J9031 J9038 J9039 J9040 J9041 J9043 J9044 J9043 J9044 J9045 J9048 J9059 J9060 J9060 J9061 J9066 J9066 J9066 J9066 J9066 J9066 J9066 J9066 J9066 J9066 J9066 J9067 J9068 J9070 J9071 J9073 J9074 J9073 J9077 J9078 J9076 J9076 J9076 J9076 J9076 J9077 J9078 J9078 J9088 J9088 J9088	E3 F11 E10 B12 D11 E10 B12 D11 F12 E11 F13 F3 F4 D10 C3 E3 E3 E3 E3 E3 E3 E3 E3 E4 E5 E8 E8 E8 E8 E8 E8 E8 E8 E8 E8 E8 E8 E8	K1520 K1521 K1522 K1521 K1522 K1600 K1601 K1603 K1603 K1603 K1600 K1700 L1500 Q7502 Q7540 Q7542 Q7540 Q7542 Q7580 Q7581 Q7582 Q7641 Q7642 Q7730 Q7731 Q7731 Q7730 Q7731 Q7731 Q7730 Q7731 Q7740 Q7731 Q7750 Q7771 Q7811 Q7850 Q7752 R3503 R3501 R3501 R3502 R3503 R3501 R3504 R3506 R3501 R3501 R3506 R3501 R3501 R3502 R3503 R3504 R3508 R3509 R3511 R3512 R3523 R3524 R3528 R3529 R3521 R3522 R3523 R3524 R3522 R3523 R3524 R3522 R3523 R3524 R3522 R3523 R3524 R3522 R3523 R3524 R3522 R3523 R3524 R3522 R3523 R3524 R3522 R3523 R3524 R3523 R3524 R3523 R3524 R3523 R3524 R3528 R3529 R3531 R3544 R3550	C13 B133 D14 D3 D12 D2 E19 E10 C10 E9 B10 C10 E9 B10 C10 E9 B10 C10 C10 E9 B10 C10 C10 E9 B10 C4 B10 B10 B10 B10 B10 B10 B10 B10 B10 B10	R3551 R3560 R3562 R3563 R3564 R3565 R3566 R3567 R3568 R3569 R3577 R3577 R3577 R3578 R3580 R3581	D10 E9 C9 C9 C9 B9 B8 C8 C8 C8 C9 D10 D10 D10 E7 D9 C9 C10 D10 E7 D9 C10 B10 B11 E13 D12 D13 C12 D12 E12 D13 C12 E12 E12 E12 E12 E12 E12 E12 E12 E12 E	R3650 R3651 R3652 R3663 R3664 R36657 R3658 R3669 R3681 R3686 R3686 R3686 R3687 R3688 R3695 R3691 R3692 R3693 R3694 R3692 R3711 R37710 R3711 R3713 R3714 R3740 R3741 R3755 R3766 R3757 R3777 R3778 R3777 R3778 R3777 R37778 R3777 R37778 R37778 R37779 R37779 R37799 R3799	E2 E3 F2 E3 D3 E7 E13 F13 F13 G13 G13 G13 G12 G13 G12 G12 F12 F12 F12 F12 F12 F13 F14 F15 F17 D7 D7 D7 D7 D7 D7 D7 D7 D7 D7 D8 D7 D7 D7 D7 D7 D7 D7 D7 D7 D7 D7 D7 D7	R3800 R3801 R3810 R3811 R3813 R3814 R3815 R3832 R3833 R3834 R3835 R3835 R3851 R3855 R3855 R3856 R3855 R3856 R3857 R3858 R3859 R3861 R3862 R3861 R3862 R3863 R3864 R3865 R3866 R3867 R3867 R3877 R3871 R3872 R3878 R3878 R3878	F8 F9 E8 C6 E7 E6 E9 D5 C5 C5 C5 B5 B7 E5 C6 B7 B8 B8 B8 C7 B12 B12 B12 B12 B6 C6 B5 B5




SERVO PANEL SOLDER SIDE




SERVO CIRCUIT DIAGRAM (SERVO-2)



WOSP CIRCUIT DIAGRAM (WOSP-1)



WOSP PANEL SOLDER SIDE



WOSP PANEL COMPONENT SIDE 3060 C8 3061 C7 3063 C8 3064 B10 3065 B8 3100 E4 3102 E5 3104 D5 3105 C5 3106 C6 3107 C6 3108 B7 3109 C6 3111 B7 3111 C6 7038 CB 7039 DB 7039 DB 7041 CB 7042 CB 7043 CB 7044 DB 7045 DB 7046 DB 7046 CB 7101 E4 7102 C6 7104 C5 7105 B6 7105 B3 7107 B4 3113 C6 3114 D2 3115 B2 3115 B3 3116 B3 3117 B5 3117 B5 3119 C7 3121 B3 3124 C2 3124 B4 3129 B4 3129 B4 3129 B4 3129 B4 3129 B4 3129 B4 3130 B4 7005 E7 70007 E8 70007 E8 70201 D6 70221 D7 7024 D6 7022 D7 7024 D6 7027 D8 7027 D8 7031 D9 7033 C9 7033 C9 7033 C9 7033 C7 7035 D7 2120 B5 2121 BC6 2122 E6 2180 E2 22180 F2 22184 F2 22184 F2 22184 F2 22187 E2 22187 E2 22189 E1 22190 E1 22131 E2 22214 B8 22214 3041 D9 3043 D9 3044 D9 3044 D9 3045 C9 3046 B9 3047 C9 3048 C10 3050 C10 3051 C7 3053 C7 3053 B7 3055 B8 3057 C8 3057 C8 3057 C8 2101 B5 2102 B5 2103 C6 2104 C6 2105 B7 2106 B5 2107 B6 2108 D4 2110 D7 2111 C7 2111 C7 2113 B3 2114 B3 2115 B4 2116 B3 2118 B4 2119 B3 3021 E10 3022 E7 3023 E6 3024 E7 3025 D6 3029 C10 3031 B10 3032 D9 3034 D8 3036 D8 3036 D8 3037 D8 3038 D8 3038 D8 3038 D8 3133 A3 3140 C55 3140 C55 3142 C5 11 10 6 5 1 = MONITOR 2 = 0 MO ASER - 5 = MEAO ER - 6 = MEAO - 6 = MEAO - 7 = FSA - 8 = FSC - 9 = GUARD - 10 = NENC - 11 = GND - 12 = IC1 - 14 = GND 15 = NENS -16 = GND -17 = GND -18 = IA2 -19 = IA1 -20 = IB2 -21 = IB1 -22 = IC3 -23 = IC2 -24 = SUBSTRATE -25 = RACT--26 = FACT--27 = FACT--28 = RACT-1001 - 1 = LSRON - 2 = FEN - 3 = TLN - 4 = REN - 5 = GND - 6 = REGAIN - 7 = CAN (-10V) 210 210 2115 210 210 2115 211 2112 2122 14 14 8 5130 219 1002 +10V 1 = RACT-2 = FACT+ 3 = FACT-4 = RACTY-5 = RAD ADJ 6 = GND 7 = -10V 8 = +10V 9 = GND 10 = -5V 11 = +5V -----(+10V) 1004 22740 - 22730 -1 = HF 2 = GND 3 = HFD 4 = GND (380) 6029 (329) -10V 22740 - 22740 - 20240 -2101 **□** (BAD) 2106 **←** - - [3160]-3141 3140 r [3064] 1 3161 3107 S 3047 3045 3045 98 2062 S 98 2063 --- [3119] --72 3063 2076 3064 (+5V) 2122 2253 Ananocanan 6108 2122 (-10V) ⊷ - -[32<u>1</u>5]- - → 7105 200 3254 2252 20478 2035 (SV) **---**3219}---**OUR DESCRIPTION** 6256 2262 3260 (+10V) 5V +10V -13026] 3263 [2263] **←** − −[3<u>1</u>94] → + **→** 9203 M PROE 218841-3278 2266 -[3192]---(-10V) 3276 3272 +10V -- [3195]---1 = EFM 2 = GND 3 = EFMCLK 4 = GND 5 = PPN 6 = ALFAD 7 = ALFALS 9 = GND 10 = RRIN 11 = TROUT 12 = POWOK 13 = EFMD 14 = GND 15 = ALFA 16 = LASWR 3280 2264 3273 -[3026] 7181 8 +5V) 3277 _ (2180) 3191 3190 2010 .5002 -- ZIO 25 ... 5001 -- 25 ... 5 ---------,mmi ,mm, 7 7003 18 8 7003 18 7 7004 g 7005 - 6001M - - • (+5V) (±5V) (+5V) (+5V) 7 7006 7001 ⊷ - -[3[86]-- → -10V 2181 2186 ---7 7002 19 # 4 # 4 | (8) | (8) | | (8) | (8) | ---3<u>0</u>06---3187 +5V 2002 (+5V)

WOSP CIRCUIT DIAGRAM (WOSP-2) 1001 i.e. 1001 i WOSP-2 WOSP - 2 LESCON FEBRUARY CAN PERSON TITLE STATE OF THE ALFA ALFA0 - Actual Absorption - Absorption Set /RINTON ASEL - CA Current Select Can Current Select Central Apperture Low Frequency Central Apperture Low Frequency Normalized Central Apperture Normalized Focus Actuator CALFN CAN FACT+ FEN FSA FSO Focus Actuator Focus Error Normalized Forward Sence Diode Anode Forward Sense Diode Reference Current HFSEL IB1-2 IC1-4 IHF IMON Select CA Current For HF Reading Purposes Spot Push Pull Diode Current (X) MAG - 3 Spot Push Pull Diode Current - CA Current To Remainder Part Of CA Processor - Monitor Current Monitor Current Laser Writing Power Reference Laser On Enable All Photodiode Currents To Normalizer Enable Central Photodiode Currents To Normalizer Enable Satellite Photodiode Currents To Normalizer IWREF LSRON NEN NENC 100 NENS Enable Satellite Photodiode C Normalized Push Pull Signal Radial Actuator Radial Gain Current Normalized Radial Error PPN RACT+ g a REGAIN REN RINTON 2 Read Integrator On Read Integrator Reset Read/Non Write Laserpower 705 7 208 10 3119 298 9 +10A V 7047 B 8 80532 7047 A ME532 7106 D MC3486 RWLASER TLN WINTON - Trackloss Normalized - Write Integrator On 3112 16 IS1 WINTRES WLINTON - Write Integrator Reset - Write Integrator On TLS 71.06 C MC1484 *5 - CMX +10A 7106 A 617 3114 619 619 616 617 19118 19118 19118 19118 7106 B MC5484 _1007.1 1107.2 3142 3133 - 10a 1007.4 _1007.6 Can's close to: 7185 7184 7181 _1007.7 1507.6 _1007.9 MODERALITIES / CA MULTIPLECES


and with a part of the contract #### **ENCODER CIRCUIT DIAGRAM (ENCODER-1)** ENCODER - 1 2222222 8 8 8 8 8 8 8 8 7481 27C010 (FROM 3514) LASWR 1504 - 16 LASWR 100g 3494 - 170 1505-3514 RC5) 1423-1 PF6 53 A6 PF1 52 A7 RC5) 1423-2 RC5) 1423-3 -Dx 3498 PB1 50 A9 PB2 49 A10 EPROM RC5) 1423-4 sc5 = 1425-3 Vba 3485 22kl FB3 48 All DACK = 1505-2 DACK DCLS == 1505=3 DCLK (FROM 3492 CPU Vba ► 1k GRD == 1505-4 (70 1488-4) POWOK 1504-12 POWOK (FROM 1505-2) DOIN = 1505-5 DOIN BCLX → 100E, (TO 1505-3) DECUT = 1505-6 - DECUT 100N - 100R (to 1505-6) CHRON PERO. +5 = 1500-15 +5 2489 T 7482 228 T 728C64 228 T 728C64 ATT → TK GND = 1500-14 MUTE - 1 (20 1504 - 8) 3455 E (TO 7482-20) 1500-11 DEFS RAM 8X MOTE = 1500-12 MOTE (FROM 34.85) REPROM BIPH - 1525 10 1500-141 DSSY = 1500-7 DSSY | TO 1510 92 1EVIL (FROM 3771) LEVSH (FROM 3768) LEVRL (FROM 3716) 1018 (1873/20-40) 1073/20-31) 1073/20-31) 2 \(\Delta \) 1033 3552 (1873/20-34) 2 \(\Delta \) 1033 3552 (1873/20-34) 15 \(\Delta \) 1033 3553 (1873/20-34) 16 \(\Delta \) 1033 3503 (1873/20-35) (RA = 1500-8 (RA (FROM) SYNCHRO -2498 618 FS0 == 1504-8 = FS0 (FROM 3519) 3504 1491 10k M:34084 (FROM 3503) QCL = 1500-4 QCL 7491 NC34084 1504-7 (FEOM 3519) ALFALS 41504-7 ALFALS (FROM 3515) 1500 - 5 GND 3528 - 1k SSD = 1504+14 OF (FROM 3520) EMPH 1500-10 BMPH 3523 ALFA0 ALFA0 (FROM 3484) 3531 ALFA (FROM 3634) ALFA (FROM 3632) 3538 820k GNO = 1504-9 GND = 1584-4 13 12 3535 20k WR (TO 7370-14) GMD = 1504-2 RILL = 1501-2 RILL -15 = 1501-3 -15 G80 == 1501-4 7452 LM833 (TO 1503-9) CRI 1500-2 □ CRI +15 = 1501-5 +15 DEMODULATION CIRCUIT (TO 1503-8) AM = 1500 - 3 SSEL = 1501-6 | SSEL | ##6# 1521 1500 - 9 MSC RAM 1503 - 1 ____ ween SREQ = 1503-3 | SREQ (FROM 3444) SACK = 1503-4 SACK TIMING SDAT = 1503-6 SDAT (PROM 3456) SRST = 1503-7 SRST (FROM 3447) (PEOK 1500-3)


ENCODER CIRCUIT DIAGRAM (ENCODER-1)




ENCODER CIRCUIT DIAGRAM (ENCODER-2)

LEVEL DETECTION CIRCUIT DIAGRAM






ENCODER PANEL COMPONENT SIDE 3769 E3 3771 D3 3771 D3 3772 D5 3773 D5 3773 D5 3775 D5 4401 D7 4481 D1 4481 D1 4482 E1 4483 E1 4483 E1 6420 D1 6422 E3 6420 B1 6420 B1 6420 E3 6420 B1 6430 E5 6430 E5 7373 C9 7374 D9 7375 D8 7400 E9 7420 E11 7421 D11 7422 C11 7425 D11 7426 D11 7427 D11 7427 D11 7427 D11 7427 D11 7450 C2 7481 F1 7483 D3 7484 F2 7485 F2 7488 D6 10 3484 F4 3484 F4 3484 F4 3486 B5 3486 B5 3487 B5 3487 B5 3487 B5 3487 B5 3488 B3 3491 B1 3492 B1 3492 B1 3494 F2 3494 F2 3494 F2 3495 F3 3496 F3 3497 B2 3496 F3 3497 B2 3497 B 3504 D1 3508 C5 3509 C7 3510 D7 3511 D7 3512 B1 3513 B5 3514 F2 3516 E2 3517 E2 3517 E2 3518 E2 3519 E2 3524 F3 3524 F3 3524 F3 3524 F3 3524 F3 3524 F3 3524 F3 3527 F4 3529 F4 5330 F3 5331 F3 5331 F3 5332 F4 3533 F4 3533 F4 3537 E3 3537 E3 3537 E3 3538 F3 3538 F3 3538 E3 3538 F3 3538 E3 5538 E 3555 D3 35557 D16 35751 F6 37751 F6 37754 E5 37754 E5 37754 E5 37757 F6 37759 F6 37759 F6 37761 E6 37761 E4 37765 E3 37766 E3 37766 E3 37768 E3 1300 F11 1301 F12 1340 F10 1400 E7 1421 D12 1422 D12 1423 B12 1425 B11 1425 A11 1480 F15 1500 F5 1500 B1 1500 B1 1500 B1 1500 B1 1500 B1 1500 B1 1500 B1 1500 B1 1500 B1 2386 B5 23867 D8 23867 D8 23867 D8 23867 D8 23867 D8 2401 E8 2401 E8 2401 E8 2401 E8 2410 E8 2434 D110 24356 E11 24356 E11 24356 E15 24551 B6 24551 B6 24553 B7 24558 B8 24558 C5 24558 D4 24561 B3 24561 B3 24663 B6 24661 B3 24683 B6 24884 B7 24884 B7 2485 D1 2487 D2 24887 D2 2488 F2 2489 E2 2490 D1 2492 F2 2494 F2 2494 F2 2495 D6 2496 F5 2497 C1 2498 D1 2498 D2 2497 C1 2498 D3 2500 E2 2501 F4 2504 F4 23555 E8 23556 E9 23557 F9 23559 F9 23559 F9 23560 F10 23570 B9 22373 C9 23774 C10 223775 D10 223776 D10 223776 D10 223776 D10 223777 B C9 22377 C9 22377 C9 22377 C9 22381 L9 22381 L9 22381 L9 22383 L9 22384 L9 27551 E66 277554 E66 277554 E45 2775554 E44 277555 E44 277556 E44 27756 E44 27766 E55 27766 E55 27766 E53 3354 FB 3370 B10 3372 C9 3374 D9 3375 D10 3376 D10 3378 B10 3378 B10 3378 B10 3378 B10 3378 B10 3378 D9 3381 D9 3382 D9 3383 C9 3385 D9 3386 C5 3386 C5 3386 C9 3386 C9 3387 B10 2387 B10 2388 D9 2388 23353 F10 23353 F10 23353 F10 23353 F10 23353 F10 23353 F10 23353 F10 23353 F10 23353 F10 23353 F10 23353 F10 23353 F10 23353 F10 23353 F10 23353 F10 34446 D11 34447 D11 34449 D15 34451 DCS 34451 DCS 34512 B7 34516 B6 34517 D4 34517 D4 34518 B7 3 1502 1 = +5V 2 = GND 3 = Vb 4 = OFF 5 = RESET 1 = DSEL 2 = DACK 3 = DCLK 4 = GND - 11 = TROUT - 12 = POWOK - 13 = EFMD - 14 = GND - 15 = ALFA 1 = MERR - 6 = SDAT 2 = TRMOT - 7 = SRST 3 = SREQ - 8 = AM 4 = SACK 9 = CRI - 6 = KILL - 7 = -15V - 8 = GND 9 = +15V 1 = DIG.IN 2 = GND 3 = RC5 5 = GND 6 = DDOUT 7 = IR 3485 (\$) (\$) 348 · 3497 \$\$\frac{15}{15} 3464 3468 3456 3455 3452 7450 1422 3436 2491[] 1 73736 8 7484 1 7 7484 T 3430 3510 1-(+5V) 7488 3502 2495 3556 200 396 1 * 8 2/5£ 356 **→ 275€** 3400 5V 11²³⁵⁶ 2546 >276€ 7482 3495 24 3492 24 25C + DI²⁷⁵² -01²⁷⁵⁴ ►-01²⁷⁶⁵ 234 2356 3343 £ 350 18 7545 18 7 7545 18 3516 (g) 13 17 20 24 7485 (d) 3501 7 • 4 • 1 259\$ 250\$ 250\$ 7491 150 (150) (1 336 (49) 1/257 336 (49) 1/257 -5V)-97.7544 T 7495 **Q** 3805 330E 2303 250f 3305 1340 1500 - 1 = MSTCK - 6 = GND - 2 = GND - 7 = CL - 3 = DATA - 8 = GND - 4 = GND - 9 = SYSS2 5 = WS - 10 = GND - 1 = RLE - 2 = RG - 3 = LG - 4 = LLE - 13 = ATT - 14 = GND - 15 = +5V - 1 = LDR - 2 = KILL - 3 = -15V 4 = GND - 5 = +15V - 6 = SSEL 7 = LDL 1 = L 2 = LG 3 = -15V 4 = GND 5 = +15V 6 = RG 7 = R - 9 = MSC - 10 = EMPH - 11 = DEFS 1 = INSEL 2 = CRI 3 = AM 4 = QCL - 5 = GND - 6 = QDA - 7 = DSSY - 8 = QRA 10 11 12 2 3




DECODER CIRCUIT DIAGRAM (DECODER-1)


to the first of the state of th




DECODER CIRCUIT DIAGRAM (DECODER-2)




DECODER PANEL COMPONENT SIDE








BS DAC CIRCUIT DIAGRAM




BS DAC PANEL








XLR BOARD





XLR BOARD



XLR BOARD


XLR BOARD			
AdPOSREF.No DESCRIPTIONMANUFACTURER	AdPOSREF.No DESCRIPTION	.MANUFACTURER AdPOSREF.No DESCRIPTION	UFACTURER AdPOSREF.No DESCRIPTIONMANUFACTURER
C1 59.06.0334 330 nF 10%, 63V, PETP C2 59.34.4221 220 pF 5%, 63V, C-CER C3 59.34.4221 220 pF 5%, 63V, C-CER C4 59.34.4221 220 pF 5%, 63V, C-CER C5 59.34.4221 220 pF 5%, 63V, C-CER C5 59.34.4221 220 pF 5%, 63V, C-CER C7 59.34.4221 220 pF 5%, 63V, C-CER C8 59.34.4221 220 pF 5%, 63V, C-CER C9 59.34.4221 220 pF 5%, 63V, C-CER C9 59.34.4221 220 pF 5%, 63V, C-CER C9 59.34.4221 220 pF 5%, 63V, C-CER C10 59.06.034 330 nF 100%, 63V, PETP	IC100 50.09.0106 NE 5532AN XR 5532 AN IC101 50.09.0106 NE 5532AN XR 5532 AN IC200 50.09.0106 NE 5532AN XR 5532 AN IC200 50.09.0106 NE 5532AN XR 5532 AN	Ex, Sig, Ra 01 R19 00.00.0000 NOT USED 821 05.711.3322 3.3 KOhm 14, MF Ex, Sig, Ra Cx, Sig, Ra R24 57.11.3322 3.3 KOhm 14, MF Ex, Sig, Ra Cx, Sig, Ra R24 57.11.3322 6.8 KOhm 14, MF	T201 1.022.454.00 INPUT TRAFO 1:0,175 St 01 TP1 54.02.0320 1 pcs TEST POINT W1 00.00.0000 NOT USED W2 00.00.0000 NOT USED W3 64.01.0106 Wire Bridge, D=0.6, L= 7.5 mm
C7 59.34.4221 220 pF 54, 63V C-CER C8 59.34.4221 220 pF 54, 63V C-CER C9 59.34.4221 220 pF 54, 63V C-CER C10 59.06.0334 330 nF 104, 63V PETP	IC201 50.09.0106 NE 5532AN XR 5532 AN J1 54.13.0003 25 pol D-Type-connector	Ex, Sig, Ra R25 57,11,3361 360 0bm 18, MF R26 57,11,3473 47 0bm 18, MF R27 57,11,3473 47 0bm 18, MF R28 57,11,3164 105 0bm 18, MF	Y1 89.01.4400 432kHz Ceramic Resonator Y2 89.01.0550 4.0000HHz Quarz
C 11 50 05 0104 100 aF 10k 63V PFTP	J2 54.21.2201 XLR-connector	Ex, Sig, Ra R 25 57.11.3361 360 Ohm 1½, MF R 26 57.11.3473 47 Kohm 1½, MF R 27 57.11.3474 270 Kohm 1½, MF R 28 57.11.3464 100 Kohm 1½, MF R 29 57.11.3154 100 Kohm 1½, MF R 30 57.11.3154 100 Ohm 1½, MF	Note 1 - Q100-Q101, Q102-Q103, Q104-Q105, Q106-Q107, 0200-0201, 0202-0203, 0204-0205, 0206-0207,
	J200 54.21.2201 XLR-connector		matched and thermically coupled with 50.20.2001. Cer-Ceramic, ElBipellectrolytic Bjoolar, El=Electrolytic, Sal=Solid aluminum.
C18 59.06.0105 1 uF 10% 63V PETP	K1 56.04.0197 Relais 24V/1A K2 56.04.0197 Relais 24V/1A L1 62.02.3229 2.2 uH	R31 57.99.0209 5.6 Ohm PTC R32 57.11.3271 270 Ohm 14, MF R33 57.11.3272 4.7 Kohm 14, MF R34 57.11.3472 4.7 Kohm 14, MF R36 57.11.3328 3.3 Kohm 14, MF	
	L100 62.01.0115 2.5 Mdg Wideband-Coil	01 R37 00.00.0000 NOT USED R100 57.11.3102 1 kOhm 1½, MF	MANUFACTURER: ExeExar, ForFairchild, ITT=Intermetall, Mot+Motorola, Ph-Philips, Ra-Raythono, Sia-Siaemes, Sign-Signentics, St-Studer, Tf=Tolefunken, IT= Texas Instruments.
C22 59.06.0104 100 nF 10%, 63V, PETP C23 59.06.0104 100 nF 10%, 63V, PETP C24 59.06.0102 1 nF 10%, 63V, PETP	L101 62.01.0115 2.5 Wdg Wideband-Coil L200 62.01.0115 2.5 Wdg Wideband-Coil	P 101 57 11 3103 10 k0hm 1%. MF	(00) 91/09/27 SERIE (01) 91/09/09 SERIE ADJUST (02) 91/11/22 EMI COMPONENTS (03) 91/22/11 C WITH VENTIL
C25 59.06.0102 1 nF 10%, 63V PETP	L201 62.01.0115 2.5 Wdg Wideband-Coil	R103 57.11.3332 3.3 kOhm 1%, MF R104 57.11.3332 3.3 kOhm 1%, MF	(03) 91/12/11 C MITH VENTIL 1.629.630.00 XLR - BOARD MOR91/12/1103
C28 59.06.0102 1 nF 10%, 63V , PETP C29 59.06.0104 100 nF 10%, 63V , PETP	MP1 1.629.630.11 XLR PCB MP2 1.629.630.10 Label	R106 57.11.3339 3.3 Ohm 1%, MF R. 107 57 11 3223 22 kOhm 1%. MF	11.027.000.00 ALN - DOWN
C30 59.06.0104 100 nF 10%, 63V PETP C31 59.06.0104 100 nF 10%, 63V PETP	MP3 50.20.2001 8 pcs Clip T092 01 MP4 00.00.0000 NOT USED MP5 1.022,400.03 2 pcs Isolation	R109 57.11.3103 10 kOhm 1%, MF R109 57.11.3181 180 Ohm 1%, MF R110 57.11.3399 3.3 Ohm 1%, MF	
01 C100 59.34.4101 100 pF 5%, 63V , CER	01 MP7 00.00.0000 NOT USED MP 8 1 010 125 54 Connector Sink	R111 57.11.3103 10 kOhm 1½, MF R112 57.11.3339 3.3 Ohm 1½, MF R113 57.11.3821 820 Ohm 1½, MF	
C101 59.05.1102 1 nF 1%, 630V, PP C102 59.05.1102 1 nF 1%, 630V, PP C103 59.06.0103 10 nF 10%, 63V, PETP C104 59.06.0333 33 nF 10%, 63V, PETP	MP10 24.16.2030 2 pcs Fin Washer	R111 57.11.3103 10 kOhm 14, MF R112 57.11.3339 3.3 Ohm 14, MF R113 57.11.322 820 Ohm 14, MF R114 57.99.0209 5.6 Ohm PTC R115 57.90.0209 5.6 Ohm PTC R116 57.11.3103 10 kOhm 14, MF	
C104 59.06.0333 33 nF 10%, 63V PETP C105 59.22.4470 47 uF -20%, 15V EL C106 59.22.5221 220 uF -20%, 25V EL	MP12 20.99.0103 6 pcs Screw 2.2 * 5, ZN 02 MP13 00.00.0000 NOT USED	R117 58.05.1203 20.10ha Trimmer R118 00.0000 MOT USED R119 57.11.3601 680 Ohm 14, MF R120 57.11.3472 4.7 Kolhm 14, MF	
C104 59.422.4430 43 m 30.00 90 FEU C104 59.422.4430 43 m 30.00 90 FEU C105 59.22.521 220 m 30.00 90 90.25 FEU C107 59.22.4470 47 m 30.00 90 90.25 FEU C108 59.22.5101 100 m 30.00 90 90.25 FEU C109 59.22.5101 100 m 30.00 90 90.25 FEU C109 59.22.5101 100 m 30.00 90 90.25 FEU C109 59.22.5101 100 m 30.00 90 90.25 FEU C109 59.22.5101 100 m 30.00 90 90.00 90 90 90 90 90 90 90 90 90 90 90 90 9	02 MP14 00.00.0000 NOT USED MP15 54.02.0452 Key for pin 24 of D-plug MP16 61.99.0136 1 pcs 303 Ferrit Tube 02 MP17 61.99.0136 1 pcs 303 Ferrit Tube	R120 57.11.3472 4.7 kOhm 14, MF R130 57.11.3332 3.3 kOhm 14, MF	
C110 59.22.5220 22 wF -20%, 16V , EL C111 00.00.0000 NOT USED	P 1 54.21.2200 XIR-connector	D 121 E7 11 2222 2 2 MAN 16 MF	
C120 59.05.1102 1 nF 1%, 630V , PP C121 59.34.2220 22 pF 5%, 63V , CER	P3 54.99.0220 3 pol RFK1-connector, GREY	R133 57.11.3222 2.2 kOhm 1½, MF R134 57.11.3161 160 Ohm 1½, MF P. 135 57.11.3271 277 Ohm 1½ MF	
C122 59.05.1102 1 nF 1%, 630V, PP	P5 54.99.0242 7 pol RFK1-connector, GREY P6 54.99.0239 7 pol RFK5-connector, BLACK P100 54.21.2200 XLR-connector	R136 57.11.3102 1 kOhm 1%, MF	
C125 59.06.0152 1.5 nF 10%, 63V, PETP	P200 54.21.2200 XLR-connector	R140 58.05.1103 10 kOhm Trimmer	
C127 59.34.5471 470 pF 54; 63V CER C128 59.22.4470 47 uF -204; 10V EL C129 59.22.4470 47 uF -204; 16V EL C130 00.00.0000 NOTUSED	Q1 50.03.0329 MP 146 P-FET Q2 50.03.0329 MP 146 P-FET Q3 50.03.0329 MP 146 P-FET	R141 00.00.0000 NOT USED R200 57.11.3102 1 kOhm 1%, MF	
C200 59.34.4101 100 pF 5%, 63V CER	Q4 50.03.0329 WP 146 P-FET Q5 50.03.0340 BC 337 NPN 0 6 50.03.0329 WP 146 P-FFT	R 201 57.11.3108 10 kOhm 14, MF R 202 57.11.3339 3.3 Ohm 14, MF R 203 57.11.332 3.3 kOhm 14, MF R 204 57.11.332 3.3 kOhm 14, MF	
C201 59.05.1102 1 nF 14, 630V PP C202 59.05.1102 1 nF 14, 630V PP C202 59.05.1102 1 nF 18, 650V PP C203 59.05.103 10 nF 16, 63V PP C205 59.05.103 10 nF 16, 63V PP C205 59.22.22.4470 4	Q7 50.03.0329 MP 146 P-FET Q8 50.03.0329 MP 146 P-FET Q. 9 50.03.0329 MP 146 P-FFT		
C204 59.06.0333 33 nF 104, 63Y, PETP C205 59.22.4470 47 uF -204, 16V, EL C206 59.22.5221 220 uF -204, 25V, EL		R. 2005 57.11.3108 10 k0hm 19, MF R. 2005 57.11.3239 3.3 0hm 14, MF R. 2007 57.11.3223 22 k0hm 14, MF R. 2008 57.11.3023 10 k0hm 14, MF R. 2008 57.11.3101 10 k0hm 14, MF	
C206 59.22.5221 220 uF -20%, 25V, EL C207 59.22.4470 47 uF -20%, 15V, EL C208 59.22.5101 100 uF -20%, 25V, EL C209 59.22.5101 100 uF -20%, 25V, EL C209 59.22.520 22 uF -20%, 15V, EL	Q13 50.03.0340 BC 337 NPN Q14 50.03.0340 BC 337 NPN	R209 57.11.3181 180 0hm 1%, Hr R210 57.11.3339 3.3 0hm 1%, MF	
C210 59.22.5220 22 uF -20%, 16V , EL	Q15 50.03.0340 BC 337 NPN Q100 50.03.0625 BC 327 PNP, match see note 1	R	
C211 00.00.0000 NOT USED C220 59.05.1102 1 nF 14, 630V , PP C221 59.34.2220 22 PF 54, 63V CER C222 59.05.1102 1 nF 14, 630V , PP	Q101 50.03.0625 BC 327 PNP, match see note 1	R214 57.99.0209 5.6 Ohm PTC R215 57.99.0209 5.6 Ohm PTC P 216 57.11.3103 10 kOhm 1k MF	
C222 59.05.1102 1 nF 1%, 630V, PP C223 59.18.0108 5.540 pF 100V, Trimmer C224 59.05.2471 470 pF 2.5%, 630V, PP C225 99.05.0152 15.nF 100%, 630V, PPTP 03 C225 59.99.1710 220 uF -20%, 35V, EL		R217 58.05.1.203 20 60hm Trimmer R218 00.00.00000 MOTU SED R219 57.11.3681 680 0hm 1%, MF R220 57.11.3472 47. fohm 1%, MF	
C222 59.05.1102 1 nr 14, 5509	Q107 50.03.0516 BC 337 NPN, match see note 1	R220 57.11.3472 4.7 kOhm 1%, MF R230 57.11.3332 3.3 kOhm 1%, MF	
	Q200 50.03.0625 BC 327 PMP, match see note 1 Q201 50.03.0625 BC 327 PMP, match see note 1 Q202 50.03.0516 BC 337 WPM, match see note 1	P	
D. 1 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 2 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 3 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 3 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 5 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 6 5 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 7 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 8 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 9 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 9 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 9 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 9 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 9 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 9 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 9 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 9 50.04.0125 IN 4448 F.LIT.Ph.Tf D. 9 50.04.0125 IN 4448 F.LIT.Ph.Tf	Q203 50.03.0516 8C 337 NPN, match see note 1	R	
D3 SD.04.0125 1N 4448 Fc,ITT.Ph,ITF D4 50,04.0125 1N 4448 Fc,ITT.Ph,ITF D5 50,04.0125 1N 4448 Fc,ITT.Ph,ITF D6 50,04.0125 1N 4448 Fc,ITT.Ph,ITF	0205 50.03.0625 BC 327 PNP, match see note 1 0206 50.03.0516 BC 337 NPN, match see note 1 0207 50.03.0516 BC 337 NPN, match see note 1	R234 57.11.3.161 150 0hm 114, MF R235 57.11.3.271 270 0hm 114, MF R236 57.11.3.102 1 10hm 114, MF R237 57.11.3.102 1 10hm 114, MF R233 57.11.3.102 1 10hm 114, MF R238 57.11.3.102 1 10hm 114, MF	
D6 50.04.0125 1N 4448 Fc,ITT,Ph,Tf D7 50.04.0125 1N 4448 Fc,ITT,Ph,Tf D8 50.04.0125 1N 4448 Fc,ITT,Ph,Tf	D 1 57 11 2072 2 7 LON- 15 ME	R241 00.00.0000 NOT USED	
D9 50.04.0125 1N 4448 Fc,ITT,Ph,If D10 50.04.0125 1N 4448 Fc,ITT,Ph,Tf	R4 57.11.3104 100 kOhm 1%, MF R5 57.11.3304 300 kOhm 1%, MF	P71 57.88.4103 10 k0hm 2%	
011 50.04.0125 1H 4448 Fc_ITT_Ph_TF 012 50.04.0125 1H 4448 Fc_ITT_Ph_TF 013 50.04.0125 1H 4448 Fc_ITT_Ph_TF 014 50.04.0125 1H 4445 Fc_ITT_Ph_TF	R	RZ2 57.88.2684 680 lOhim 2k RZ3 57.88.2684 680 lOhim 2k RZ4 57.88.4472 4.7 lOhim 2k	
011 50.04.0125 IN 4488 F.LIT.Ph.Tf 012 50.04.0125 IN 4488 F.LIT.Ph.Tf 013 50.04.0125 IN 4448 F.LIT.Ph.Tf 014 50.04.0125 IN 4448 F.LIT.Ph.Tf 015 50.04.0125 IN 4448 F.LIT.Ph.Tf 016 50.04.0125 IN 4448 F.LIT.Ph.Tf 017 50.04.0125 IN 4448 F.LIT.Ph.Tf		T1 00.00.0000 NOT USED T2 1.022.633.00 DOBM TRANSFORMER 1:2 T3 1.022.633.00 DOBM TRANSFORMER 2:1	
IC1 50.99.0126 4N28 OPTO-COUPLER	R11 57.11.3103 10 kOhm 1½, MF R12 57.11.3683 68 kOhm 1½, MF R13 00.00.0000 NOT USEO 01 R14 57.11.3151 150 Ohm 1½, MF	T3 1.022.533.00 DOWN TRANSFORMER 2:1 T100 1.022.366.00 LINE OUTPUT TRAFO 1:1,46	St
IC4 50.11.0203 SAA3049 RC5-DECODER PN IC 6 50.15.0123 SN75ALS192 ONAD DIFFERENTIAL LINE DRIVER Ti	01 R15 57.11.3181 180 0hm 1½, MF	T101 1.022.454.00 INPUT TRAFO 1:0,175 T200 1.022.366.00 LINE OUTPUT TRAFO 1:1,46	St St
IC7 50.10.0106 TL 431CLP SHUNT-REGULATOR Mot,Ti	R17 00.00.0000 MOT USED R18 57.11.3332 3.3 kOhm 1%, MF	43 1200 1.022.366.00 EINE 001P01 TRAFO 1:1,46	**






The JADA production of the company of the Mark to the Company of t

LEVEL BOARD



LEVEL BOARD




The month of the later than 1915 for the later than 1916 the control of the later than 1916 the later than


Ad	POS	REF.No	DESCRIPT	[ONM	INUFACTURER
	C100	59.22.4470	47 uF	-20%, 16V , EL	
01	C101 C102 C103	59.22.8479 59.22.4470 00.00.0000	4.7 uF 47 uF NOT USED 22 nF 220 uF	-20%, 50V , EL -20%, 16V , EL	
	C104 C105	59.06.0223 59.22.5221	22 nF	10%, 63V PETP -20%, 25V EL 10%, 63V PETP -20%, 25V EL 5%, 63V CER	
	C106	59 06 0223	22 nF 220 uF	10°, 63°, PETP -20°, 25°, EL 10°, 63°, PETP -20°, 25°, EL	
	C107 C108	59.22.5221 59.34.2220	220 uF 22 pF	-20%, 25V , EL 5%, 63V , CER	
	C200	59.22.4470	47 uF	-20%, 16V , EL	
	C201	59.22.8479	4.7 uF 47 uF	-20%, 50V , EL -20%, 16V , EL	
01	C202 C203	59.22.4470 00.00.0000		-20%, 16V , EL	
-	C204	59.06.0223	22 nF	10%, 63V , PETP	
	C205 C206	59.22.5221 59.06.0223	22 nF 220 uF 22 nF 22 nF 220 uF	10%, 63V , PETP -20%, 25V , EL 10%, 63V , PETP	
	C206 C207 C208	59.22.5221 59.34.2220	220 uF 22 pF	10%, 63Y, PETP -20%, 25Y, EL 10%, 63Y, PETP -20%, 25Y, EL 5%, 63Y, CER	
	D100	59.34.2220	6¥2	Zener-Diode	
	D101	50.04.1118	6V2	Zener-Diode	
	D200	50.04.1118	6V2	Zener-Diode	
	D201 DL1	50.04.1118 50.04.2129	6V2	Zener-Diode LED. RED	
	DL2	50.04.2131	WEEE20AP	LED, RED LED, GREEN	F., Cd., D
	IC100 IC101	50.09.0106 50.07.0015	NE5532AN 74HC4053	OP-AMP 3 * 2-CHANNEL ANALOGUE MUX/DEMUX	Ex,Sig,Ra Mot
	IC200 IC201	50.09.0106 50.07.0015	NE5532AN 74HC4053	OP-AMP 3 * 2-CHANNEL ANALOGUE MUX/DEMUX	Ex,Sig,Ra Mot
02	MP2	1.629.635.12 1.629.635.10		Level PCB Label	St St
	MP3	54.02.0320	2 pcs	Test point	St
	MP5 MP6	1.629.635.01 1.629.635.02	2 pcs	Test point Levelboard Traeger Potunterlage	St St
	MP6	1.629.640.01	L p05		St
	MP7 MP8 MP9	1.629.640.02		LED-Halter ESE - Label	St
	MP9 MP10	43.01.0108 21.46.0354 23.01.2032	4 pcs 4 pcs	Torx-Screw M3x6 Ring	
	P1	54.99.0242	7 pol 4 pol	RFK1-connector, GREY RFK1-connector, GREY	
	P2 R1	54.99.0219 57.11.3183	18 kOhm	1%, MF	
	R2 R3	57.11.3183 00.00.0000 57.11.3821	NOT USED	1%, MF	
	R4	57.11.3821	820 Ohm 820 Ohm	1%, MF	
	R100	1.010.202.58	5 kOhm	Potentiometer	
	R101 R102 R103	57.11.3473 57.11.3102 57.11.3222 57.11.3103 57.11.3103 57.11.3103	47 kOhm 1 kOhm	1%, MF 1%, MF	
	R103	57.11.3222	2.2 kOhm	1%, MF 1%, MF	
	R104 R105	57.11.3103	10 kOhm	1%, MF	
	R106	57.11.3103	1 kOhm 2.2 kOhm 10 kOhm 10 kOhm 10 kOhm 470 Ohm	14, MF 14, MF 14, MF 14, MF 14, MF 14, MF 14, MF	
	R107 R108 R109	57.11.3471 57.11.3471 57.11.3271	470 Ohm	1%, MF 1%, MF	
	R109 R110	57.11.3271 57.11.3000	270 Ohm 0 Ohm	1%, MF	
		1.010.202.58	5 kOhm	Potentiometer	
	R201 R202	57.11.3473 57.11.3102 57.11.3222	47 k0hm 1 k0hm 2.2 k0hm 10 k0hm 10 k0hm	14, MF 14, MF 14, MF 14, MF 14, MF 14, MF 14, MF	
	R203	57.11.3222	2.2 kOhm	1%, MF	
	R204	57.11.3103	10 k0hm 10 k0hm	1%, MF 1%, MF 1%, MF	
	R206 R207	57.11.3103 57.11.3103 57.11.3471	10 kOhm	15, MF	
	R207 R208	57.11.3471 57.11.3471	470 Ohm 470 Ohm	14, MF 14, MF	
	R209 R210	57.11.3271 57.11.3000	270 Ohm O Ohm	14, MF	
	S1	55.15.2000	o unm	Druckschalter mit Rasterung	
02	W1 W2	1.629.635.93 00.00.0000	NOT HEED	LL - Level-Board	
02	W3	00.00.0000	NOT USED NOT USED		
Cen E1:	r=Ceramic, =Electroly	ElBip=Electro	lytic Bipola aluminum.	ir,	
				ITT=Intermetall, Mot=Motorola, , Sie=Siemens, Sig=Signetics, n, TI= Texas Instruments .	
		St=Studer, T 17 SERIE 23 SERIE ADJUS 20 PCB -12		i, ii= lexas instruments .	
(0	01) 91/10/	23 SERIE AUJUS	1		

CONTROL AND DISPLAY CIRCUIT DIAGRAM

THE GROUP THE TRANSPORT OF THE STATE OF THE




CONTROL AND DISPLAY PANEL




PARALLEL REMOTE CONTROL 1.328.660

- KEYBOARD 1.328.661
- SUPPLY BOARD 1.328.662




PARALLEL REMOTE CONTROL 1.328.660






AdPOSRE	F.No DESC	RIPTION	MANUFACTURER
B5 51.0	02.0155 02.0155 02.0155	5V 60mA 5V 60mA 5V 60mA	
C1 59.	06.0104 100	nF 10%, 50%, PETP	
D1 50. D2 50.	04.0125 1N44 04.0125 1N44	48	any any
D3 50.	04.0125 1N44 04.0125 1N44	48	any
D5 50.	04.0125 1844	48	any
DL1 50. DL2 50. DL3 50.	04.2129 LS33 04.2130 LY33 04.2130 LY33	60 LED, yellow dif.	
J2 54. J3 54.	13.0023 25 p 01.0021 01.0021 01.0021	in Connector D-Type Jumper Jumper Jumper	
MP1 1.328	3.661.11	Keyboard PCB	St
MP3 53	3.661.01 .03.0240	Label DL-socket	St
MP4 53.	03.0240 03.0240	DL-socket DL-socket	
MP6 1.328 MP7 55.	3.661.02 .15.0201 3 1 .15.0228 3 1	Switch label set cs Button pannel	St
MP8 55.	.15.0228 3 ; .15.0221 3 ;	cs Sutton case	
MP10 55.			
MP12 55.	.15.0124 1 p	ce 8utton pannel yell ce 8utton pannel gree cs Button pannel red cs Adapter for high =	ow n
MP14 55.	.15.0125 1 .15.0122 2 .15.0132 8	cs Button pannel red cs Adapter for high =	ounting
MP16 1.010	0.055.22 0.055.22	Rivet hex nut Rivet hex nut	
MP18 1.010	0.035.54 0.035.54	Lock hex nut Lock hex nut	
MP19 24.	.16.1030 .16.1030	Fin washer Fin washer	
MP21 54. MP22 55.	.02.0452 .15.0212	Key Foil red	
P1 54.	.14.2003 26	ol Connector for flat	-cable
P4 54.	.01.0020 .01.0020 .01.0020	male, P-Strip male, P-Strip	
P6 54.	.01.0020 .01.0020 .01.0020	male, P-Strip male, P-Strip	
P8 54.	.01.0020 .01.0020	male, P-Strip male, P-Strip male, P-Strip male, P-Strip male, P-Strip	
P9 54. P10 54.	.01.0020	male, P-Strip	
	.01.0020	male, P-Strip	
Q2 50.	.03.0436 BC	37	any any
R2 57	.11.3223 22 k .11.3103 10 k .11.3223 22 k	0hm 5% 0hm 5%	
R4 57.	.11.3103 10 k .11.3223 22 k .11.3682 6.8 k	0hm 5% 0hm 5%	
R5 57.	.11.3223 22 ki	0hm 5% 0hm 5%	
R7 57.	.11.3331 330 .11.3331 330	0hm 5%r 0hm 5%r	
R9 57	.11.3331 330	Ohm 5%	
S2 55 S2 55	.15.0112 .15.0112	Momentary pushbutt	on switch
\$3 55	.15.0112	Momentary pushbut	on switch
S5 55	.15.0231 .15.0231 .15.0231	Momentary pushbutt	on switch
S7 55	.15.0112	Homentary pushbutt	on switch
S9 55	.15.0112	Momentary pushbut Homentary pushbut Homentary pushbut Homentary pushbut Homentary pushbut Homentary pushbut Homentary pushbut Homentary pushbut Homentary pushbut Homentary pushbut	on switch
	.15.0112		
W1 1.02		Momentary pushbuts	OH SWILCE
el=Electrolytic,		Flat cable 10 pol	
MANUFACTURED: St=			
	8.661.00 KEYBOA	en.	HL 92/05/2600
1.320	0.001.00 ALIBOR		ne 52/50/2000


PARALLEL REMOTE CONTROL 1.328.660 - SUPPLY BOARD 1.328.662




P0S	REF.No	DESCRIPT	IONMANUFACT	URER
c1	59.06.0104	100n F	10%, 50V, PETP	
C2	59.22.6470	47uF	-20%, 40V, EL	
C3	59.06.0104	100nF	10%, 50V, PETP	
C4	59.06.0103	10nF	10%, 50V, PETP	
C5	59.06.0104	100nF	104, 50V, PETP	
C6	59.06.0102	1nF 100uF	10k, 50V, PETP	
C7	59.22.3101 59.22.3101	100uF	-20%, 10%, EL -20%, 10%, EL	
C8 C9	59.06.0104	100ur	10%, 50V, PETP	
c10	59.06.0104	100n F	104, 50V, PETP	
C11	59.06.0104	100nF	104, 50V, PETP	
C12 C13	59.06.0104 59.06.0104	100n F 100n F	10%, 50V, PETP 10%, 50V, PETP	
D1	50.04.0519	1N5822		any
D2	50.04.0125	1N4448		an
D3	50.04.0125	1N4448		an
D4	50.04.0125	1N4448		an
D5	50.04.0125	184448		an
IC1 IC2	50.05.0279 50.17.1074	IP3524B 74HC74	Voltage-regulator Dual D-Type Flip Flop Nat,Ph	IP:
		7411074		AN
J1 J2	54.01.0021 54.01.0021		Jumper Jumper	AH
K1	56.04.0190	57	Relais	
L1	62.03.0005	250uH	Toroidal choke	
MP1	1.328.662.11		Supply Board PCB	St
MP2	1.328.662.01		Label .	
MP3	43.01.0108		"ESE" Label	
P1	54.02.0320		Flat Pin	
P2	54.02.0320		Flat Pin	
P3	54.02.0320		Flat Pin	St
P4	54.01.0020 54.01.0020		male P-Strip male P-Strip	
P5 P6	54.01.0020		male P-Strip	
P7	54.01.0020		male P-Strip	
P8	54.01.0020		male P-Strip	
P9	54.01.0020		male P-Strip	
P10	54.01.0020		male P-Strip	
P11	54.14.2101	10-pol	Connector for flat-cable	
Q1	50.03.0505	BD 680		
Q2	50.03.0436	BC237B		
Q3	50.03.0340	BC337-25		
R1	57.11.3272	2.7k	*** all resistor 5% 0.25 W general ***	
R2	57.11.3472	4.7k	*** purpose unless otherwise noted ***	
R3	57.11.3182	1.8k		
R4	57.11.3473	47 k		
R5	57.11.3472 57.11.3101	4.7k		
R6	57.11.3101	100e 33k		
R7 R8	57.11.3333 57.11.3333	33k		
R9	57.11.3333	33 k		
R10	57.11.3333	33k		
R11	57.11.3105	1Ĥ		
R12	57.11.3562	5.6k		
=Electroly	tic, Si=Silici	um		
NUFACTURED	: St=Studer, P	h=Philips,	IPS=Integrated Power Semiconductors	



START UP PROCEDURE



START UP PROCEDURE



FAULTFINDING DIAGNOSIS

REPLACING THE CDM-UNIT OR THE ENCODER PCB **FAULTFINDING DIAGNOSIS** WOSP -set upside down Remove bottomplate - Visual control: are all the solderings ok? (transistors, IC's) - Check safety resistors - Check all voltages (on connectors, IC's) - Check actuator (ohmic) on flex connector 1003 on WOSP Radial actuator: points 25 - 28 Focus actuator : points 26 - 27 - Open the set Remove the clamper - Actuator is visible: Press play: turntable motor turns focus 2x pumping laserlight - Actuator is inside: Press play: turntable motor turns a few seconds no focus no laserlight slide switch is not closed (wiring or switch) - Test of turntable motor: (Black connector) External 1V on motor - Test of slidemotor: (Grey connector) External -1V: slide goes outwards +1V: slide goes inwards - Test of slidebeginswitch: (Red connector) When slide is inside: 0Ω

AUDIO RECORD BUFFER

STUDER D740 CD-RECORDER

Option 1.629.626.00

Installation Instructions

AUDIO RECORD BUFFER

STUDER D740 CD-RECORDER

Option 1.629.626.00

Einbauanleitung

Prepared and edited by: STUDER Professional Audio AG TECHNICAL DOCUMENTATION Althardstrasse 30, CH-8105 Regensdorf-Switzerland

We reserve the right to make alterations. Copyright by STUDER Professional Audio AG printed in Switzerland Order No.: 10.27.3361 (Ed. 0194)

STUDER is a registered trade mark of STUDER PROFESSIONAL AUDIO AG Regensdorf STUDER ist ein eingetragenes Warenzeichen der STUDER PROFESSIONAL AUDIO AG Regensdorf

EDITION: 27.06.94

Option: Audio Record Buffer (set: 1.629.626.00)

Track generation problem:

In AUTO mode a new track is written when the modulation start is detected. This modulation start has first to be recognized by the microprocessor system. Subsequently the track number is incremented in the subcode generator of the CD recorder. The disadvantage of this method is that the modulation start is typically located 90ms before the track change. When a track is selected on a CD player, the beginning of the music is cut off by this amount.




Fig. 1: Diagram: Modulation start and track generation on a CD recorder without compensation

Even if the modulation start was located exactly at the track change, the start of the music could be cut off on certain CD players. For this reason the modulation start must be located at least 100ms after the track change. On stamped CDs the time between the track change and the modulation start is typically 100 to 300ms.




Fig. 2: Diagram: Ideal modulation start

Solution:

As can be seen from the two diagrams, the audio information in the CD recorder must internally be delayed by 200ms relative to the subcode that contains the track information. For this purpose STUDER offers the AUDIO RECORD BUFFER as an option which delays the audio information by 200ms, 400ms or Oms. The delay time can be set manually on the rear panel of the unit. The nominal setting is 200ms. The larger delay of 400ms can be useful for certain audio sources that generate the track change with an additional delay via the PARALLEL REMOTE of the D740.

The AUDIO RECORD BUFFER option can be retrofitted on the D740. The installation and testing of the board takes approx. 1 hour. This work should only be performed by an authorized service center.

EDITION: 20/01/94 3

The AUDIO RECORD BUFFER can also be retrofitted to the D740 CD recorder. The installation and functional test require approx. 1 to 2 hours. This work should only be performed by an authorized service center.

When working on the D740 please follow the instructions concerning the handling of ESD components. Refer to the service instructions (publication No. 10.27.3060)

Installing the CD-R delay unit

- 1. Disconnect the CD recorder from the AC power source!
- 2. Remove the cover, rear panel and bottom panel (refer to the exploded view on the last page).
- 3. Holes for mounting the new circuit board and the changeover switch must be drilled into the rear panel. The positions and hole diameters are shown in the diagram below.




Fig. 1 Mounting holes in the rear panel of the D740 and drill holes for the new switch.

- 4. Modify the ENCODER BOARD as shown on the following fold-out page:
 - Interrupt the printed conductor near R3404 (designation: "cut").
 - Remove R3404 (designation: "remove").
 - Solder the 7 wires of the special connection cables to the ENCODER BOARD. Refer to the drawing on the following fold-out page.
- **5.** Place the CD-R DELAY UNIT loosely into the designated position in the CD recorder. (see Fig. 2).
- 6. Plug the special connection cable into P1 on the CD-R delay unit.
- 7. Install the wired change-over switch (ON-OFF-ON) in the correct mounting plane.
- 8. Reinstall the rear panel.

4 EDITION: 20/01/94




Fig. 2 CDR delay unit installed in the D740 CD recorder. Front top view.




Fig. 3 Connection of the special connection cable on the encoder board. Rear bottom view

EDITION: 20/01/94 5

- 9. Fasten the delay unit with the two female screws to the rear panel.
- 10. Perform a functional test, if necessary.
- 11. Reinstall the bottom plate and the cover.
- 12. Affix the labeling strip below the new toggle switch.


Functional test

- Set the jumper on the delay unit to the TEST position (JP2-3).
- Set the delay with the toggle switch to 400 ms.

Test When the CD recorder is now switched to record-pause (REC-PAUSE), the input signal can be monitored via the output. It has a 400 msec delay.

The complete circuitry can be tested via the digital input and output by means of a pattern test on a "System One" measuring instrument.

• After the test has been successfully completed restore the jumper to the NORMAL position (JP1-2)!!



CD-R delay unit: Test mode in jumper setting JP2-JP3

Option: Audio Record Buffer (set: 1.629.626.00)

Trackgenerierungsproblem:

In der AUTO-Betriebsart wird beim Beginn der Modulation ein neuer Track beschrieben. Dieser Modulationsbeginn muss vom Mikroprozessorsystem erkannt werden. Anschliessend wird die Tracknummer im Subcode-Generator des CD-Recorders um 1 erhöht. Der Nachteil dieses Verfahrens ist, dass der Modulationsbeginn typischerweise 90 ms vor den Anfang des Tracks zu liegen kommt. Beim Abspielen dieses Tracks auf dem CD-Spieler wird der Anfang der Musik gerade um diesen Betrag abgeschnitten.




Abb. 1: Diagramm: Modulationsbeginn und Trackgenerierung auf einem CD Recorder ohne Kompensation

Selbst wenn der Modulationsbeginn genau auf dem Trackwechsel liegt, kann der Anfang des Musikstücks bei einigen CD-Spielern abgehackt werden. Aus diesem Grund muss der Modulationsbeginn mindestens 100 ms hinter dem Trackanfang liegen. Bei serienmässig hergestellten CDs beträgt die Zeit zwischen dem Trackwechsel und dem Modulationsbeginn typ. 100 bis 300 ms.




Abb. 2: Diagramm: Idealer Modulationsbeginn

Lösung:

Wie aus den beiden Diagrammen ersichtlich ist, müssen die Audiodaten des CD-Recorders relativ zum Subcode mit der Trackinformation um 200 ms verzögert werden. Zu diesem Zweck offeriert STUDER einen AUDIO RECORD BUFFER, welcher die Audiodaten um 200ms, 400 ms oder 0 ms verzögert. Die Verzögerungszeit kann auf der Rückseite des Gerätes von Hand eingestellt werden. Die Standardeinstellung ist 200 ms. Nützlich ist die längere Verzögerungszeit von 400 ms für bestimmte Audioquellen, welche den Trackwechsel mit einer zusätzlichen Verzögerung über den PARALLEL REMOTE Anschluss der D740 erzeugen.

Der AUDIO RECORD BUFFER kann als Option für den D740 nachgerüstet werden. Der Zeitaufwand für die Installation und den Funktionstest der Platine beträgt ca. 1 Stunde. Diese Arbeit soll ausschliesslich durch eine autorisierte Servicestelle ausgeführt werden.

EDITION: 20/01/94 7

Die Option AUDIO RECORD BUFFER kann auch nachträglich in den D740 CD-Recorder eingebaut werden. Installation und Funktionstest nehmen etwa 1 bis 2 Stunden in Anspruch. Diese Arbeit soll ausschliesslich durch eine autorisierte Servicestelle ausgeführt werden.

Bei Arbeiten am D740 sind die Hinweise zum Umgang mit ESD-Komponenten zu befolgen. Siehe dazu die Serviceanleitung (Best.-Nr. 10.27.3060)

Einbau der CD-R Delay Unit

- 1. Gerät vom Netz trennen!
- 2. Deckblech, Rückwand und Bodenplatte entfernen (Explosionsansicht siehe hinterste Seite).
- 3. In die Rückwand müssen Löcher zur Befestigung des neuen Prints sowie für den Umschalter gebohrt werden. Lage und Lochdurchmesser gemäss Abbildung.




Abb. 1 Befestigungslöcher in der Rückwand des D740 und Bohrungen für den neuen Schalter.

- 4. ENCODER-BOARD bearbeiten gemäss folgender Ausklappseite:
 - Leiterbahn in Nähe von R3404 unterbrechen (Bezeichnung "cut")
 - R3404 entfernen (Bezeichnung "remove")
 - Die 7 Drähte des Spezialverbindungskabels auf dem ENCODER-BOARD anlöten. Siehe Zeichnung auf der folgenden Ausklappseite.
- 5. CD-R-DELAY UNIT lose an vorgesehener Position ins Gerät legen. (siehe Abb. 2)
- 6. Spezialverbindungskabel in P1 auf der CD-R-Delay Unit einstecken.
- 7. Bekabelter Umschalter (ON-OFF-ON) orientierungsrichtig einbauen.
- 8. Rückwand wieder einbauen.

EDITION: 20/01/94




Abb. 2 CDR-Delay Unit eingebaut in den D740 CD-Recorder. Ansicht von vorne oben.




Abb. 3 Der Anschluss des Spezialverbindungskabels auf dem Encoder Board. Ansicht von hinten unten.

EDITION: 20/01/94 9

- 9. Delay Unit mit den beiden Mutterbolzen an der Rückwand befestigen.
- 10. Funktionstest durchführen falls nötig
- 11. Bodenplatte und Deckblech wieder montieren
- 12. Beschriftungsstreifen unterhalb des neuen Kippschalters anbringen.


Der Funktionstest

- Den Jumper auf der Delay Unit in Stellung TEST (JP2-3) bringen.
- Die Verzögerung mit dem Kippschalter auf 400ms einstellen.

Test Wird der CD-Recorder nun in Aufnahme-Pause (REC-PAUSE) gebracht, kann über den Ausgang das Eingangssignal abgehört werden. Es hat eine Verzögerung von 400msec.

Über den Digital Ein- und Ausgang kann das Ganze mittels Pattern Test auf einem "System One"-Messgerät getestet werden.


 Nach erfolgreichem Test den Jumper auf der Delay Unit wieder in Stellung NOR-MAL (JP1-2) bringen!!



CD-R Delay Unit: Testmode bei Jumperstellung JP2-JP3

EDITION: 20/01/94

CD-R Delay Unit 1.629.625.20



EDITION: 20/01/94

Mitteilung